

# redefine

by **morphy richards**®

## Instruction manual

 Please read and keep these  
instructions for future use

TT228000 MUK REV1

# Health & Safety

The use of any electrical appliance requires the following common sense safety rules.

Please read these instructions carefully before using the product.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- If the supply cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The bread may burn, therefore do not use the appliance near or below combustible material such as curtains.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.

## Mains cable

- Do not let the cable run across a cooker or hot area which might damage the cable.

## Personal safety

- Do watch your appliance during use.
- **WARNING:** Do not touch the top of the appliance or other hot parts during or after use, use handles or knobs.
- **WARNING:** Do not wrap the cable around the main body of the appliance during or after use.
- **WARNING:** Do not insert oversize foods, metal, foil packages or utensils into the Toaster.
- **WARNING:** Do not attempt to dislodge food when the appliance is plugged in and never insert cooking utensils into the slot.
- **IMPORTANT:** Do not place bread or other items on top of the slot as this may +damage the appliance and creates a fire hazard.

## Electrical requirements

- Should the fuse in the mains plug require changing, a 13 amp BS1362 fuse must be fitted.
- **WARNING:** This appliance must be earthed.

## Precautions

- Never use the appliance when it is empty (when there is no bread inside) except on first use.
- Do not use very thin or broken slices of bread.
- Do not insert other foods that may drip during the cooking process. In addition to making the cleaning procedure more difficult, these may cause fires.
- Only use for intended purpose.
- Clean the crumb tray regularly: crumbs can smoke or burn.
- Do not insert (by force) foods that are too big for the slot.
- Do not insert forks or other utensils into the Toaster in order to remove bread. As well as damaging the Toaster, there is a high risk of electric shock.
- Should some toast remain blocked in the Toaster, remove the plug from the mains, wait for the Toaster to cool down until it is safe to touch, then turn the Toaster over and shake it gently.



PLEASE BE AWARE OF HOT SURFACES. HANDLE WITH CARE

## Treating scalds

- Run cold water over the affected area immediately.
- Do not stop to remove clothing.
- Seek medical advice quickly.

this is where the similarity ends




this is where the exceptional begins

... the premium, highly innovative Morphy Richards product group.

Driven by principles of innovation and providing exceptional quality, the Redefine range is designed to fulfil the consumer need for brilliantly performing products that have equal aesthetic consideration.

smart **i**deas for your home



### 1 Bread Slot

Makes toasting your favourite bread a breeze, whether it's a thin or thick slice.

### 2 Bread Carriage

Automatically rises and falls to allow perfect browning.

### 3 Glass Panels

Allows you to see your bread turning into toast.

### 4 Browning Setting

Illuminated browning setting which shows you the progress of your toast.

### 5 Start/Stop Button

Engages the toaster to begin/finish the toasting cycle.

### 6 Browning Control

Ensures easy selection for perfect, evenly brown toast everytime.

### 7 Defrost Button

Defrost setting for ease and convenience, so no need to defrost your bread first.

### 8 Reheat Button

Reheat setting allows you to quickly warm up your toast.

### 9 Removable Bread Cages

Secures your bread whilst toasting.

### 10 Removable Crumb Tray

Allows you to easily clean your toaster.

### 11 Crumb Cleaner

Allows you to remove any leftover crumbs from the glass panels.

### 12 Sound Notification


Alerts you when your bread will begin to brown, and when your toast is ready.

# Using your toaster


The following instructions detail the steps to follow to use your new toaster. For cleaning instructions, see page 6.

Before using the toaster for the first time, follow the instructions below to operate the toaster without adding any bread. As with all new electric heating elements, your toaster may emit a 'new' smell when it is first switched on. This is quite normal and not cause for concern.

When first removed from the box the Bread Carriage will be in the low position. This is normal.



1 Plug your toaster into the mains. The Bread Carriage (2) will rise to the 'ready' position. Alternatively, if already plugged in, press any button to wake from standby mode.





2 Place the sliced bread into the Bread Slot (1) and onto the Bread Carriage.




3 Using the Browning Control Button adjust the Browning Setting (4) to the desired level (from 1-7). The Browning Setting will illuminate.



4 Press the Start/Stop Button (5). Your toaster will sound and the bread slices will lower into the Toasting Chamber.



5 The lights on the Browning Setting on the side of the toaster will flash and extinguish one by one as the bread toasts. During the toasting process, your toaster will sound when the bread begins to brown.



6 When ready, your toaster will sound twice, and the toast will automatically rise from the Toasting Chamber.

# Defrosting

To defrost and toast frozen sliced bread.

1

Follow steps 1-3 of 'Using your toaster'.

2

Press the Defrost Button (7).

3

Press the Start/Stop Button (5). The Bread cage will lower automatically and your toaster will notify you when it has finished toasting. The bread cage will automatically rise with your toast.

# Reheating

If you have already made some toast but it has gone cold, you can reheat the toast.

1

Follow steps 1-3 of 'Using your toaster'.

2

Press the Reheat Button (8).

3

Press the Start/Stop Button (5). The Bread cage will lower automatically and your toaster will notify you when it has finished reheating your cold toast. The bread cage will automatically rise with your toast.

**IMPORTANT: DO NOT REHEAT TOAST THAT HAS ALREADY BEEN SPREAD WITH A TOPPING.**

# Browning Control

The Browning Control (6) and Browning Setting (4) adjusts the time taken for the bread to be toasted, the longer the time, the darker and crispier the toast.

You can adjust the Browning Control at any time during the toasting process by reselecting your desired level of browning. The lights on the Browning Setting will reflect your adjustment.

# Cancelling

If for any reason during the toasting process you need to cancel and remove the bread, press the Start/Stop Button (5) to stop. The Bread Carriage (2) rises automatically.

## Hints & Tips

When toasting 2 slices it is recommended they are of equal size and freshness.

Stale bread toasts more rapidly than fresh bread. Therefore, the Browning Control (6) should be set at a lower setting than usual.

All sorts of bread can be used as well as teacakes, small rolls etc. Slices should not however be so thick as to cause burning or jamming within the Bread Slot (1).

If the bread in your Toaster becomes jammed disconnect your Toaster at the socket, allow it to cool for a minimum of 30 minutes, then carefully remove the bread with the cleaning tool.

**IMPORTANT: ALLOW THE TOASTER TO COOL FULLY FOR A MINIMUM OF 30 MINUTES BEFORE PUTTING AWAY.**

## Care & Cleaning

**WARNING: DO NOT TOUCH THE GLASS WHILE IN USE OR AFTER USING. ALLOW TO COOL FOR A MINIMUM OF 30 MINUTES BEFORE CLEANING THE GLASS.**

If the glass on your toaster becomes chipped or cracked by any means it should not be used, or touched. If the glass becomes damaged, contact Morphy Richards for more information.

**UK Helpline 0344 871 0945**


**EIRE Helpline 1800 409 119**

After leaving to cool for a minimum of 30 minutes you can wipe the exterior of your toaster with a clean damp cloth.

If bread crumbs adhere themselves to the glass, you will need to remove them as soon as possible. Failure to do so can cause them to 'burn' onto the glass, making them harder to remove in the future. Follow these steps to clean your toaster.

# Cleaning your toaster

The following instructions detail the steps to follow to clean your toaster.




**1** Press and hold the Start/Stop Button (5) for 5 seconds. The Toaster will sound and the Bread Carriage (2) will automatically lower to the bottom of the Toasting Chamber without heating the elements.




30  
minutes


**2** Unplug the Toaster from the mains. Allow to cool for a minimum of 30 minutes.




**3** Remove the Bread Cages (9) from the Toasting Chamber.



**4** Remove the Crumb Tray (10) and empty. Un-clip the Crumb Cleaner (11) and replace the Crumb Tray into the base of the Toaster.




**5** Use the Crumb Cleaner to remove any bread crumbs visible on the inside of the glass. Do not use any cleaning products or solutions on the glass.




**6** Remove the Crumb Tray. Replace the Crumb Cleaner into the Crumb Tray and replace into the base of the Toaster.

smart ideas for your home



**7** Replace the Bread Cages into the Toasting Chamber. The Bread Cages will only fit into the slots with the handles facing outward.



**8** When finished cleaning, plug your toaster into the Mains. The Bread Carriage will automatically rise to the 'ready' position.

## Contact Us

### Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from. Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

**UK Helpline** 0344 871 0945

**EIRE Helpline** 1800 409 119

**Spares** 0344 871 0945

### Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

**Blog** [www.morphyrichards.co.uk/blog](http://www.morphyrichards.co.uk/blog)

**Facebook** [facebook.com/morphyrichardsuk](http://facebook.com/morphyrichardsuk)

**Twitter** @loveyourmorphy

**Website** [www.morphyrichards.com](http://www.morphyrichards.com)

## Registering your 2 year guarantee

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at

[www.morphyrichards.co.uk](http://www.morphyrichards.co.uk)

Or call our customer registration line

**UK 0344 871 0945**

**IRE 1800 409 119**

N.B. Each qualifying product needs to be registered with Morphy Richards individually. Please note that the 2 year guarantee is only available in the UK and Ireland. Please refer to the one year guarantee for more information.

## Your 1 year guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no, Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date.

Therefore it is vital to retain your original retailer's receipt or invoice to indicate the date of initial purchase. To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

**IF YOU ARE HAVING A PROBLEM  
WITH ONE OF OUR PRODUCTS,  
CALL OUR HELPLINE:**

## Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

**1**

The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.

**2**

The appliance has been used on a voltage supply other than that stamped on the products.

**3**

Repairs have been attempted by persons other than our service staff (or authorised dealer).

**4**

The appliance has been used for hire purposes or non domestic use.

**5**

The appliance is second hand.

**6**

Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion.

**7**

Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.

**8**

Batteries and damage from leakage are not covered by the guarantee.

This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

## Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.

For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.



Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

## Notes



# Troubleshooting

Your toaster is plugged in and switched on at the socket, but will not toast your bread.

## Solution

- Check that the main fuse board in your house has not tripped. If it has been tripped contact the customer helpline.
- Check that the Thermoglass Element is not damaged. For your safety, this product will not power up if it has been damaged.
- Check the fuse in the plug.

---

The Bread Carriage doesn't automatically rise and fall.

## Solution

- Check that the main fuse board in your house has not tripped. If it has been tripped contact the customer helpline.
- Unplug from the wall, wait 10 seconds and replug. This should initiate the toaster operation.
- Check the fuse in the plug.
- Something is jammed in your toaster. Disconnect your Toaster at the socket, allow it to cool for a minimum of 30 minutes, then carefully remove the bread with the cleaning tool.

---

The Glass Panels have visible cracks/chips.

## Solution

- Unplug the glass toaster from the wall and contact the customer helpline.

## Still having a problem?

- Please call our Helpline, as we are more likely to be able to help than the store you purchased the item from. Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

**UK Helpline 0344 871 0945**

**EIRE Helpline 1800 409 119**



**morphy richards®**

The After Sales Division, Morphy Richards Ltd  
Mexborough, South Yorkshire, S64 8AJ  
**UK: 0344 871 0945**  
**EIRE: 1800 409 119**

[www.morphyrichards.co.uk/redefine](http://www.morphyrichards.co.uk/redefine)



TT228000 MUK REV1 03/15