



Exploded View of DF-EF0832K

| No. | Part Name | | No. | Part Name | |
|-----|---------------------------|--|-----|------------------------------|--|
| 1 | Decorative Cover | | 30 | Spring | |
| 2 | Front Guard | | 31 | Display Panel | |
| 3 | Nut | | 32 | Button | |
| 4 | Blade | | 33 | Light Cover | |
| 5 | Heating Wire Assembly | | 34 | Light Support | |
| 6 | Heating Wire Support | | 35 | Control PCB | |
| 7 | Duct Damper | | 36 | NTC | |
| 8 | Adapter | | 37 | Shaft Sleeve | |
| 9 | Screw | | 38 | Screw | |
| 10 | Stepping Motor Adapter | | 39 | Synchronous Motor | |
| 11 | Shade-pole Motor | | 40 | Silicone Ring | |
| 12 | Left Rotating Shaft | | 41 | Shaft Support | |
| 13 | Back Guard | | 42 | Clamp Plate | |
| 14 | Screw | | 43 | Crank | |
| 15 | Dust Filter 1 | | 44 | Connecting Rod | |
| 16 | Dust Filter 2 | | 45 | Steel Ball | |
| 17 | Back Net | | 46 | Tip-over Switch | |
| 18 | Right Rotating Shaft | | 48 | Foot Pad | |
| 19 | Oscillation Support | | 49 | Stepping Motor | |
| 20 | Oscillation Support Cover | | 50 | Gear Wheel | |
| 21 | Power PCB | | 51 | Screw | |
| 22 | Lower Base Cover | | 52 | Rack | |
| 23 | Strong Electricity Switch | | 53 | Remote Control Panel | |
| 24 | Line Press Code | | 54 | Screw | |
| 25 | Power Cord | | 55 | Remote Control PCB | |
| 26 | Wearing Ring | | 56 | Battery | |
| 27 | Base | | 57 | Remote Control Battery Cover | |
| 28 | Screw | | 58 | Remote Control Box | |
| 29 | Locating Nail | | | | |