


# AIR COOLER


MODEL: YS-833A



## INTRODUCTION

- Thank you for purchasing our air cooler.
- Each unit has been manufactured to ensure safety and reliability.
- Before first use, read the instructions carefully and keep it for further reference.

## DIAGRAM



## PERFORMANCE PARAMETERS

Model	Rating Power	Power	Max Water Injection Rate	Specification
YS-833A	220-240V~50/60Hz	150W	40L	540*430*1055MM

## FUNCTIONS

- **Principle of Cool:** took cool water from the water tank by pump or synchronous motor, after reaching the top, the cool water will flow through the wetted pad, then blow off humid cool air rounding the wetted pad by rotational wind wheel. With the water evaporation principle.
- **Adjustable speed:** have three speeds , blow at a wide angle.
- **Cool:** adopt the technology of ice crystal cooling and air humidifying, cut down the temperature from air vent and raise relative humidity, prevent air drying.
- **Anion:** purified and sterilized air by generating negative ion.
- **Deliver wind at a wide angle:** swing the blades automatically, deliver wind at horizontal and vertical wide angle. Swing the blades transversely manually, select the direction discretionarily.

## ASSEMBLING AND WATERING


1. Assembling castors: put the appliance on a flat surface, take out the wrench from box, then assemble the castors.

Attention: the back castors are with brake, but the front ones are without.


2. Watering: open the water in-let door, then add clean water(map 1)
3. There is water outfall hole at the back of unit. (map 2)

Attention:


- a. Pay attention to the level of water tank when add water.(map 3)
- b. The level of water tank should not over “MAX” scale at any time, when humidifying, the total level of water tank should not below “MIN” scale.
- c. Put ice to the water tank if you want to strengthen the efficiency of cooling. But the total level of water tank should not over “MAX” scale.



MAP 1




MAP 2



MAP 3

## OPERATION

- **Speed:** rotate the knob, start the air cooler. The corresponding function changes as follows when



- **Swing:** press the key, the wind swings vertical automatically and the swing indicator light is on. Cancel this function when press again.
- **Anion:** press the key, the anion generator works and releases anion, at the same time the anion indicator light is on. Cancel this function when you press again.
- **Timer:** adjustable 2 hours timer design
- **Cool:** press the key, if add frozen ice box, the temperature from air vent can lower. Cancel this function when press again.

## CAUTION

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, it should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. When the appliance is not in use, switch off and unplug it.
6. Do not insert foreign things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas. Avoid long-term direct solar radiation.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. The level of water tank should not over "MAX" scale at any time, when humidifying, the total level of water tank should not below "MIN" scale.
11. After adding water to the water tank, do not tilt or knock over it when you put or move. If you want to move, please push slowly from the side, in order to avoid spilling.
12. Do not turn over the appliance. If it is toppled over and there are some water in the body, should unplug the power supply first. Then send it to the repair department or after-sales service and overhaul the appliance.
13. Do not cover the air vent.
14. Clean the appearance with a lightly damp cloth. Do not use any type of detergents or solutions. Do not rinse the appliance.

15. Do not make air outlets and inlets near the wall or curtain.
16. Do not knock or shake the body when using, otherwise it may cause stop automatically.
17. The water in tank will easily metamorphose and has odor in summer, please renew the water frequently.
18. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
19. Children should be supervised to ensure that they do not play with the appliance.
20. To avoid the risk caused by instability of unit, you must fix the unit firmly according to manual book.
21. Fan for temperate climates only.
22. Should it be necessary to move the unit after the water has been added, roll gently to the required  
Position and activate the bracket the castors.
23. Children should be supervised to ensure that they do not play with the appliance.
24. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
25. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.