

BRD1100ISILS

Part No.	Description
083184800	INDUCTION UNIT EGO
083184800-R	INDUCTION UNIT EGO - REWORK
082060800	BEARING DOOR
083479700	ELEMENT OVEN FAN 2.0KW
083576212	BEZEL RG ELEC ON-OFF CHR
083576227	BEZEL RG ELEC 1-8 CHR
083576243	BEZEL FS MF CHR
083576225	BEZEL RG ELEC T/OV GRILL CHR
083576244	BEZEL FS M/OV CHR
083576245	BEZEL FS M/OV MF CHR
083677200	BLOCK TERMINAL 7 POLE SKF 7FTW
083714000	BLOCK TERMINAL 7 POLE SKF 7FTW
502895700	BRACKET PLINTH
082533800	CATCH ROLLER (NYLON)
082101600	CLIP TUBULAR
562802005	COVER PLINTH INNER 110 BLK
562895813	COVER PLINTH 110 BLK
603135600	REAR FAN COVER
013755200	DOOR INNER RG55M/OV LH AU ASSY
013755201	DOOR INNER RG55M/OV RH AU ASSY
013755300	DOOR INNER 55 TOP LH AU ASSY
562810114	DOOR SKIN 110CM LH MAIN OVEN BLK
562810115	DOOR SKIN 110CM RH MAIN OVEN BLK
013759700	DOOR TOP ASSY RG BEL RICH55BLK
601823319	DOOR INNER 55 TOP MOT
083081200	INDUCTOR 180/150MM - *****MUST READ NOTES*****
083517300	ELEMENT SLOW COOK
083592000	ELEMENT GRILL DUAL 2.7KW
083479900	ELEMENT BASE
083541200	ELEMENT BASE 700W
083123900	ELEMENT OVEN FAN 2.0KW (3 RING MAIN OVEN)
083292100	(RTN) FAN COOLING RAL1238S1
083292101	FAN COOLING RAH1238S1
083595600	FAN OVEN CIRCULATION A20R00706
083624902	TOWEL RAIL RG 110 CHR
081830501	FOOT LEVELLING LONG
083231800	CONVERTER 75.96475.575 *****MUST READ NOTES*****
083232000	GENERATOR 4 ZONE 75.96475.577 *****MUST READ NOTES*****
603249500	OVENPAN MAIN 110
083666400	GUIDE SHELF RG M/OV LH
083666500	GUIDE SHELF RG TO/OV LH

Part No.	Description
083666401	GUIDE SHELF RG M/OV RH
083666501	GUIDE SHELF RG TO/OV RH
082587204	HANDLE DOOR 308CRS CHR
083605500	HARNESS 90 IND CHASSIS
083612300	HARNESS 90LH MF OVEN CHASSIS
083612301	HARNESS 90LH MF OVEN TOPBOX
083616800	HARNESS 90LH MF TO CHASSIS
083616802	HARNESS 90LH MF TO TOPBOX
083644600	HARNESS 100 RH RICH CHASSIS
083644601	HARNESS 100 RH RICH TOPBOX
083644801	HARNESS 90/100 IND.G5 TOPBOX
082905901	HINGE DROP DOWN DOOR (TOP)
082979700	BOTTOM HINGE FOR SIDE OPENING DOOR FOR TOP HINGE FOR SIDE OPENING DOOR USE 082979701
082979701	HINGE FOR SIDE OPENING DOORS (TOP HINGE) FOR SIDE OPENING SIDE DOOR HINGE FOR BOTTOM PART OF DOOR USE 082979700
082852401	HOLDER PHIAL
012929439	HOTPLATE ASS GLASS 110EI G5BLK (NLA DUE TO HIGH PRICE)
083633200	KIT TOWEL RAIL FIXING
083623300	KNOB ST RICH BLK/CHR
083160201	LAMP ASSY OVEN HAL
082964902	LENS NEON WHITE
082044000	LOCKNUT FOOT
082964900	NEON LAMP ASSEMBLY
083480700	NEON DUAL LEAD
083719101	NEON GAS
080215756	BR54EW CLIP IN DOOR
503753104	PANEL RG E HOB REAR 110 AU
083231900	POWER BOARD 75.96475.576 ***** MUST READ NOTES *****
083231500	TOUCH CONTROL FLEX MASTER ZONE 75.96469.588 ****MUST READ NOTES****
083231600	TOUCH CONTROL FLEX 2 ZONE 75.96469.590 *****MUST READ NOTES*****
083231700	TOUCH CONTROL FLEX 1 ZONE 75.96469.592 *****MUST READ NOTES****
013707002	PLINTH ASSY 110
083492800	REGULATOR ENERGY EGO SINGLE
083666200	TELESCOPIC SLIDERS (LEFT)
083666300	TELESCOPIC SLIDERS (RIGHT)
083758201	SEAL FOAM STRIP 2.0MM
031797200	KIT SEAL OVEN 2 METRES

Part No.	Description
080180734	SCREW M4X12 TT PCSK CH BLK
083667301	WIRE SHELF MAIN 110
082554300	SPACER OVEN FAN
083614900	SPRING
082494402	STRIKER DOOR (SILVER)
082963200	HINGE SUPPORT
083010000	SWITCH T/OV 42.03000.029
083586000	SWITCH ON/OFF 42/04900.011
082914200	SWITCH THERMAL CUTOUT 120C
083319801	SWITCH THERMAL CUTOUT T220
083489500	SWITCH L130C THERMAL CUTOUT
082956100	SWITCH M/OV 42.02900.033
082808902	SWITCH THERMAL FAN 70C
083675500	SWITCH SEL MF
082558001	THERMOSTAT EGO OVEN (EGO NUMBER 55.17069.090)
083437200	THERMOSTAT EGO 55.1769.220 (GRILL)
083684300	TIMER OT-3100-CLF-13FA3BW-G
083249600	OVENPAN INSERT MAIN 110
030116310	WHEEL ASSY
080180183	SPIRENUT SNU01877.17.4 NO6EX
082606772	BADGE BELLING BLK/SIL ENAMEL BBELLING013
081050400	WASHER BEARING
082057901	BRACKET STABILITY
602129300	GRILL ELEMENT COVER (60CM)
561776724	OUTERSIDE FS COOKERS
082065700	ROD PUSHROD 040