



Baumatic

Spare parts list for Baumatic model *BH900*

Position	Part No.	Description
1	SYCI353B	Inside chimney
2	SYC0353B	Outside chimney
3	SY0004	Outlet(vent)
4	SYCB353B6	Connection board
5	SYS353F	Shell
6	SYFR353FP	Frame
7	SYLR353B6	Left/right corner
8	SYFB353F	Front board
9	SYKL-08	LED light
10	ST1	Charoal filter
11	SYCMF03	Motor accessory 750m3/h
12	SYS013	Switch bracket
13	SYEB388	Electronic Button assembly
14	SYF353F	Filter
15, 16	SYPCBBOX	PCB box section
17	SYEPCBLEDE	PCB board
18	SYLBH353F	Lamp board
19	SYB353F	Back board
20	SYCP21	Cable (with AU plug)
21	SYOB353B01	outside chimney bracket
21	SYIB353B01	inside chimney bracket
22	SYSN503B	Srew