

ICS6SG2

27.2.14

Drawing No.	Part No.	Description
CUA007	601001094	TERMINAL BOARD
CUB011	601001086	HOB BOTTOM
CUB012	601001087	FIXING ACCESSORIES KIT
CUC102	601001069	2 HEAT GRILL BURNER
CUC174	601001623	FAST BURNER HEAD
CUC175	601001196	SEMI-FAST AND AUXILIARY BURNER HEAD
CUC176	601001194	AUXILIARY BURNER HEAD
CUC180	601001648	FAST WALL BAFFLE COVER
CUC181	601001195	SEMI-FAST AND AUXILIARY WALL BAFFLE COVER
CUC186	601001193	AUXILIARY BURNER BAFFLE COVER
CUC240	601001645	HOB BOTTOM
CUC508	601001219	HOB GRILL RUBBER
CUD002	601001216	IGNITION GENERATOR
CUD005	601001647	Microswitch Catenary Assembly
CUD079	601001650	BURNER COTROL KNOB
CUD532	601001647	IGNITION MICROSWITCH
CUE031	601001097	SEMI-FAST AND AUXILIARY BURNER IGNITION GLOW PLUG
CUE031	601001098	SEMI-FAST AND AUXILIARY BURNER IGNITION GLOW PLUG
CUE161	601001080	TAP FEED RAMP
CUE190	601001203	HOSE CONNECTION GASKET
CUE191	601001202	UNION ELBOW
CUE461	601001103	RIGHT SEMI-FAST BURNER RAMP ASSEMBLY
CUE462	601001084	AUSILIARY BURNER RAMP ASSEMBLY
CUE470	601001101	LEFT SRB RAMP ASSEMBLY
CUE477	601001074	TAP BRIDLE
CUM101	601001069	2 BURNER GRILL FOR ULTRA-FAST BURNER
CUZ432	601001209	RUBBRE STAY-CLEAN BRUSH
E623	639000568	Rapid burner tap
E621	639000569	Semirapid burner tap
E624	639000564	Auxiliary burner tap