

BRD/BCC KNOB TROUBLESHOOTING / HOW TO INSTALL



Check if the clip is missing or has come off the knob. It has to be inserted back the correct way as shown in photos above. If clip is missing, knob needs to be replaced as clip doesn't come separately. P/N is **083623300(BRD)** or **083576401(BCC)**



Have all 3 parts (bezel, spring, knob) in one hand, compress them together & install them all to the shaft. Where required, spring p/n is **083614900**