




LOC	Part number	Description	QTY
1	30303400220	DOOR FRAME - RIGHT SIDE	1
2	30500400215	INNER DOOR GLASS	1
3	30500300098	MIDDLE DOOR GLASS	1
4	30500201582	OUTER DOOR GLASS	1
5	30400700283	HANDLE	1
6	30201400005	HANDLE WASHER	2
7	30303400219	DOOR FRAME - LEFT SIDE	1
8	30303500146	DOOR BRACKET	1
9	30303600001	HANDLE FIXING PLATE	2
10	30201000020	MIDDLE GLASS FIXING BLOCK RUBBER	3
11	30303700011	MIDDLE DOOR GLASS FIXING BLOCK	2
12	30201000018	MIDDLE GLASS FIXING BLOCK RUBBER	2
13	30301100144	REAR ELEMENT BAFFLE	1
14	30101200283	REAR ELEMENT	2
15	30302600040	HINGE FIXING PLATE	1
16	30302300127	LEFT SIDE PANEL OF THE CAVITY	1
17	20304000018	DOOR SEAL	1
18	30403900025	TELESCOPIC RAIL	1
19	30403900024	TELESCOPIC RAIL	1
20	30402500680	KNOB COLLAR - TEMPERATURE KNOB	1
21	30402500717	KNOB	2
22	30100900003	TEMPERATURE CONTROL SWITCH	1
23	30102500060	INDICATOR LIGHT	1
24	30100200162	TIMER	1
25	30402500679	KNOB COLLAR - FUNCTION KNOB	1
26	30304400511	CONTROL PANEL FRONT PANEL	1
27	30402500678	KNOB	5
28	30402500681	KNOB COLLAR - BURNER KNOB	5
29	30500101638	CONTROL PANEL GLASS	1
30	30217400001	CONTROL PANEL FIXED BUCKLE	4
31	30100500076	OVEN FUNCTION SWITCH	1
32	30301400127	CONTROL PANEL FIXING PLATE	1
33	30403100079	GAS VALVE -Ø0.44	1
34	30403100080	GAS VALVE -Ø0.34	2
35	30403100078	GAS VALVE -Ø0.65	1
36	30300100060	VALVE CLAMP	1
37	30401900357	INLET PIPE	1
38	30403100094	GAS VALVE -Ø0.29	1
39	30300100059	VALVE CLAMP	1
40	30302800086	OVEN REINFORCEMENT PLATE	1
41	30400200079	SIDE RACKS - LEFT SIDE	1
42	30101100008	SQUARE OVEN LAMP	1
43	30402300002	AIR INTAKE CONNECTOR	1
44	30200300012	SEALING RING	2
45	30402300010	REGULATOR	1
46	2030300355	CAVITY ASSEMBLY	1
47	30312600040	COVER BOARD FOR EXHAUST FLUE	1
48	30301800043	BOTTOM BOARD FOR EXHAUST FLUE	1
49	30100800001	THERMOSTAT	1

LOC	Part number	Description	QTY
50	30312600039	COVER BOARD FOR EXHAUSTING FLUE	1
51	30102300032	IGNITOR	1
52	30100400083	COOLING FAN	1
53	30301300037	HEAT SHIELD	1
54	30101000014	ROUND LAMP COMPONENTS	1
55	30100700008	OVERHEAT PROTECTOR	1
56	30401100018	EXHAUST PIPE	1
57	30408700001	FIXING CLIP	2
58	30101200282	UPPER ELEMENT	1
59	30301700008	BOTTOM SUPPORT BLOCK FOR EXHAUST FLUE	2
60	30301700010	SUPPORT BLOCK FOR EXHAUST FLUE	1
61	30304100001	CLIPS FOR THERMOSTATS	4
62	30100300060	CIRCULATION FAN	2
63	30102600028	TERMINAL BLOCK	1
64	30302200153	BACK COVER FOR PRODUCT	1
65	30302700073	OVEN CONNECTING PLATE	2
66	30301500026	CAVITY REAR BRACKET	1
67	30302800058	OVEN REINFORCEMENT PLATE	1
68	30102400180	POWER CORD	1
69	30302900409	OVEN FIXING PLATE	1
70	30302800087	OVEN REINFORCEMENT PLATE	1
71	30200600008	SLIDER	1
72	30401600042	SPRING	1
73	30101700040	MICRO SWITCH	1
74	30217500003	FIXING BASE	1
75	30302900273	OVEN FIXING PLATE	2
76	30302700172	OVEN CONNECTING PLATE	2
77	30302900404	OVEN FIXED BOARD	2
78	30202600001	ADJUSTABLE LEGS	4
79	30204100033	KICK PANEL FIXING CLIPS	2
80	30302900378	FIXING PLATE FOR KICK PANEL CLIPS	2
81	30213800025	KICK PANEL	1
82	30302300128	RIGHT SIDE PANEL OF CAVITY	1
83	30400200080	SIDE RACKS - RIGHT SIDE	1
84	30313300056	OVEN FIXING BLOCK	2
85	30302600041	HINGE FIXING PLATE	1
86	30302900321	OVEN FIXING PLATE	2
87	30302900301	OVEN FIXING PLATE	1
88	30101200220	LOWER ELEMENT	1
89	30307800018	INNER COMPARTMENT BAFFLE	1
90	30302900275	OVEN FIXING PLATE	2
91	30403900028	TELESCOPIC RAIL FOR STORAGE DRAWER	1
92	30307100157	STORAGE DRAWER BASE AND SIDES	1
93	30307800021	BAFFLE	1
94	30307100161	STORAGE DRAWER LINING PLATE	1
95	30307100239	STORAGE DRAWER FRONT PANEL	1
96	30403900027	TELESCOPIC RAIL FOR STORAGE DRAWER	1
97	30307800020	BAFFLE	1
98	30301200013	FIXING BOARD FOR BOTTOM ELEMENT	1

LOC	Part number	Description	QTY
99	30400600065	DOOR HINGE	2
100	30313300059	OVEN FIXING BLOCK	1
101	30313300058	OVEN FIXING BLOCK	1
102	2030900118	CAVITY PANEL COMPONENT	1
103	30304500537	DOOR TRIM	1
104	2040600035	SPLASHBACK ASSEMBLY	1
105	30402600505	TRIVET - CENTRE	1
106	30402600504	TRIVET - LEFT AND RIGHT	2
107	30403000066	RAPID BURNER CAP	1
108	30402900038	RAPID BURNER CAP	1
109	30403000098	WOK BURNER CAP-INNER	1
110	30403000097	WOK BURNER CAP-OUTER	1
111	30402900060	WOK BURNER	1
112	30403000052	SEMI RAPID BURNER CAP	2
113	30402900027	SEMI RAPID BURNER	2
114	30403000040	AUXILIARY BURNER CAP	1
115	30402900019	AUXILIARY BURNER	1
116	2040500353	HOB PANEL ASSEMBLY	1
117	30302900290	OVEN FIXED BOARD	2
118	30402400004	IGNITION PIN	3
119	30401800006	THERMOCOUPLE	2
120	30402100077	NOZZLE	2
120	30402100104	NOZZLE	2
121	30402800024	SEMI RAPID BURNER BASE	2
122	30402001566	ALUMINIUM TUBE	1
123	30402400022	IGNITION PIN	1
124	30401800044	THERMOCOUPLE	1
125	30313900001	IGNITION PIN FIXING NUT	1
126	30402100047	NOZZLE	1
126	30402100214	NOZZLE	1
127	30402001565	ALUMINIUM TUBE	1
128	30402800038	WOK BURNER BASE	1
129	30402800042	NOZZLE BLOCK	1
130	30402001567	ALUMINIUM TUBE	1
131	30402100147	NOZZLE	1
131	30402100148	NOZZLE	1
132	30402800033	RAPID BURNER BASE	1
133	30402001563	ALUMINIUM TUBE	1
134	30401600003	SPRING	1
135	30402400003	IGNITION PIN	1
136	30402001564	ALUMINIUM TUBE	1
137	30402800017	AUXILIARY BURNER BASE	1
138	30401800005	THERMOCOUPLE	2
139	30402100094	NOZZLE	1
139	30402100164	NOZZLE	1
140	30400100044	WIRE SHELF	2
141	30401000025	GRILL INSERT	2
142	30304200053	BAKING TRAY	2
143	30400100052	BAKING TRAY HOLDER	1

LOC	Part number	Description	QTY
	2030102174	COMPLETE DOOR	1
	2040300573	CONTROL PANEL ASSEMBLY	1
	30102101227	CONNECTION LINE	1
	30102101299	CONNECTION LINE	1
	30102101422	CONNECTION LINE	1
	30105000060	WIRE FOR ENCODER SWITCH (FOR DOOR LOCK)	1