




No	Part number	Part Description	QTY
1	30300400939	HOB	1
4	30200900042	FIXATION BLOCK FOR INNER GLASS	2
4	30102900058	ELECTROMAGNETIC MODULE	1
5	30302700224	CONNECTING PLATE	2
6	30302700218	CONNECTING PLATE	1
7	30302700217	CONNECTING PLATE	1
8	30302700238	CONNECTING PLATE	1
9	30305900647	CONTROL PANEL	1
10	30102500073	INDICATOR LAMP	3
11	30201000030	MIDDLE GLASS SUPPORT RUBBER	2
12	30100500051	2 FUNCTIONS SWITCH	1
13	30100500084	4 FUNCTIONS SWITCH	1
13	30100500085	2 FUNCTIONS SWITCH	1
14	30100900028	TEMPERATURE SWITCH	1
15	30100900030	TEMPERATURE SWITCH	1
15	30100900031	TEMPERATURE SWITCH	1
16	30105700010	ENCODER SWITCH	1
17	30105700028	ENCODER SWITCH	1
18	30101600442	DISPLAY	1
19	30200200030	DISPLAY BOARD HOLDER	3
19	30200200037	DISPLAY BOARD HOLDER	1
20	30207700007	PCB FIXED BRACKET	1
21	30101500239	PCB	1
22	30100600027	TEMPERATURE MEASURING PROBE ASSEMBLY	1
23	30402500589	KNOB-4 FUNCTIONS SWITCH	1
24	30402500590	KNOB-TEMPERATURE CONTROL SWITCH	1
25	30402500591	KNOB-12 FUNCTIONS CODE SWITCH	1
26	30402500605	KNOB-2 FUNCTIONS SWITCH REAR WITH TEMPERATURE CONTR	2
27	30402500646	KNOB-CODE SWITCH WITH BRIDGE	2
27	30402500656	KNOB-CODE SWITCH	3
28	30301200012	BOTTOM ELEMENT FIXING PLATE	2
29	30316200124	OVEN BAFFLE	2
30	30302900301	OVEN FIXED PLATE	2
31	30302900347	OVEN FIXED PLATE	1
31	30302700205	CONNECTING PLATE	1
32	30302700210	CONNECTING PLATE	1
33	30302700216	CONNECTING PLATE	2
34	30302800074	OVEN STIFFENER	1
35	30315000558	CAVITY PANEL	1
36	30315000563	CAVITY PANEL	1
37	30315000564	CAVITY PANEL	1
38	2040700308	CAVITY ASSEMBLY	1
39	2040700310	CAVITY ASSEMBLY	1
40	2040700312	CAVITY ASSEMBLY	1
41	30600100054	HEAT RESERVATION FIBRE	1
41	30600100176	HEAT RESERVATION FIBRE	1
42	30600100036	HEAT RESERVATION FIBRE	1
42	30600100163	HEAT RESERVATION FIBRE	1

No	Part number	Part Description	QTY
43	30600100170	HEAT RESERVATION FIBRE	1
43	30600100164	HEAT RESERVATION FIBRE	1
44	30201000031	MIDDLE GLASS SUPPORT RUBBER	2
45	30600100064	HEAT RESERVATION FIBRE	1
45	30600100171	HEAT RESERVATION FIBRE	1
47	30401600005	SPRING	6
48	2030400013	DOOR SEAL	1
48	30302800070	OVEN STIFFENER	1
48	30302800071	OVEN STIFFENER	1
49	2041000019	DOOR SEAL	1
50	2041000022	DOOR SEAL	1
51	30302600053	FIXATION BOARD FOR HINGE	1
52	30302600049	FIXATION BOARD FOR HINGE	1
53	30302600044	FIXATION BOARD FOR HINGE	1
54	30302600054	FIXATION BOARD FOR HINGE	1
55	30301500019	INNER BACK BRACKET	1
56	30301500018	INNER BACK BRACKET	1
57	30301500031	INNER BACK BRACKET	2
58	30302300160	LEFT OR RIGHT SIDE PANELS OF THE SHELL	1
59	30302300162	LEFT OR RIGHT SIDE PANELS OF THE SHELL	1
60	30302200187	REAR PANEL	1
61	30302200195	REAR PANEL	1
62	30302700199	CONNECTING PLATE	1
63	30302700198	CONNECTING PLATE	1
64	30302700213	CONNECTING PLATE	1
65	30313200116	SUPPORTIVE BRACKET	1
66	30313200113	SUPPORTIVE BRACKET	1
67	30302700214	CONNECTING PLATE	1
68	30308500029	SUPPORT PLATE	1
69	30301100115	GUARDING BOARD FOR REAR ELEMENT	1
70	30301100168	GUARDING BOARD FOR REAR ELEMENT	2
71	30309600142	COVER PLATE	3
72	30309600143	COVER PLATE	1
73	30401100002	EXHAUSTING FLUE	1
73	30401100021	EXHAUSTING FLUE	1
73	30401100022	EXHAUSTING FLUE	1
74	30201600011	NON-SLIP FOOT	3
75	30101200287	ELEMENT	1
76	30101200292	ELEMENT	2
77	30101200305	ELEMENT	1
78	30101200288	ELEMENT	1
78	30101200290	ELEMENT	1
79	30101200291	ELEMENT	1
80	30101000014	ROUND LAMP COMPONENT	4
81	30104800010	BINDING POST	1
82	30313400041	EXHAUST PIPE UPPER/BOTTOM COVER PANEL	1
83	30313400040	EXHAUST PIPE UPPER/BOTTOM COVER PANEL	1
84	30301800050	BOTTOM BOARD FOR EXHAUSTING FLUE	1

No	Part number	Part Description	QTY
85	30312600011	COVER BOARD FOR EXHAUSTING FLUE	1
86	30301800051	BOTTOM BOARD FOR EXHAUSTING FLUE	1
88	30100400102	COOLING FAN	1
89	30312600017	COVER BOARD FOR EXHAUSTING FLUE	1
91	30100400101	COOLING FAN	1
92	30100300066	CIRCULATION FAN ASSEMBLY	3
93	30400200094	GUIDE BRACKET	2
94	30400200087	GUIDE BRACKET	2
95	30400200088	GUIDE BRACKET	1
96	30400200091	GUIDE BRACKET	1
97	30400300005	GUIDE BRACKET FIXED SHAFT	6
98	30100700008	OVER-HEAT PROTECTOR	1
98	30100700015	OVER-HEAT PROTECTOR	2
98	30100700027	OVER-HEAT PROTECTOR	1
98	30100700054	OVER-HEAT PROTECTOR	1
99	30100800003	THERMOSTAT	3
100	30304100001	CLIPS FOR THERMOSTATS	6
101	30407300019	SHAFT BRACKET	1
102	30407300020	SHAFT BRACKET	1
103	30407300022	SHAFT BRACKET	1
104	30407300023	SHAFT BRACKET	1
105	30404300007	SHAFT BRACKET FIXING SLEEVE	4
106	30407200012	DOOR LOCK ASSEMBLY LH/ RH	2
107	30400700366	HANDLE	1
108	30303600001	FIXATION BOARD FOR HANDLE	3
109	30201400005	HANDLE SEAL	6
110	30500201445	DOOR GLASS	1
111	30500400235	INNER GLASS	1
112	30200900034	FIXATION BLOCK FOR INNER GLASS	1
113	30200900035	FIXATION BLOCK FOR INNER GLASS	1
114	30303500175	TOP BRACKET	1
115	30303400309	DOOR BRACKET	1
116	30303400305	DOOR BRACKET	1
117	30400600096	HINGE ASSEMBLY	2
118	30201000032	MIDDLE GLASS SUPPORT RUBBER	1
119	30406200021	CATCH PIN	4
120	30202100026	CUSHION BLOCK	4
120	30202100026	CUSHION BLOCK	10
120	30202100026	CUSHION BLOCK	6
120	30700300009	RETAINER	40
120	30304500414	DOOR TRIM	1
121	30213800011	KICK PANEL	1
121	30400700366	HANDLE	1
122	30500201432	DOOR GLASS	1
123	30500400278	INNER GLASS	1
124	30200900036	FIXATION BLOCK FOR INNER GLASS	2
125	30200900037	FIXATION BLOCK FOR INNER GLASS	2
126	30303500180	TOP BRACKET	1

No	Part number	Part Description	QTY
127	30303400310	DOOR BRACKET	1
128	30303400311	DOOR BRACKET	1
129	30407200011	DOOR LOCK FIXING BASE	2
130	30304500417	DOOR TRIM	1
131	30201000032	MIDDLE GLASS SUPPORT RUBBER	1
132	30302800071	OVEN STIFFENER	1
133	30302800070	OVEN STIFFENER	1
135	30400700365	HANDLE	1
135	30500201446	DOOR GLASS	1
136	30500400258	INNER GLASS	1
137	30303500182	TOP BRACKET	1
138	30303400306	DOOR BRACKET	1
139	30303400312	DOOR BRACKET	1
140	30304500421	DOOR TRIM	1
141	30100600035	TEMPERATURE MEASURING PROBE ASSEMBLY	1
142	30200300053	SEAL RING	1
143	30301900013	EXHAUST PIPE BAFFLE PLATE	1
144	30301900014	EXHAUST PIPE BAFFLE PLATE	2
145	30102101411	CONNECTING WIRE	1
146	30102101512	CONNECTING WIRE	1
147	30400100070	RACK	3
148	30400100071	RACK	4
149	30400800002	TONGS FOR RACK	1
150	30400100074	RACK	1
151	30401000013	GRILL INSERT FOR BAKING TRAY	1
152	30401700008	TELESCOPIC RUNNER	4
153	30401700009	TELESCOPIC RUNNER	4
154	30302800082	OVEN STIFFENER	2
155	30212400018	ROLLER	2
156	30302900350	OVEN FIXED PLATE	1
157	30302900351	OVEN FIXED PLATE	2
158	30406200021	CATCH PIN	4
159	30700500269	SCREWS	2
160	30700500270	SCREWS	2
161	69900600249	HEX KEY	1
162	30304200058	BAKING TRAY	1
163	30401000028	GRILL INSERT FOR BAKING TRAY	1
164	30401000029	GRILL INSERT FOR BAKING TRAY	1
165	30401000030	GRILL INSERT FOR BAKING TRAY	4
166	30319400041	SEPARATOR PLATE	1
167	30319400042	SEPARATOR PLATE TRIM	2
168	30319400043	SEPARATOR PLATE TRIM	2
169	30313300075	OVEN FIXED BOARD	1
170	30313300076	OVEN FIXED BOARD	1
171	30205700024	OIL COLLECTOR	1
172	30401600039	SPRING	3
173	30502201330	CERAMIC GLASS PANEL	1
174	30211000019	PANEL WASHER	10

No	Part number	Part Description	QTY
175	30201000030	MIDDLE GLASS SUPPORT RUBBER	2
176	30500300112	MIDDLE GLASS	1
177	30500300112	MIDDLE GLASS	1
178	30105000036	OVEN WIRING	1
179	30105000037	OVEN WIRING	1
180	30105000061	OVEN WIRING	1
181	30205800015	PRESS THE PLATE	1
182	30300100075	HOLDER	2
183	30302900360	OVEN FIXED PLATE	2
184	30302900347	OVEN FIXED PLATE	1
185	30400700373	HANDLE	1
	2040200899	COMPLETE DOOR - GRILL DOOR	1
	2040201132	COMPLETE DOOR - MAIN LHS	1
	2040200938	COMPLETE DOOR - TALL	1