

Key	Part number	Description	QTY
1	30300400901	Hob	1
2	30313300075	Oven fixed board	1
3	30313300076	Oven fixed board	1
4	30402600474	Trivet	1
5	30402600473	Trivet	2
6	30401900426	INTAKE-TUBE	1
7	30300100075	Holder	1
8	30101700044	MICRO SWITCH	1
9	30403100225	Valve-Φ0.65	1
10	30403100226	Valve-Φ0.44	1
11	30403100227	Valve-Φ0.35	2
12	30403100228	Valve-Φ0.27	1
13	30200300012	Seal ring	2
14	30302900364	Oven fixed plate	1
15	30208200005	Microswitch pressure plate	5
16	30402800009	WOK Burner base	1
17	30402400012	WOK IGNITION PIN	1
18	30401600001	SNAP HOOK	1
19	30402800032	RD burner base	1
20	30402400004	SR IGNITION PIN	1
20	30402400004	SR IGNITION PIN	1
21	30402800022	SR burner base	2
22	30402800016	AU burner base	1
23	30401800012	WOK thermocouple	1
24	30401800078	RD thermocouple	2
24	30401800005	RD thermocouple	2
25	30402100129	Nozzle-Y1.0	1
26	30402100238	Nozzle-Y1.8	1
27	30402100056	Nozzle-Y1.55	1
28	30402100047	Nozzle-Y1.18	2
29	30402100105	Nozzle-Y0.7	2
30	30402100031	Nozzle-Y0.9	1
31	30402100031	Nozzle-Y0.9	1
32	30402100094	Nozzle-Y0.53	1
33	30402900085	Wok buerner	1
34	30402900037	SR buerner	1
35	30402900026	RD buerner	2
36	30402900018	AU buerner	1
37	30403000031	Burner cap-Wok-outer	1
38	30403000013	Burner cap-WOK-inner	1
39	30403000064	Burner cap-SR	1
40	30403000050	Burner cap-SR	2
41	30403000038	Burner cap-AU	1
42	30102300040	PULSE IGNITER	1
43	30402001513	aluminuim pipe	1
44	30402001514	aluminuim pipe	1
45	30402001516	aluminuim pipe	1
46	30402001517	aluminuim pipe	1

47	30402001539	aluminuim pipe	1
48	30302800070	Oven stiffener	1
48	30305900647	control panel	1
49	30302800071	Oven stiffener	1
49	30102500073	indicator lamp	3
51	30100500084	4 functions switch	1
51	30100500085	2 functions switch	1
51	30200200037	display board holder	1
52	30100500051	2 functions switch	1
53	30100900030	TEMPERATURE SWITCH	2
53	30100900031	TEMPERATURE SWITCH	1
54	30105700010	encoder switch	1
55	30105700028	encoder switch	1
57	30500300112	middle glass	1
58	30207700007	PCB fixed bracket	1
59	2040700308	Cavity assembly	1
59	30101500239	PCB	1
61	30402500588	Knob-gas	5
62	30402500589	Knob-4 functions switch	1
63	30402500590	Knob-temperature control switch	1
64	30402500591	Knob-12 functions code switch	1
65	30402500605	Knob-2 functions Switch rear with temperature contro	2
67	30301200012	Bottom element fixing plate	2
68	30316200124	Oven baffle	2
69	30302900301	Oven fixed plate	2
70	30302700205	connecting plate	1
71	30302700210	connecting plate	1
72	30302700216	connecting plate	2
74	30315000558	cavity panel	1
75	30315000563	cavity panel	1
76	30315000564	cavity panel	1
77	2040700310	Cavity assembly	1
78	2040700312	Cavity assembly	1
80	30600100036	heat reservation fibre	1
80	30600100054	heat reservation fibre	1
80	30600100163	heat reservation fibre	1
81	30600100171	heat reservation fibre	1
81	30600100176	heat reservation fibre	1
82	30600100064	heat reservation fibre	1
84	30600100164	heat reservation fibre	1
85	30600100170	heat reservation fibre	1
86	30401600050	spring	10
86	30401600005	spring	6
87	2030400013	Door seal	1
88	2041000019	Door seal	1
89	2041000022	Door seal	1
90	30302600053	fixation board for hinge	1
91	30302600049	fixation board for hinge	1
92	30302600054	fixation board for hinge	1
93	30302600044	fixation board for hinge	1
94	30402400004	IGNITION PIN	2

94	30301500019	inner back bracket	1
95	30301500018	inner back bracket	1
96	30201900020	Burner base waterproof ring	1
96	30301500031	inner back bracket	2
97	30302300160	Left or right side panels of the shell	1
98	30302300162	Left or right side panels of the shell	1
99	30302200208	rear panel	1
100	30302200187	rear panel	1
101	30302700198	connecting plate	1
102	30302700199	connecting plate	1
103	30302700213	connecting plate	1
104	30313200113	supportive bracket	1
105	30313200116	supportive bracket	1
106	30302700214	connecting plate	1
107	30308500029	Support plate	1
108	30402200007	Intake elbow	1
109	30402300010	Regulator	1
109	30301100115	guarding board for rear element	1
110	30301100168	guarding board for rear element	2
111	30309600142	Cover plate	3
112	30401100002	exhausting flue	1
112	30401100021	exhausting flue	1
112	30401100022	exhausting flue	1
113	30201600011	Non-slip foot	3
114	30101200287	Element	1
115	30101200292	Element	2
116	30101200305	Element	1
117	30101200288	Element	1
118	30101200290	Element	1
118	30101200291	Element	1
119	30101000014	ROUND LAMP COMPONENT	4
120	30102600033	TERMINAL BLOCK	1
121	30313400041	Exhaust pipe upper/bottom cover panel	1
122	30313400040	Exhaust pipe upper/bottom cover panel	1
123	30301800050	bottom board for exhausting flue	1
124	30312700003	Baffle plate for exhausting flue	1
125	30312600017	cover board for exhausting flue	1
126	30302900350	Oven fixed plate	1
128	30301800051	bottom board for exhausting flue	1
129	30312600011	cover board for exhausting flue	1
130	30100400102	Cooling fan	1
131	30100400101	Cooling fan	1
131	30100300066	circulation fan assembly	3
132	30400200087	GUIDE BRACKET	2
133	30400200088	GUIDE BRACKET	1
134	30400200091	GUIDE BRACKET	1
135	30400200094	GUIDE BRACKET	2
136	30400300005	Guide bracket fixed shaft	6
137	30100700008	over-heat protector	1
137	30100700015	over-heat protector	2
137	30100700027	over-heat protector	1

137	30100700054	over-heat protector	1
138	30100800003	THERMOSTAT	3
139	30304100001	CLIPS FOR THERMOSTATS	6
140	30407300019	SHAFT BRACKET	1
141	30100600027	TEMPERATURE MEASURING PROBE ASSEMBLY	1
141	30407300020	SHAFT BRACKET	1
142	30407300022	SHAFT BRACKET	1
143	30407300023	SHAFT BRACKET	1
144	30404300007	SHAFT BRACKET Fixing sleeve	4
145	30407200012	DOOR LOCK ASSEMBLY LH/ RH	1
145	30407200012	DOOR LOCK ASSEMBLY LH/ RH	1
146	30400700366	handle	1
146	30400700366	handle	1
146	30400700373	handle	1
147	30303600001	fixation board for handle	1
147	30303600001	fixation board for handle	1
147	30303600001	fixation board for handle	1
148	30201400005	handle seal	2
148	30201400005	handle seal	2
148	30201400005	handle seal	2
149	30500201445	door glass	1
150	30500400235	inner glass	1
151	30200900034	fixation block for inner glass	1
152	30200900035	fixation block for inner glass	1
153	30303500175	top bracket	1
154	30303400305	door bracket	1
155	30303400309	door bracket	1
156	30400600096	hinge assembly	2
157	30201000032	middle glass support rubber	1
157	30201000032	middle glass support rubber	1
157	30201000031	middle glass support rubber	2
157	30101600442	Display	1
159	30202100026	cushion block	4
159	30202100026	cushion block	10
159	30202100026	cushion block	6
160	30304500414	door trim	1
161	30500201432	door glass	1
162	30500400278	inner glass	1
163	30200900036	fixation block for inner glass	1
163	30105000061	Oven wiring	1
164	30200900037	fixation block for inner glass	1
165	30303500180	top bracket	1
166	30303400310	door bracket	1
167	30303400311	door bracket	1
169	30304500417	door trim	1
170	30201000030	middle glass support rubber	2
170	30212400018	roller	2
171	30302800071	Oven stiffener	1
172	30302900360	Oven fixed plate	2
173	30302800070	Oven stiffener	1
173	30406200021	Catch pin	4

174	30400700365	handle	1
175	30500201446	door glass	1
176	30500400258	inner glass	1
177	30303500182	top bracket	1
178	30303400312	door bracket	1
179	30303400306	door bracket	1
180	30304500421	door trim	1
181	30200900037	fixation block for inner glass	1
182	30200900036	fixation block for inner glass	1
184	30100600035	TEMPERATURE MEASURING PROBE ASSEMBLY	1
184	30301900013	exhaust pipe baffle plate	1
185	30200300053	Seal ring	1
186	30301900014	exhaust pipe baffle plate	2
187	30102101477	connecting wire	1
188	30400100070	rack	3
189	30400100071	rack	4
190	30304200058	baking tray	1
191	30400800002	Tongs for rack	1
192	30400100074	rack	1
193	30401000013	grill insert for baking tray	1
193	30401000024	grill insert for baking tray	1
193	30401000029	grill insert for baking tray	1
193	30401000030	grill insert for baking tray	4
196	30401700008	telescopic runner	4
197	30401700009	telescopic runner	4
201	30302800074	Oven stiffener	1
202	30302900351	Oven fixed plate	2
203	30302800082	Oven stiffener	2
204	30402600411	WOK ADAPTOR	1
205	30302900364	Oven fixed plate	1
206	30313300075	Oven fixed plate	1
207	30313300076	Oven fixed plate	1
208	30319400041	separator plate	1
209	30319400042	separator plate trim	2
210	30319400043	separator plate trim	2
211	30205700024	OIL COLLECTOR	1
212	30401000028	grill insert for baking tray	1
213	30403800007	iron chain	2
214	30700500254	CROSS BOLT	2
215	40401100001	Expansion hook	2
216	30105000036	Oven wiring	1
217	30211000019	PANEL WASHER	5
218	30407200011	door lock fixing base	1
219	30200900042	fixation block for inner glass	2
220	30201900024	Burner base waterproof ring	1
221	30105000037	Oven wiring	1
222	30213800011	Kick panel	1
223	30700300009	retainer	40

1044300105

