

VST130-I-AU Spare Parts

Location	Item Code	Description
	03.09.001.188	REMOTE CONTROL VST
	04.01.001.227	MIRRORED GLASS (VST130)
	04.02.001.548	FRONT GLASS (VST130)
	04.02.001.552	SIDE GLASS VST
	06.04.003.351	FUEL BED TOP ASSEMBLY (VST130)
	06.04.003.352	BASE LOG SET (VST130)
	05.01.092.001	SPRING GLASS VST
	03.08.002.206	SD CARD VST
	05.03.049.061	GRILL SIDE RH VST
	05.03.049.062	GRILL SIDE LH VST
	05.03.049.051	GRILL FRONT (VST130-I)
	05.03.019.071	MIRRORED GLASS TOP FIXING BRACKET (VST130)
	03.08.003.035	SCREEN PANEL IR BOARD VST
	03.08.006.065	SCREEN PANEL DIMMER BOARD VST
	03.08.002.208	SCREEN PANEL LCD AU PANEL VST
	03.18.004.222	LED PANEL LED STRIP VST
	03.18.004.221	LED PANEL LED 1W VST
	03.08.005.018	LED PANEL SWITCH BOARD VST(NEW)
	03.08.016.001	LED PANEL 6 WAY CONNECTOR VST
	03.08.002.201	ELECTRONIC BASE RELAY BOARD VST(NEW)
	03.08.002.203	ELECTRONIC BASE SPEAKER VST
	06.02.001.133	ELECTRONIC BASE FERGAS BLOWER VST
	03.08.005.016	ELECTRONIC BASE POWER SUPPLY VST
	03.08.002.202	ELECTRONIC BASE BACKLIGHT BOARD VST
	03.08.002.204	ELECTRONIC BASE LED CONTROLLER VST
	03.08.002.205	ELECTRONIC BASE MEDIA BOARD VST
	03.08.002.207	ELECTRONIC BASE 7 DAY TIMER VST
	02.01.038.064	ELECTRONIC BASE NEON LENS VST
	03.08.005.019	ELECTRONIC BASE AC IN BOARD VST
	03.08.005.017	ELECTRONIC BASE AC BOARD WITH CHOKE VST(NEW)
	06.03.001.129	ELECTRONIC BASE HEAT ELEMENT (2X1000W) VST
	02.01.009.002	PCB STANDOFF VST
	03.08.002.209	NTC SENSOR VST
	02.01.014.002	SUCTION CUP
	03.08.017.001	ONE-TO-TWO SPLIT SCREEN BOARD(ONLY USE FOR VST130)
	03.21.013.009	POWER CORD - LEAD AU PLUG