





Number	Part number	Description	QTY	Unit Price /USD
1	30304500677	door trim	1	4.06
2	30303400338	door bracket	1	1.25
3	30500400322	inner glass	1	5.93
4	30500300098	Middle glass	1	4.49
5	30202100026	cushion block	12	0.18
6	30500201612	door glass	1	9.09
7	30400700547	handle	1	17.94
8	30201400005	handle seal	2	0.04
9	30303400337	door bracket	1	1.25
10	30303500212	top bracket	1	2.25
11	30303600001	fixation board for handle	2	0.1
12	30201000020	middle glass support rubber	3	0.37
13	30303700011	Middle glass positioning block	2	0.16
14	30201000018	middle glass support rubber	2	0.41
15	30301100179	guarding board for rear element	1	5.86
16	30101200283	Element	2	3.39
17	30302600040	fixation board for hinge	1	1.37
18	30302300207	Left or right side panels of the shell	1	4.71
19	2030400028	Door seal	1	3.84
20	30403900025	Guide rail	2	6.06
21	30403900024	Guide rail	2	6.06
22	30402500588	Knob-Gas	5	1.35
23	30402500590	Knob-Temperature	1	1.35
24	30105700028	encoder switch	1	2.26
25	30101600553	Display	1	16.18
26	30402500909	Knob-Function	1	1.35
27	30200200037	display board holder	1	2.04
28	30400700373	handle	1	19.93
29	30305900985	control panel	1	2.13
30	30105700010	encoder switch	1	2.26
31	30403100226	Valve	1	9.34
32	30101700054	MICRO SWITCH	1	4.56
33	30208200005	Microswitch pressure plate	5	0.06
34	30403100227	Valve-Φ0.35	2	9.34
35	30403100225	Valve-Φ0.65	1	9.34
36	30401900476	INTAKE-TUBE	1	4.01
37	30403100228	Valve-Φ0.27	1	9.34
38	30300100083	Holder	1	2.17
39	30302700285	connecting plate	1	0.92
40	30400200079	GUIDE BRACKET	1	2.02
41	30101100008	Square lamp component	1	1.99
42	30402300026	Intake connector	1	1.11
43	30200300012	Seal ring	2	0.08

44	30402300010	Regulator	1	4.5
45	2030300652	Cavity component	1	24.3
46	30312600040	cover board for exhausting flue	1	2.04
47	30301800043	bottom board for exhausting flue	1	4.36
48	30100800001	THERMOSTAT	1	0.29
49	30101500239	PCB	1	14.86
50	30207700007	PCB fixed bracket	1	0.91
51	30312600039	cover board for exhausting flue	1	2.37
52	30102300032	PULSE IGNITER	1	1.62
53	30302900239	Oven fixed plate	1	0.25
54	30100600027	TEMPERATURE MEASURING PROBE ASSEMBLY	1	2.73
55	30100400083	Cooling fan	1	9.92
56	30301300037	HEAT SHIELD	1	0.47
57	30101000023	ROUND LAMP COMPONENT	1	1.34
58	30100700013	over-heat protector	1	0.36
59	30401100026	exhausting flue	1	0.44
60	30408700001	FIXING CLIP	2	0.2
61	30101200282	Element	1	8.3
62	30301700008	Bottom support block for exhausting flue	2	0.14
63	30301700010	Bottom support block for exhausting flue	1	0.35
64	30100300060	circulation fan assembly	2	4.5
65	30302200249	rear panel	1	4.18
66	30302700287	connecting plate	2	0.73
67	30301500026	inner back bracket	1	2.41
68	30302800058	Oven stiffener	1	0.64
69	30205800015	cable ramp	1	0.14
70	30309600013	Cover plate	1	0.28
71	30313300007	Oven fixed board	1	1
72	30302900291	Oven fixed plate	1	2.31
73	30104800010	Terminal post	1	3.77
74	30302700286	connecting plate	1	0.92
75	30200600008	SLIDER	1	0.09
76	30401600042	spring	1	0.02
77	30302900430	Oven fixed plate	1	0.07
78	30101700040	MICRO SWITCH	1	0.49
79	30217500003	FIXING BASE	1	0.16
80	30302900273	Oven fixed plate	2	3.54
81	30201600011	Non-slip foot	4	0.39
82	30302700172	connecting plate	2	1.52
83	30302900404	Oven fixed plate	2	0.32
84	30202600008	ADJUST LEG	4	2.29
85	30204100033	LOCKING BLOCK PLASTIC	4	0.06
86	30302900378	Oven fixed plate	2	0.44
87	30213800031	Kick panel	1	1.9
88	30316200196	Oven baffle	1	2.2

89	30302300208	Left or right side panels of the shell	1	4.71
90	30400200080	GUIDE BRACKET	1	2.02
91	30313300056	Oven fixed board	2	0.16
92	30302600041	fixation board for hinge	1	1.37
93	30302900321	Oven fixed plate	2	0.14
94	30302900301	Oven fixed plate	1	0.12
95	30101200220	Element	1	6.65
96	30307800018	BAFFLE	1	3.02
97	30302900275	Oven fixed plate	2	0.59
98	30403900050	Guide rail	1	5.22
99	30307100240	Warming drawer bottom board	1	7.21
100	30307800021	BAFFLE	1	0.12
101	30307100161	Warming drawer Lining plate	1	2.91
102	30202100027	cushion block	2	0.04
103	30307100271	DRAWER PANEL	1	1.7
104	30403900049	Guide rail	1	5.22
105	30307800020	BAFFLE	1	0.12
106	30301200013	Bottom element fixing plate	1	3.59
107	30400600109	hinge assembly	2	11.45
108	30313300059	Oven fixed board	1	0.77
109	30313300058	Oven fixed board	1	0.77
110	2030900165	CAVITY PANEL COMPONENT	1	8.65
111	30401000024	grill insert for baking tray	1	15.7
112	30402600411	WOK ADAPTOR	1	2.24
113	30402600474	Trivet-Mid	1	11.57
114	30402600473	Trivet-L&R	2	15.08
115	30201900022	Burner base waterproof ring	1	0.07
116	30403000064	Burner cap-Rapid	1	2.09
117	30402900037	Buerner-Rapid	1	2.01
118	30403000013	Burner cap-inner	1	1.17
119	30403000031	Burner cap-Outer	1	3.62
120	30402900085	Buerner-WOK	1	7.68
121	30201900021	Burner base waterproof ring	2	0.05
122	30201900024	Burner base waterproof ring	1	0.19
123	30403000050	Burner cap-Semi rapid	2	1.28
124	30402900026	Buerner-Semi rapid	2	1.42
125	30403000038	Burner cap-Auxiliary	1	0.89
126	30402900018	Buerner-Auxiliary	1	1.18
127	30201900020	Burner base waterproof ring	1	0.03
128	2040500402	Hob Panel Assembly	1	15.91
129	30302800105	Oven stiffener	1	1.05
130	30302900470	Oven fixed plate	1	0.74
131	30302900471	Oven fixed plate	1	0.74
132	30302800060	Oven stiffener	2	0.24
133	30402400004	IGNITION PIN	2	0.29

134	30401800006	Thermocouple	2	0.86
135	30402100047	Nozzle	2	0.1
136	30402100105	Nozzle	2	0.1
137	30402800022	Burner base-Semi rapid	2	0.05
138	30402001514	aluminuim pipe	1	0.98
139	30402400012	IGNITION PIN	1	1.11
140	30401800012	Thermocouple	1	0.8
141	30402100129	Nozzle	1	0.1
142	30402100204	Nozzle	1	0.1
143	30402001516	aluminuim pipe	1	0.98
144	30402800009	Burner base-WOK	1	10.74
145	30402001513	aluminuim pipe	1	0.99
146	30402100056	Nozzle	1	0.1
147	30402800032	Burner base-Rapid	1	0.05
148	30402001539	aluminuim pipe	1	0.97
149	30401600001	SNAP HOOK	5	0.05
150	30402400005	IGNITION PIN	2	0.32
151	30402001517	aluminuim pipe	1	0.98
152	30402800016	Burner base-Auxiliary	1	0.05
153	30401800005	WOK thermocouple	2	0.81
154	30402100031	Nozzle	2	0.1
155	30402100094	Nozzle	1	0.1
156	30400100054	rack	2	6.7
157	30400100053	rack	1	5.32
158	30400800001	Tongs for rack	1	0.87
159	30400100157	rack	2	13.11
160	30401000025	grill insert for baking tray	2	2.32
161	30304200063	baking tray	2	7.5
162	30400100052	rack	1	4.78
	2040201546	Complete door	1	56.62
	30102101227	Connection wires	1	2.08
	30102101299	Connection wires	1	2.82
	30102101335	Connection wires	1	14.33
	30105000060	Oven wiring	1	0.66
	30105000061	Oven wiring	1	1.6
	30105000066	Oven wiring	1	0.43
	30105000067	Oven wiring	1	0.34