

Number	Part Number	Description	QTY	Unit Price /USD
0	1042400687			
1	30304500677	door trim	1	4.06
2	30303400338	door bracket	1	1.25
3	30500400322	inner glass	1	5.93
4	30500300098	Middle glass	1	4.49
5	30202100026	cushion block	12	0.18
6	30500201612	door glass	1	9.09
7	30400700547	handle	1	17.94
8	30201400005	handle seal	2	0.04
9	30303400337	door bracket	1	1.25
10	30303500212	top bracket	1	2.25
11	30303600001	fixation board for handle	2	0.1
12	30201000020	middle glass support rubber	3	0.37
13	30303700011	Middle glass positioning block	2	0.16
14	30201000018	middle glass support rubber	2	0.41
15	30301100179	guarding board for rear element	1	5.86
16	30101200283	Element	2	3.39
17	30302600040	fixation board for hinge	1	1.37
18	30302300207	Left or right side panels of the shell	1	4.71
19	2030400028	Door seal	1	3.84
20	30403900025	Guide rail	1	6.06
21	30403900024	Guide rail	1	6.06
22	30402500656	Knob-encoder switch	3	1.35
23	30402500590	Knob-Temperature	1	1.35
24	30105700028	encoder switch	1	2.26
25	30101600553	Display	1	16.18
26	30402500909	Knob-Function	1	1.35
27	30200200037	display board holder	1	2.04
28	30400700373	handle	1	19.93
29	30402500646	Knob-encoder switch	2	1.35
30	30305900985	control panel	1	2.13
31	30105700010	encoder switch	1	2.26
32	30302700285	connecting plate	1	0.92
33	30400200079	GUIDE BRACKET	2	2.02
34	30101100008	Square lamp component	1	1.99
35	2030300652	Cavity component	1	24.3
36	30312600040	cover board for exhausting flue	1	2.04
37	30301800043	bottom board for exhausting flue	1	4.36
38	30100800001	THERMOSTAT	1	0.29
39	30101500239	PCB	1	14.86
40	30207700007	PCB fixed bracket	1	0.91
41	30312600039	cover board for exhausting flue	1	2.37
42	30302900239	Oven fixed plate	1	0.25

43	30100600027	TEMPERATURE MEASURING PROBE ASSEMBLY	1	2.73
44	30100400083	Cooling fan	1	9.92
45	30301300037	HEAT SHIELD	1	0.47
46	30101000023	ROUND LAMP COMPONENT	1	1.34
47	30100700013	over-heat protector	1	0.36
48	30401100026	exhausting flue	1	0.44
49	30408700001	FIXING CLIP	2	0.2
50	30101200282	Element	1	8.3
51	30301700008	Bottom support block for exhausting flue	2	0.14
52	30301700010	Bottom support block for exhausting flue	1	0.35
53	30100300060	circulation fan assembly	2	4.5
54	30302200249	rear panel	1	4.18
55	30302700287	connecting plate	2	0.73
56	30301500026	inner back bracket	1	2.41
57	30302800058	Oven stiffener	1	0.64
58	30309600013	Cover plate	1	0.28
59	30313300007	Oven fixed board	1	1
60	30302900291	Oven fixed plate	1	2.31
61	30104800010	Terminal post	1	3.77
62	30302700286	connecting plate	1	0.92
63	30200600008	SLIDER	1	0.09
64	30401600042	spring	1	0.02
65	30302900430	Oven fixed plate	1	0.07
66	30101700040	MICRO SWITCH	1	0.49
67	30217500003	FIXING BASE	1	0.16
68	30302900273	Oven fixed plate	2	3.54
69	30201600011	Non-slip foot	4	0.39
70	30302700172	connecting plate	2	1.52
71	30302900404	Oven fixed plate	2	0.32
72	30202600008	ADJUST LEG	4	2.29
73	30204100033	LOCKING BLOCK PLASTIC	4	0.06
74	30302900378	Oven fixed plate	2	0.44
75	30213800031	Kick panel	1	1.9
76	30316200196	Oven baffle	1	2.2
77	30302300208	Left or right side panels of the shell	1	4.71
78	30400200080	GUIDE BRACKET	2	2.02
79	30313300056	Oven fixed board	2	0.16
80	30302600041	fixation board for hinge	1	1.37
81	30302900321	Oven fixed plate	2	0.14
82	30302900301	Oven fixed plate	1	0.12
83	30101200220	Element	1	6.65
84	30307800018	BAFFLE	1	3.02
85	30302900275	Oven fixed plate	2	0.59
86	30403900050	Guide rail	1	5.22
87	30307100240	Warming drawer bottom board	1	7.21

88	30307800021	BAFFLE	1	0.12
89	30307100161	Warming drawer Lining plate	1	2.91
90	30202100027	cushion block	2	0.04
91	30307100271	DRAWER PANEL	1	1.7
92	30403900049	Guide rail	1	5.22
93	30307800020	BAFFLE	1	0.12
94	30301200013	Bottom element fixing plate	1	3.59
95	30400600109	hinge assembly	2	11.45
96	30313300059	Oven fixed board	1	0.77
97	30313300058	Oven fixed board	1	0.77
98	2030900165	CAVITY PANEL COMPONENT	1	8.65
99	30502201330	Ceramic glass	1	44.04
100	30302800105	Oven stiffener	1	1.05
101	2040500406	Hob Panel Assembly	1	16.07
102	30302900470	Oven fixed plate	1	0.74
103	30302900471	Oven fixed plate	1	0.74
104	30302700218	connecting plate	2	1.34
105	30102900097	Electromagnetic module	1	501.11
106	30302700291	connecting plate	2	0.77
107	30302700292	connecting plate	2	1.59
108	30400100054	rack	2	6.7
109	30400100053	rack	1	5.32
110	30400800001	Tongs for rack	1	0.87
111	30400100157	rack	2	13.11
112	30401000025	grill insert for baking tray	2	2.32
113	30304200063	baking tray	2	7.5
114	30400100052	rack	1	4.78
	2040201546	Complete door	1	56.42
	30102101299	Connection wires	1	2.82
	30102101545	Connection wires	1	14.12
	30105000060	Oven wiring	1	0.66
	30105000061	Oven wiring	1	1.6
	30105000066	Oven wiring	1	0.43
	30105000067	Oven wiring	1	0.34