


TBFS9005CERS- Parts List

A



Location	Part Number	Description	QTY
1	30500400186	INNER GLASS	1
2	30500300098	MIDDLE GLASS	1
3	30500201752	DOOR PANEL GLASS	1
4	30400700409	HANDLE	1
5	30201400005	HANDLE WASHER	2
6	30303400219	DOOR FRAME ON THE LEFT	1
7	30303500146	DOOR STRIP	1
8	30303600001	HANDLE FIXED BOARD	2
9	30201000020	MIDDLE GLASS SUPPORT RUBBER	3
10	30303700011	MIDDLE DOOR GLASS LIMITED BLOCK	2
11	30201000018	MIDDLE GLASS SUPPORT RUBBER	2
12	30301100144	BACK ELEMENT BAFFLE	1
13	30101200269	ELEMENT	2
14	30302600040	HINGE FIXED BOARD	1
15	30302300127	LEFT AND RIGHT SIDE PANELS OF THE SHELL	1
16	2030400028	DOOR SEAL	1
17	30402500659	KNOB BASE	2
18	30100900003	TEMPERATURE CONTROL SWITCH	1
19	30102500060	INDICATOR LIGHT	1
20	30100200162	TIMER	1
21	30401600033	SPRING	2
22	30402500673	KONB	2
23	30304400449	CONTROL PANEL DECORATIVE PLATE	1
24	30100500071	FUNCTION SWITCH	1
25	30500101917	CONTROL PANEL GLASS	1
26	30217400001	CONTROL PANEL FIXED BUCKLE	4
27	30301400130	CONTROL PANEL FIXING PLATE	1
28	30302700254	CONNECTING PLATE	2
29	30400200079	GUIDE BRACKET	1
30	30101100008	SQUARE LAMP	1
31	2030300355	CAVITY ASSEMBLY	1
32	30312600040	COVER BOARD FOR EXHAUSTING FLUE	1
33	30301800043	BOTTOM BOARD FOR EXHAUSTING FLUE	1
34	30100800001	THERMOSTAT	1
35	30312600039	COVER BOARD FOR EXHAUSTING FLUE	1
36	30100400083	COOLING FAN	1
37	30301300037	HEAT SHIELD	1
38	30101000023	ROUND LAMP COMPONENTS	1
39	30100700016	OVERHEAT PROTECTOR	1
40	30401100026	EXHAUSTING PIPE	1
41	30408700001	FIXING CLIP	2
42	30101200208	ELEMENT	1
43	30301700008	BOTTOM SUPPORT BLOCK FOR EXHAUSTING FLUE	2
44	30301700010	BOTTOM SUPPORT BLOCK FOR EXHAUSTING FLUE	1
45	30304100001	CLIPS FOR THERMOSTATS	4
46	30302900409	OVEN FIXED BOARD	1
47	30302200155	BACK COVER FOR SHELL	1
48	30100300060	CIRCULATION FAN	2
49	30301500026	CAVITY BACK BRACKET	1
50	30302800058	OVEN STIFFENER	1
51	30309600013	COVER PANEL	1
52	30302900291	OVEN FIXED BOARD	1

Location	Part Number	Description	QTY
53	30313300007	OVEN FIXED BLOCK	1
54	30104800010	TERMINAL POST	1
55	30302800086	OVEN STIFFENER	1
56	30302800087	OVEN STIFFENER	1
57	30302900430	OVEN FIXED BOARD	1
58	30200600008	SLIDER	1
59	30401600042	SPRING	1
60	30101700040	MICRO SWITCH	1
61	30217500003	FIXING BASE	1
62	30201600011	ANTI-SLIP FEET	4
63	30302900273	OVEN FIXED BOARD	2
64	30302700172	CONNECTING PLATE	2
65	30302900404	OVEN FIXED BOARD	2
66	30202600001	ADJUST FOOT	4
67	30204100033	LOCKING BLOCK PLASTIC	2
68	30302900378	OVEN FIXED BOARD	2
69	30213800012	KICK PANEL	1
70	30302300128	LEFT AND RIGHT SIDE PANELS OF THE SHELL	1
71	30400200080	GUIDE BRACKET	1
72	30313300056	OVEN FIXED BLOCK	1
73	30302600041	HINGE FIXED BOARD	1
74	30307800018	BAFFLE	1
75	30307100164	DRAWER PANEL	1
76	30400600065	HINGE	2
77	30313300059	OVEN FIXED BLOCK	1
78	30313300058	OVEN FIXED BLOCK	1
79	2030900118	CAVITY PANEL COMPONENT	1
80	30303400220	DOOR FRAME ON THE RIGHT	1
81	2040600035	SPLASHBACK COVER ASSEMBLY	1
82	30102800045	HEATING ELEMENT	2
83	2040500343	HOB PANEL ASSEMBLY	1
84	30502201524	HOB PANEL GALSS	1
85	30102800048	HEATING ELEMENT	1
86	30302900290	OVEN FIXED BOARD	2
87	30302800060	OVEN STIFFENER	2
88	30102800046	HEATING ELEMENT	2
89	30300500051	BASE PLATE	1
90	30103000043	TOUCH SWITCH	1
91	30202200002	THERMAL INSULATION STRIP	0.04
92	30300900028	HEAT SHIELD	1
93	30200200010	DISPLAY FIXED SUPPORT	6
94	30200100010	PCBFIXED FOOT	6
95	30400100044	RACK	2
96	30401000025	GRILL INSERT	2
97	30304200053	BAKING TRAY	2
98	30400100052	RACK	1
	2030202026	CONTROL PANEL ASSEMBLY	1
	2040201421	COMPLETED DOOR	1
	2042200049	EXHAUSTING PIPE COMPONENT	1
	2070600004	DOOR SWITCH COMPONENT	1
	30102101299	CONNECTION LINE	1
	30102101532	CONNECTION LINE	1
	30102101700	CONNECTION LINE	1
	30105000060	OVEN WIRING	1