










Part Code at the Exploded View	Part number	Part Name	Qty
1001	673000900223	External pipe	1
1002	673001500005	O Ring I 31.5X3.55	2
1003	673001800364	Guide casing	1
1004	673001600021	External pipe nut	1
1005	673001900016	Water dispenser	1
1006	673000300067	Upper sprayer	1
1007	673000900195	Upper sprayer pipe	1
1012	673002300003	Float	1
1016	673002500047	Micro filter	1
1017	673001600022	Sump nut	1
1018	673001500098	Sump gasket	1
1019	673000700087	Sump assembly	1
1022	673000900073	PVC hose	1
1027	674000600106	Drain pump	1
1036	672000700029	Clamp 14.5×1.8	1
1037	673006200027	Drain hose hook	1
1038	673001500002	Drain hose holder	1
1039	673000900269	Drain hose	1
1042	674000000196	power cord	1
1043	674000200001	Inlet valve	1
1045	673000900225	Inlet hose assembly	1
1051	673001600025	Air breather nut	1
1053	673002600001	Air inlet	1
1064	670400051614	Lower sprayer	1
1065	673001200027	Lower sprayer connection assembly	1
1070	674005600080	Washing pump	1
1083	673000900045	Bend connect hose	1
1085	673001400025	Heating element support	1
1086	674001100050	Heating elements	1
1088	673001600024	Water inlet nut	1
1089	673001500019	Water inlet gasket	1
1091	673002700608	Water inlet	1
1093	674000900053	Sensing device	1
1096	673000900368	Inlet hose 1	2
1097	673000900369	Inlet hose 2	1
1098	674006000006	Flowmeter	1
1113	672000605000	plane filter	1
1114	673001300179	Scran collection	1
1115	674000300079	Pressure switch	1
1116	673001400083	power cord clasper	1
1117	674000302006	pressure switch assembly for	1

2001	673002000022	Door edge guard piece	2
2002	672002200330	Inner door	1
2004	672001700002	Dispenser bracket	2
2005	674000800032	Dispenser	1
2006	674000102027	Wiring harness	1
2007	675000201002	Inner door foam	1
2008	672000500006	Ring $\Phi 6$	4
2009	672001300029	Left hinge	1
2010	672001200012	Dowel	2
2011	672001300030	Right hinge	1
2012	672001300024	Door gemel assembly	1
2013	672000100000	Door spring	2
2014	672001100001	Door spring bolt	2
2017	672001800067	Outer door	1
2018	673000491657	Control panel	1
2023	673001800513	Handle assembly	1
2024	674010030000	Micro switch	1
2027	674010010002	Power switch	1
2033	673000900003	Indicator cover	5
2034	674001000885	Control assembly	1
2036	673002400190	Control board box	1
2950	673000802015	Power button	1
2951	673000802003	program button	1
2952	673000802009	start/pause button	1
3001	672001600155	Left side panel	1
3002	673000100014	Back cover board	1
3003	672002190005	Left frame	1
3004	673000200338	Ceiling board	1
3005	672001500008	Upper rear crosspiece	1
3006	673001300634	door clamp	1
3007	672001400039	door lock	1
3008	673001300003	Top clamp block	2
3009	672001500150	Upper front crosspiece	1
3010	673001700079	Tank gasket	1
3011	672002190006	Upright right assembly	1
3012	672001600156	Right panel	1
3013	673001300072	Upper basket cup holder	4
3017	672000800335	Lower basket	1
3018	672000800339	Upper basket	1
3020	673001100024	Right washboard	1
3021	673001300181	Rail block	2
3022	672001701000	Rail	2
3023	673001401005	Rail support assembly	4

3024	673001100019	Washboard	1
3025	673001100156	Adjustable foot(front)	2
3026	672000200058	Feet support assembly	2
3027	672001503004	Lower front crosspiece	1
3029	672002000044	Base board	1
3030	673001100023	Left side baseboard	1
3033	672001500202	Lower rear crosspiece	1
3034	672001500007	Middle rear crosspiece	1
3035	673002200079	Measurable spoon	1
1010+1011+1013	673001490016	Float holder assembly	1
1071+1072	672000200054	Washing motor support	1
1074-a	673000900228	connect hose a	1
1074-b	673000900229	connect hose b	1
3014+3015+3016	673002200055	Cutlery basket	1
3025-a	673001100180	Adjustable foot(back)	2
C5004	673006200004	rinse aid cup	1
OTK 175	672000700004	OTK 175	2
OTK 310	672000700001	OTK 310	7
OTK 396	672000700007	OTK 396	3