

TECHNIKA

EUROPEAN COOKING APPLIANCES


23-Oct-03

GAS COOKTOP

PA5GTC/2 S/S

SPARE PARTS &
EXPLODED VIEW

PA5GTC/2 S/S



Technika Pty. Ltd.

A.B.N. 38 069 686 326

8 - 10 VESPER DRIVE, NARRE WARREN

P.O. BOX 2254, FOUNTAIN GATE RETAIL POST OFFICE 3805

Ph: 9705 4144 Fax: 9704 1796

Toll Free 1800 333 244

PA5GTC-2 S/S

TECHNIKA PART #	MENEGETTI PART #	DESCRIPTION	REF
F00015	11701595	TRIVET LEFT HAND THIN	1
F00115	11701605	TRIVET RIGHT HAND THIN	11
F00205	11701615	TRIVET CENTRE PA5GTC - 2 THIN	20
F00016	11701595	TRIVET LEFT HAND THICK	1
F00116	11701605	TRIVET RIGHT HAND THICK	11
F00206	11701615	TRIVET CENTRE PA5GTC - 2 THICK	20
F00210	11380650	RUBBER GROMET TRIVET	21
F00310	11430452	SMALL BURNER SKIRT	31
F00410	11430462	MEDIUM BURNER SKIRT	41
F00500	11430472	LARGE BURNER SKIRT	50
F00510	11430492	WOK BURNER SKIRT	51
F00610	11440751	SMALL BURNER CAP	61
F00710	11440761	MEDIUM BURNER CAP	71
F00800	11440771	LARGE BURNER CAP	80
F00810	11440791	OUTER BURNER CAP - WOK	81
F00910	11440781	INNER BURNER CAP - WOK	91
F01010	170110312	TECHNIKA BADGE	101
F01110	11380821	GROMETS	111
F01210	11741804	KNOB WHITE	120
F01211	11741801	KNOB S/S	121
F01420	4110419000701	HOB PA5GTC - W - 2	142
F01421	7110419000772	HOB PA5GTC - S/S - 2	142
F01610	11410310	ELBOW	161
F01710	11410140	FIBRE WASHER	171
F01810	11410450	CLIP FOR IGNITION SWITCH	181
F01900	11541150	IGNITION SWITCH 5	190
F02100	11422850	GAS RAIL	210
F02000	11191940	BRACKET FOR GAS RAIL	200
F02210	11423090	GAS TAP - MEDIUM	221
F02300	11730960	GAS TAP - LARGE	230
F02310	11730970	GAS TAP - WOK	231
F02410	11730950	GAS TAP - SMALL	241
F02510	11410230	RUBBER GROMET GAS TAPS	251
F02600	11423520	GAS PIPE - SMALL BURNER	260
F02700	11423470	GAS PIPE - MEDIUM BURNER	270
F02820	1142348	GAS PIPE - LARGE BURNER	282
F02830	114231550	GAS PIPE - WOK BURNER	283
FF02910	11550381	IGNITION CANDLE	291
F03010	11550392	IGNITION CANDLE - WOK	301
F03110	11230180	CLIP FOR IGNITION CANDLE	311
F03210	11430423	BURNER CUP - SMALL	321
F03310	11430443	BURNER CUP - MEDIUM	331
F03400	11430443	BURNER CUP - LARGE	340
F03410	11430482	BURNER CUP - WOK	341
F04610	11550240	SPARK PAK S	460
F04315	41111230	COOKTOP BASE	431
F04710	11541070	TERMINAL BLOCK	471
F04410	11190410	FIXING CLIPS	441
F04510	16713111	SPEED NUT	451

945034
945030