
















No	Part No.	Description
2	03210797	FOOTSTALL
3	03170241	ADJ. FOOT
3	03170411	ADJ. FOOT
4	10020291	UNDER OVEN DOOR
5	03120273	UNDER OVEN DOOR GLASS WOOL
6	10020172	LEFT/RIGHT SIDE S/S MOD. 66-86
7	03120036	INSULATING MATTRESS
8	03040076	OVEN DOOR HINGE HOLDER
9	10160494	OVEN SIDE FIXING BAR FOR MXG86MF
14	03111212	FRONT PANEL
15	10160059	SQUARE FIXING FRONT PANEL
16	03170147	3 SIDES OVEN DOOR GASKET
19	10580296	WORKING TOP
21	03190093	2 FLAMES CAST IRON GRID 80X60
22	03190094	5TH BURNER CAST IRON GRID 80X60
25	03100230	SMALL FLAME DISTRIBUTOR
25	03100231	MEDIUM FLAME DISTRIBUTOR
25	03100232	LARGE FLAME DISTRIBUTOR
26	03190117	SMALL FLAME DISTRIBUTOR COVER
26	03190118	MEDIUM FLAME DISTRIBUTOR COVER
26	03190119	LARGE FLAME DISTRIBUTOR COVER
28	03040014	WORKING TOP RIGHT HINGE
28	03040015	WORKING TOP LEFT HINGE
32	03040030	GLASS LID RIGHT HINGE
32	03040031	GLASS LID LEFT HINGE
33	21500525	COVER LID
34	03170084	COVER LID RUBBER FOOT
40	03040078	LEFT/RIGHT OVEN DOOR HINGE
47	21502008	EXTERNAL OVEN DOOR GLASS
48	03070081	GIANT OVEN DOOR HANDLE
49	03020107	SCREW FIXING OVEN DOOR HANDLE
49	03170220	UNDER HANDLE BUSH WASHER
49	03170306	UNDER HANDLE BUSH
51	03090674	GAS COCK 0,35
51	03090675	GAS COCK 0,48
51	03090676	GAS COCK 0,55
51	03090677	GAS COCK 0,65
52	03100270	LARGE BURNER CUP
52	03100271	SMALL BURNER CUP
52	03100272	MEDIUM BURNER CUP
52	03100273	TRIPLE RING CUP
54	03090577	THERMOCOUPLE 750 mm.
54	03090578	THERMOCOUPLE 320mm
54	03090579	THERMOCOUPLE 500mm
55	21501763	TRIPLE RING GAS PIPE
55	21501765	FRONT LEFT GAS PIPE
55	21501766	BACK LEFT GAS PIPE
55	21501767	FRONT RIGHT GAS PIPE
55	21501768	BACK RIGHT GAS PIPE
58	03090072	RAMP CONNECTION WASHER
58	03090350	RAMP CONNECTION (NIPLES)
63	03010535	FAN MOTOR
65	03010329	LAMP HOLDER WITH LAMP

No	Part No.	Description
68	03010124	WIRING
69	03010615	GENERATOR
76	03010211	LED
79	03010239	SWITCH
80	03010636	NIKEL PLATE
81	03010727	FAN BUTTON
81	03010875	GRILL BUTTON
81	03010893	LIGHT/TURNSPIT BUTTON
82	03010780	IGNITION CANDLE 900MM
84	03090580	NUT FIXING HOB THERMOCOUPLE
86	10500209	LOWER BLACK TRAY
89	03170266	FAN FILTER
90	03010869	TURNSPIT MECHANISM AND SUPPORT KIT
91	03010426	TURNSPIT ROD
92	03010384	TURNSPIT HANDLE
93	10500266	OVEN TRAY
99	03120183	INSULATING MATTRESS
104	03020086	SCREW FIXING WORKING TOP
104	03020414	CLIP FIXING WORKING TOP TO SIDE
121	03090552	THERMOSTAT 0,55
122	21500070	COMPLETE OVEN BURNER
123	03090230	THERMOSTAT THERMOCOUPLE 1200mm
123	03090231	THERMOCOUPLE NUT
124	03010419	OVEN BURNER CANDLE
125	03010589	TURNSPIT MOTOR
126	03090155	INJECTOR HOLDER
126	03090226	INJECTOR HOLDER NUT/RING
127	03090120	INJECTOR X INJ.HOLDER 2,0
130	21500897	OVEN GAS PIPE
136	03010355	GRILL + BOTTOM HEATING ELEMENT 1750W
142	03170169	MINUTE-COUNTER
143	03010584	CATENARY
150	03010632	TEMPERATURE THERMOSTAT
158	03060177	ENAMELLED WOK GRID D=170
158	03190152	CAST IRON WOK GRID D=170
161	03060155	UPSIDE DOWN OVEN GRID
162	03060157	UPSIDE OVEN GRID
163	03060156	SIMPLE OVEN GRID
164	03060079	LEFT/RIGHT OVEN SHELVES HOLDER
165	03020094	CAGE SCREW
166	03020225	CAGE SCREW RING M25
167	03140334	NIKEL SHINY EL.KNOB, BLACK DOT IND.
168	03140332	NIKEL SHINY GAS KNOB, BLACK DOT IND.
171	10500232	FAN COVER
172	03020098	SCREW FIXING FAN COVER
174	03100150	TRIPLE RING CUP
175	03100219	TRIPLE RING BURNER FLAME DISTRIB. 3,9 kW
176	03190067	EXTERNAL TRIPLE RING BURNER RAF COVER
177	03190068	INTERNAL TRIPLE RING BURNER RAF COVER
178	03170239	TRIPLE RING BURNER CUP GASKET
179	03090468	TRIPLE RING BURN.THERMOCOUPLE
180	03090469	NUT FIX.TRIPLE RING BURN.THERMOCOUPLE
181	03010609	TRIPLE RING ELECTRIC IGNITION CANDLE

No	Part No.	Description
181	03010623	TRIPLE RING ELECTRIC IGNITION CANDLE
182	03020566	SPRING FIX.TRIPLE RING IGNITION CANDLE
192	03020406	O-RING GASKET
195	03100188	RIGHT TERMINAL WALL
195	03100189	LEFT TERMINAL WALL
211	03020226	CLIP FIXING FAN COVER
214	03170234	GLASS PROTECTION RUBBER
221	03080221	LARGE OVEN DOOR RIGHT STEEL FRAME
222	03080222	LARGE OVEN DOOR LEFT STEEL FRAME
223	03080228	OVEN DOOR UPPER FRAME
224	03060442	INNER GLASS
225	03080234	OVEN DOOR GLASSES SPACER
329	03010725	KLICSON
390	03020585	OVEN TRAY BUSH
391	03020586	RING NUT FIXING OVEN TRAY BUSH
400	20170799	COMPLETE FRONT PANEL
401	21502000	COMPLETE OVEN DOOR
402	21501764	LPG INJECTORS KIT
410	03010928	COOLING FAN
411	03210832	STEEL FRAME
412	03130296	CARDBOARD PACKAGING 80X60
413	03090499	GAS REGULATOR