










Location	Part Number	Description	Qty
1001	673000900249	External pipe	1
1002	673001500005	O Ring I 31.5X3.55	2
1003	673001800364	Guide casing	1
1004	673001600021	External pipe nut	1
1005	673001900016	Water dispenser	1
1006	673000300067	Upper sprayer	1
1007	673000900195	Upper sprayer pipe	1
1012	673002300003	Float	1
1016	673002500047	Micro filter	1
1017	673001600022	Sump nut	1
1018	673001500016	Sump gasket	1
1019	673000700083	Sump	1
1022	673000900073	PVC hose	1
1027	674000600106	Drain pump	1
1036	672000700029	Clamp 14.9×1.8	1
1037	673006200027	Drain hose hook	1
1038	673001500002	Drain hose holder	1
1039	673000900185	Drain hose	1
1042	674000000196	Power cord	1
1043	674000200012	Inlet valve	1
1045	673000900226	Inlet hose assembly	1
1051	673001600025	Air breather nut	1
1053	673002600001	Air inlet	1
1064	673000300069	Lower sprayer	1
1070	674005600065	Washing pump	1
1083	673000900045	Bend connect hose	1
1085	673001400025	Heating element support	1
1086	674001100050	Heating elements	1
1088	673001600024	Water inlet nut	1
1089	673001500019	Water inlet gasket	1
1091	673002600035	Water inlet	1
1092	673006500011	Water inlet cover	1
1093	674000900037	Sensing device	1
1096	673000900307	Inlet hose 1	1
1097	673000900308	Inlet hose 2	1
1098	674006000003	Flowmeter	1
1113	673002500049	plane filter	1
1114	673001300137	Scran collection	1
1115	674000300079	Pressure switch 140/120	1
1116	673001400083	power cord clasper	1
1117	674000302006	pressure switch assembly for hea	1
2001	673002000084	Door edge guard piece	2
2002	672002200138	Inner door	1
2004	672001700002	Dispenser bracket	2
2005	674000800053	Dispenser	1
2006	674000100497	Wiring harness	1
2007	675000200104	Inner door foam	1

Location	Part Number	Description	Qty
2008	672000500006	Ring Φ6	4
2009	672001300029	Left hinge	1
2010	672001200012	Joint pin	2
2011	672001300030	Right hinge	1
2012	672001300024	Door gemel assembly	1
2013	672000100000	Door spring	2
2014	672001100001	Door spring bolt	2
2017	672001804020	Outer door	1
2018	673000495594	Front panel	1
2023	673001800437	Handle assembly	1
2024	674000300080	Door switch	1
2027	674000300089	Power switch	1
2029	673001400085	Swith support	1
2033	673002800087	Indicator cover	6
2034	674001000489	Control board	1
2035	673002901262	Control panel film	1
2036	673002400190	Control board box	1
2039	673002800112	Window	1
2080	672000100022	button spring	7
2950	673000801275	Power button	1
2951	673000801277	Program key	7
3001	672001600158	Left side panel	1
3002	673000102001	Back cover board	1
3003	672002100067	Left frame	1
3004	673000200392	Ceiling board	1
3005	672001500008	Upper rear crosspiece	1
3008	673001300003	Top clamp block	2
3009	672001500150	Upper front crosspiece	1
3010	673001700079	Tank gasket	1
3011	672002100066	Upright right assembly	1
3012	672001600157	Right panel	1
3013	673001300102	Upper basket cup holder	4
3017	672000800417	Lower basket	1
3018	672000800339	Upper basket	1
3021	673001300044	Rail block	2
3022	672001700005	Rail	1
3023	673001401005	Rail support assembly	4
3024	672001501026	Washboard	1
3025	673001100151	Adjustable foot	4
3026	672000200004	Feet support assembly	2
3027	672001500303	Lower front crosspiece	1
3029	672002000067	Base board	1
3032	673001700010	Tank band bracing block	2
3033	672001500202	Lower rear crosspiece	1
3034	672001500007	Middle rear crosspiece	1
3035	673002200079	Measurable spoon	1
3079	673002200091	3 in 1 tablet container	1

USE 672000800155

Location	Part Number	Description	Qty
1010+1011+1013	673001490016	Float holder assembly	1
1071+1072	672000200054	Washing motor support	1
1074-a	673000900140	connect hose a	1
1074-b	673000900182	connect hose b	1
3006+3007	673001300054	door lock and clamp	1
3014+3015+3016	673002200055	Cutlery basket	1
C5004	673006200004	rinse aid cup	1
OTK 175	672000700004	OTK 175	2
OTK 310	672000700001	OTK 310	7
OTK 396	672000700007	OTK 396	2