

AO980SS - 7721687700 BOM List

No.	Model no.	Description	
	118924144	BURNER PLATE..	0
10	157240509	TAP KNOB -BUILT-IN HOB	14
119	161900001	SD-2 SUPPLY CORD	8
19	266100017	TERMINAL BLOCK (3 SOCKETS)	4
200	115240031	TAP FIXING SHEET	5
202	155946901	SQUEEZING PUTTY Ø8	0
230	110241009	PAN SUPPORT-LEFT	15
230	110241011	PAN SUPPORT- RIGHT	15
244	155240011	TAP SQUEEZING SEAL	1
245	371900003	M 4 X 10 SCREW	1
3	110241007	PROTECTION COVER GROUP	15
334	219100029	BURNER CAP DECOR 1 KW	4
335	219100030	BURNER CAP DECOR 2KW(REF NO 335 FOR UK)	4
337	219100031	BURNER CAP DECOR 2_5-2.9 KW	4
338	223110002	BURNER CAP (REAR RIGHT)	7
339	223100080	BURNER CAP (FRONT LEFT)	8
341	423110001	BURNER CAP	9
342	223110058	BURNER HEAD_1 KW.	5
343	223110034	BURNER HEAD*2 KW	0
344	223110069	BURNER HEAD * 2.5 KW.	7
346	123241012	BURNER GROUP * 1KW	8
347	123241022	BURNER GROUP * 2KW	8
349	123241023	BURNER GROUP2,9 KW..	9
350	231100004	ARCELIK INJ G30_28-30MBAR 1KW_M52	3
351	231100003	ARCELIK INJ_M73	3
352	431900024	INJECTOR	2
378	123261018	SOURDILLON PROGRASIVE TAP_0.32	12
379	123261017	SOURDILLON PROGRASIVE TAP_0.34	12
381	123261019	SOURDILLON PROGRASIVE TAP_0.41	13
384	121241003	FEEDING TUBE- REAR RIGHT.	5
385	121241004	FEEDING TUBE- FRONT RIGHT.	5
386	121241001	FEEDING TUBE-REAR LEFT.	5
387	121241002	FEEDING TUBE-FRONT LEFT.	5
4	110243001	ASSEMBLY ELEMENTS GROUP	7
402	150240501	IGNITION BUTTON	3
403	110240011	FLEXIBLE PIPE	22
406	255100016	TAP SEAL	1
566	255100015	SUPPORTING TAMPON FOR PAN SUPPORT	1
58	119100057	PAN ADAPTOR.	5
62	268100043	SPARK PLUG (CABLE LENGTH_ 300MM)	8
62	268100044	SPARK PLUG (CABLE LENGTH_ 450 MM)	8
62	268100045	SPARK PLUG (CABLE LENGTH_ 500 MM)	8
62	268100047	SPARK PLUG (CABLE LENGTH_ 580 MM)	8
654	155261012	SEAL FOR SPARK PLUG	2
67	110240080	MAIN GAS PIPE GROUP.	12
70	168241003	IGNITOR COMPLETE 4PLUGS FOR HOBs..	19
8	115240024	TERMINAL BLOCK COVER	4



