


Spare part list for BCG60S

No.	Model No.	Description	QTY(Per Set)
1	11000137	bottom shell (galvanized steel plate)	1
2	14000006	power cable holder	1
3	12000024	power cable	1
4	12000008	blue cable	1
5	12000013	brown cable I	1
6	12000014	brown cable II	1
7	14000012	terminal connector spacer	1
8	12000021	terminal connector	1
9	12000002	ignitor	1
10	13000007	fixing square	4
11	13000055	gas valve support	4
12	11000292	intake-tube	1
13	11000134	gas valve without FFD	4
14	14000015	knob waterproof gasket	4
15	14000023	plastic knob (ARC, not Baumatic)	4
16	11000261	RAPID Al. tube	1
17	11000259	S-R Al. tube (long)	1
18	11000258	AUX Al. tube	1
19	11000260	S-R Al. tube (short)	1
20	11000351	SABAF 500 sparking ignition	2
21	14000005	Joint gasket	1
22	13010041	HHG610SS Stainless steel panel	1
23	11000350	SABAF 400 sparking ignition	2
26	13020053	HHG610SS pan stand (right & left)	2
27	11000150	AUX burner cup	1
28	11000026	AUX gas injector, NG	1
29	11000141	AUX flame spreader	1
30	11000156	AUX burner cap	1
31	11000151	Semi-rapid burner cup	2
32	11000027	Semi-rapid gas injector, NG	2
33	11000144	Semi-rapid flame spreader	2
34	11000157	Semi-rapid burner cap	2
35	11000152	RAPID burner cup	1
36	11000028	Rapid injector, NG	1
37	11000147	RAPID flame spreader	1
38	11000158	RAPID burner cap	1
39	14000022	Pan stand rubber feet	8
40	11000022	AUX gas injector, LPG	1
41	11000023	S-R gas injector, LPG	2
42	11000024	RAPID gas injector, LPG	1



	1	2	3	4	5	6	7	8		
A	This technical diagram illustrates the exploded view of a gas cooktop assembly. The components are numbered as follows: 1: Main cooktop body 2: Front panel 3: Control knobs 4: Knob cap 5: Gas supply line 6: Gas valve 7: Gas control valve 8: Gas control valve bracket 9: Gas control valve cover 10: Gas control valve cap 11: Gas control valve assembly 12: Gas control valve bracket 13: Gas control valve cap 14: Gas control valve cap 15: Gas control valve cap 16: Gas control valve cap 17: Gas control valve cap 18: Gas control valve cap 19: Gas control valve cap 20: Gas control valve cap 21: Gas control valve cap 22: Gas control valve cap 23: Gas control valve cap 24: Gas control valve cap 25: Gas control valve cap 26: Gas control valve cap 27: Gas control valve cap 28: Gas control valve cap 29: Gas control valve cap 30: Gas control valve cap 31: Gas control valve cap 32: Gas control valve cap 33: Gas control valve cap 34: Gas control valve cap 35: Gas control valve cap 36: Gas control valve cap 37: Gas control valve cap 38: Gas control valve cap 39: Gas control valve cap 40: Gas control valve cap 41: Gas control valve cap 42: Gas control valve cap									A
B										B
C										C
D										D
E										E
F	F									
	1	2	3	4	5	6	7	8		