




460



6




66




65



467




468




468




467



94




118



119

202

4



363



10



244




272



476

3



477

No	Part No.	Description	Qty
10	157240692	TAP KNOB..	4
118	160260701	CABLE GR	1
19	166900047	TERMINAL BOX 1_5	1
202	255430011	SQUEEZING SEAL.	1
244	155261020	HOB UNITE SEAL	4
272	265900005	HOTPLATE INDICATOR	2
3	115260052	SILM TC PROTECTION SHEET	1
363	142600002	KNOB PRESSURE SPRING	4
4	110243001	ASSEMBLY ELEMENTS GROUP	1
460	250920069	CABLE TIE	2
467	162926001	RADIANT HOTPLATE (Q140_1200W) 1650234810	2
468	162926002	RADIANT HOTPLATE (Q180-1700W)-2000234810	2
476	265100043	SIGNAL LAMP	1
477	163925002	ELECTRICAL COMMUTATOR	1
6	190261530	GLASS BURNER PLATE GROUP	1
65	300240158	HOTPLATE FIXING SHEET	8
66	117260008	Inox_Ceran_Burner_Supporting_Clamp	12
94	115260016	COMMUTATOR FIXING SHEET (CERAN COOKER)	1