







CF9GS 90CM S/S GAS COOKTOP





	CF9GS	GH915BFCI	24.11.11
Drawing #	Description	Part #	Qty
1	Base Cover	GHS915BFC101	1
2	?	GHS915BFC102	
3	?	GHS915BFC103	
4	?	GHS915BFC104	
5	Bolt - retains igniter block	GHS915BFC105	2
6	Insulation pad	GHS915BFC106	1
7	Igniter Block	GHS915BFC107	1
8	Nut	GHS915BFC108	2
9	?	GHS915BFC109	
10	Screw - retains gas tap	GHS915BFC110	1
11	Screw - retains gas tap	GHS915BFC111	1
12	?	GHS915BFC112	
13	TAP - front right & micro switch	GHS915BFC113	1
14	Pipe - front right	GHS915BFC114	1
15	Burner base - front right	GHS915BFC115	1
16	Jet NAT	GHS915BFC116	1
16	Jet LPG	?	1
17	Igniter- front right sparker	GHS915BFC117	1
18	Thermocouple - front right	GHS915BFC118	1
19	Nut - thermocouple	GHS915BFC119	1
20	Burner base - rear right	GHS915BFC120	1
21	Jet NAT	GHS915BFC121	1
21	Jet LPG	?	1
22	Thermocouple - rear right & left & front right	GHS915BFC122	2
23	Clip - Igniters retainer	GHS915BFC123	1
24	Igniter - rear right sparker	GHS915BFC124	1
25	Pipe - rear right	GHS915BFC125	1
26	Gas Tap - Rear right & micro switch	GHS915BFC126	1
27	Gas Tap - Left Front & Rear & micro switch	GHS915BFC127	1
28	Pipe - rear left	GHS915BFC128	1
29	Igniter - rear & front left - sparker	GHS915BFC129	2
30	Jet - NAT	GHS915BFC130	1
30	Jet - LPG	?	1
31	Burner base rear & front left	GHS915BFC131	2
32	Gas Tap - Rear left & micro switch	GHS915BFC127	1



Note : Hob & Knob Part #'s difference

	CF9GS	GH915BFCI	
Drawing #	Description	Part #	Qty
32	Gas Tap - Rear left & micro switch	GHS915BFC127	1
33	Gas Tap - & micro switch - WOK	GHS915BFC133	1
34	Pipe - wok	GHS915BFC134	1
35	Burner base - wok	GHS915BFC135	1
36	Jet - NAT	GHS915BFC136	1
	Jet - LPG	?	1
37	Igniter - wok sparker	GHS915BFC137	1
38	Thermocouple - WOK	GHS915BFC138	1
39	Elbow - pipe connection	GHS915BFC139	1
40	Gasket seal - pipework	GHS915BFC140	1
41	Nut - encapsulated on pipe	GHS915BFC141	0
42	Bracket - pipe	GHS915BFC142	1
43	Pipe - feeder	GHS915BFC143	1
44	Knob dark grey  *	GHS915BFC144	1
45	Hob S/Steel Euromaid logo *	GHS915BFC145	1
46	Burner - front right	GHS915BFC146	1
47	Cap - cast - front right	GHS915BFC147	1
48	Burner - rear right	GHS915BFC148	1
49	Cap - cast rear left	GHS915BFC149	1
50	? Screws ?	GHS915BFC150	
51	Trivett RIGHT 260x410	GHS915BFC151	1
52	Trivett CENTRE 315x410	GHS915BFC152	1
53	Trivett LEFT - Wok 360x410	GHS915BFC153	1
54	Cap cast - rear & front left	GHS915BFC154	2
55	Burner - rear & front right	GHS915BFC155	1
56	Cap - cast - Centre - WOK	GHS915BFC156	1
57	Cap - cast - Ring Wok	GHS915BFC157	1
58	Burner - wok	GHS915BFC158	1
59	?	GHS915BFC159	
60	?	GHS915BFC160	
61	?	GHS915BFC161	
62	Terminal block	GHS915BFC162	1
	Mount brackets	?	4
	Screws - mount screws	?	4
	Sealer strip - blue tack	?	1
	note ITEM 45 part # is different		1