

This exploded view diagram illustrates the assembly of a refrigerator. The main body is shown on the left, with the upper and lower doors positioned to the right. The upper door features a handle (1) and a hinge assembly (2, 3, 4, 5). The lower door has a handle (1) and a hinge assembly (2, 3, 4, 5). The interior of the refrigerator includes shelves (6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67) and drawers (6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67). The diagram also shows the internal components of the doors, including the hinge mechanism (1, 2, 3, 4, 5) and the handle assembly (1, 2, 3, 4, 5). The exploded view shows the relationship between the main body, the doors, the shelves, and the drawers, with numbered callouts (1-67) identifying each component.

No	Part No.	Description
1	20122990129	Egg Rack
2	3031400197	Upper door hinge
3	20122990103	Ice cube tray
4	20122080139	Upper door hinge,right
5	3031400040	Middle door hinge
7	2106100022	Shelves of freezer chamber
8	3039900316	Water channel of drain heater
9	3040300075	Fin evapurator
10	3050700023	Defrost heater
11	3050200087	Connecting wire of temperature sensor
14.1	20122990720	Rear cover of freeze wind tunnel part
14.2	20122990721	Installation cover of electrical motor
14.3	3071000311	Foam of freeze wind part
14.4	3059900004	Fan motor assembly of freeze wind tunnel part
14.5	2208500042	Front cover of freeze wind tunnel part
14.6	2208100219	Knob of freeze wind tunnel part
14.7	2208200085	Adjust catch of freeze wind tunnel part
18	3031400205	Lower door hinge assembly,left
19	20122080138	Upper door hinge,left
21	3050400018	LED Light
23	2100290010	Upper door
23.1	2200200004	Upper door gasket
23.2	2208510008	Right limit block,upper door
23.3	2208510007	Left limit block,upper door
23.4	3029900431	Inner door gasket
25	2207500047	Door rack,freeze
29.1	20122990726	Water rack
29.2	2701000134	Foaming parts A of refrigerate wind tunnel part
29.3	3071000313	Foaming parts B of refrigerate wind tunnel part
29.4	3050200252	Connecting wire of refrigerator
29.5	3050300057	Potentiometer
29.6	2208500006	Front cover of refrigerator wind tunnel part
29.7	2208100083	Knob of refrigerate wind
29.8	2800100001	Adhesive tape of refrigerator wind foaming parts
32	2207500051	Lower door rack,upper
33	2207500052	Lower door rack,lower
34	2100290008	Lower door
34.1	2200200005	Lower door gasket
34.2	20122090159	Right aid-closer,lower door
34.3	20122090176	Left aid-closer,lower door
39	2208300005	Front cover of freeze door
40	2106100007	Shelf of refrigerator chamber assembly
41	20120030165	Cover of crisper drawer
42	2106140017	Crisper drawer
43	2207300019	Drawer of freeze zone
44	20122990812	Short adjust leg

No	Part No.	Description
45	3031400204	Lower door hinge assembly , right
46	20122990023	Long leg
47	2107100002	Compressor support base
48	2500100017	Power supply cord plug
49	20114070006	Connecting tube
51	3040100333	Compressor
52	3050200094	Earthing wire of compressor
53	3040600005	Process tube
54	3040500011	Drier filter
55	20122990705	Drain pan
56	20114010106	Evaporative condenser
57	2207700024	Drain pipe
58	2208200135	Installation cover of electric control board
59	2500300066	Electric control board
61	20122010104	Lamp cover
62	2501100002	Door switch
300	2700500261	Trademark
301	2700104251	Carton