




Item	Part Number	Part Description	Qty.
1	W-ZT-777	Body	1
	W-CB-3104	Left panel of body	1
	W-CB-5704	Right panel of body	1
	W-DGZl-9400	Left Slider Bracket	1
	W-DGZl-9500	Right Slider Bracket	1
2	D-KG-235	Micro Switch	1
3	D-KG-206	Light Push Button	1
4	D-KG-205	Motor Push Button	1
5	P-DQH-152	Switch button box	1
6	P-DQH-153	Switch button box cover outside	1
7	W-DG-8602	Slider	2
8	W-Zl-9006	Glass Cover Lamp	1
9	W-ZSB-536	Front panel	1
	W-HJP-8305	Front panel connector	1
10	P-ZSB-308	Front panel cover	2
11	W-Zl-9705	Slider Bracket	1
12	W-GLW-460	Aluminum Filter Bottom	1
13	W-GLW-459	Aluminum Filter Top	1
14	P-GDZ-401	Bulb holder top cover	1
15	P-GDZ-402	Bulb holder bottom cover	1
16	D-DT-250	Bulb holder	2
17	920150	Bulb	2
18	P-DG-156	Left cover for slider	1
19	P-WG-106	Charcoal Filter Outside Cover	2
20	P-LG-102	Charcoal Filter Inside Cover	2
21	CF02	Charcoal filter	2
22	D-DJ-350	Motor	1
23	W-GDB-8408	Motor holder	1
24	Q-KK-153	Fastener Lamp Cover	2
25	D-LIX-131	Connector wire 2	1
26	S-LM-198	Blind rivet nut	4
27	D-DYX-046	AC wire	1
28	D-LIX-181	Connector wire 1	1