




No.	Part Number	Part Description	Qty.
1	W-ZT-758	Body	1
2	920150	Bulb	2
3	P-GDZ-401	Buld holder cover top	1
	P-GDZ-402	Buld holder cover bottom	1
4	P-DQH-152	Switch button box	1
	P-DQH-153	Switch button box cover outside	1
	D-KG-205	Motor Push Button	1
	D-KG-206	Light Push Button	1
	D-KG-207	Micro Switch	1
5	W-GDZ-8415	Motor Housing	1
6	D-DJ-345	Motor	1
	P-WG-103	Motor cover	1
	P-FYL-003	Propeller	1
	P-SZ-351	Small clip for propeller	2
	P-SZ-352	Big clip for propeller	1
7	P-LG-102	Charcoal filter	1
	P-WG-106		1
	Q-HXT-150		260g
8	W-ZJ-9714	Slider Bracket	1
9	W-ZSB-526	Front panel	1
	W-HJP-8318	Front panel holder	1
	P-ZSB-252	Front panel cover	2
10	W-GLW-464	Aluminum Filter Bottom	1
11	W-GLW-463	Aluminum Filter Top	1
12	P-YXJ-657	Wire clip top	1
13	P-YXJ-658	Wire clip top	1
14	Q-BL-001	Glass cover lamp	1
15	Q-BL-001	Fastener Lamp Cover	2
16	D-JXZ-302	Wire connector	1
17	W-DG-8602	Slider	2
18	P-DG-156	Cover for Left Slider	1
19	D-DYX-008	Plug	1
20	D-LJX-139	Connect wire 1	1
	D-LJX-101	Connect wire 2	1
	D-LJX-131	Connect wire 3	1