




Model: LKD20-AU

No	Part No.	Description
33	03.08.002.105	Main board
36	03.08.006.028	Display board
10	02.04.004.005	Club foot
12	03.08.002.106	keypad
	03.08.002.091	Remote