



















NUMBER	COMPONENT	DESCRIPTION	QUANTITY

	M9106SP6X5DBD	BAF91.1EG free-standing cooker	

01	601503	CIRCUIT DIAGRAM	1,000
01	601734	CIRCUIT DIAGRAM	1,000
01	800075	EXPLODED VIEW OF STRUCTURE	1,000
01	800112	EXPLODED VIEW COOLING FAN	1,000
01	800290	EXPLODED VIEW OF MUFFLE	1,000
01	800296	EXPLODED VIEW OF WORK TABLE	1,000
01	800460	EXPLODED VIEW OF OVEN	1,000
01	800799	EXPLODED VIEW OF DOTATION	1,000
01	910588	PAN SUPPORT BUMPER KIT	1,000
02	3100089	USER MANUAL	1,000
11	202375	PART FOR BURNER FIXING	2,000
38	306032	THERMOSTAT CLIP	4,000
39	306002	SPRING FOR KNOB	7,000
80	504160	COVER FOR SMALL FLAME SPREADER	1,000
81	504161	COVER FOR MEDIUM BURNER	2,000
82	504162	COVER FOR RAPID BURNER	1,000
83	504800	COVER OUT FOR ULTRA RAPID FLAME SPREADER	1,000
84	504798	COVER IN FOR ULTRA RAPID FLAME SPREADER	1,000
105	2020063	UP SUPPORT FOR AXIAL COOLIN FAN	1,000
106	2020062	DOWN SUPPORT FOR AXIAL COOLIN FAN	1,000
117	190061	SELF CLEANING PROT. FOR VENT.OVEN 9000	1,000
120	101280	OVEN TRAY	1,000
138	202348	DISHWARMER BOTTOM	1,000
160	202526	BRIDLE FOR FIXING GAS VALVES	1,000
205	410987	PROFILE FOR GLASS D00R	1,000
206	410986	PROFILE FOR GLASS D00R	1,000
207	308061	BUMPER FOR GLASS	2,000
274	202681	HORIZONTAL VENT	3,000
311	301156	SCREW 4,2X30	4,000
329	309176	INSIDE D00R PAN COMPARTMENT SPACER	2,000
362	4010451	PROFILE FOR GLASS D00R TAP RIGHT	1,000
363	4010452	PROFILE FOR GLASS D00R TAP LEFT	1,000
385	306024	SPRING FOR SPARK PLUG	5,000
389	301105	SCREW M5X45	2,000
392	309026	PART FOR KNOB PROTECTION FIXING	2,000
425	415054	SPARK PLUG 350MM	2,000
426	415057	SPARK PLUG 700MM	2,000
428	415102	SPARK PLUG FOR ULTRA RAPID BURNER	1,000
430	415081	ACCUMULATOR	1,000
436	402475	BACK FIBER GLASS	1,000
441	404042	SIDE GRID FOR OVEN	2,000
442	404154	GRID FOR OVEN	2,000
443	404151	GRID FOR TRAY	1,000
444	202936	FLASK HINGE	2,000
446	405134	OVEN D00R HINGE	2,000
450	409040	ELECTRONIC PROGRAMMER	1,000
478	200430	DISHWARMER FLAP D00R	1,000
561	508025	THERMOCOUPLE MM300	1,000
562	508021	THERMOCOUPLE MM600	2,000
565	508027	THERMOCOUPLE MM800	1,000
566	508034	THERMOCOUPLE ULTRA-RAPID BURNER	1,000

NUMBER	COMPONENT	DESCRIPTION	QUANTITY

	M9106SP6X5DBD	BAF91.1EG free-standing cooker	

611	603037	MOTOVENTILATOR	1,000
612	603039	COOLING FAN	1,000
613	606094	HEATING ELEMENT 1800W 240V	1,000
614	606095	UPPER+GRILL RESISTANCE	1,000
615	606045	CIRCULAR HEATER 3000W 240V	1,000
621	602031	COMMUTATOR 9+0	1,000
623	608062	OVEN BULB WITH HOLDER	1,000
648	601965	TERMINAL SEPARATOR	1,000
649	608034	SMALL WARNING LIGHT	1,000
667	602025	THERMOSTAT	1,000
670	504128	SMALL FLAME SPREADER	1,000
671	504129	MEDIUM FLAME SPREADER	2,000
672	504130	RAPID FLAME SPREADER	1,000
673	504796	ULTRA RAPID FLAME SPREADER	1,000
715	604072	DASYCHAIN SWITCH	1,000
760	510507	SMALL BURNER	1,000
761	510508	SEMI RAPID BURNER	2,000
762	510509	RAPID BURNER	1,000
763	510708	ULTRA-RAPID BURNER	1,000
880	502217	GAS VALVE BY PASS 034	1,000
881	502218	GAS VALVE BY PASS 036	2,000
882	502221	GAS VALVE BY PASS 052	1,000
883	502223	GAS VALVE BY PASS 065	1,000
917	200303	STAINLESS STEEL SIDE	2,000
929	202108	VERTICAL VENT	2,000
930	202214	FEET SUPPORT	2,000
940	405075	WORK TABLE AND TOP COVER HINGE RIGHT	1,000
941	405076	WORK TABLE AND TOP COVER HINGE LEFT	1,000
943	308041	BUMPER	4,000
960	408074	CAST IRON PAN SUPPORT 1 BURNER	1,000
965	408073	CAST IRON PAN SUPPORT 2 BURNERS	2,000
972	2020006	WORK TABLE FIXING	3,000
1039	4010164	THERMOSTAT KNOB	1,000
1041	4010161	GAS VALVE KNOB	5,000
1048	4010163	COMMUTATOR KNOB	1,000
1058	4010105	KNOB RING	7,000
1143	410816	RISER	1,000
1406	403495	OVEN HANDLE	1,000
1407	406431	OUTER OVEN DOOR GLASS	1,000
1411	411087	GASKET FOR OVEN FRONT 4 SIDE	1,000
1411	411088	GASKET FOR OVEN FRONT ONE SIDE	1,000
1415	602037	THERMOREGULATOR	1,000
1421	406588	INNER OVEN DOOR GLASS	1,000
1602	210595	CONTROL PANEL	1,000
1614	202888	BACK PROTECTION	1,000
1615	2020110	CONTROL SUPPOR	1,000
1616	402169	FIBER GLASS	1,000
1622	608029	SMALL YELLOW BUD	1,000
1624	200319	WORK TABLE	1,000
1627	501872	GAS COLLECTOR	1,000
1628	5010020	FRONT RIGHT TUBE	1,000

NUMBER	COMPONENT	DESCRIPTION	QUANTITY

	M9106SP6X5DBD	BAF91.1EG free-standing cooker	

1629	5010104	LEFT FRONT TUBE	1,000
1630	501833	RIGHT BACK TUBE	1,000
1631	501826	TUBE FOR LEFT BACK BURNER	1,000
1632	501828	CENTRAL TUBE	1,000
1640	202223	CLAMP PROTECTION FOR FLAP DOOR	1,000
1644	414055	FEET	4,000
1645	414063	BASE FOR LEGS	4,000
1661	202127	OVEN PANEL	1,000
1671	101256	ELECTRIC OVEN PANEL	1,000
1673	101468	BACK PANEL FOR OVEN	1,000
1674	101115	OVEN TOP PANEL BLACK	1,000
1677	101497	FRONT PANEL BLACK	1,000
1685	201152	BACK VENT STACK	2,000
1710	200857	OVEN GLASS SUPPORT	1,000
1720	200858	OVEN DOOR SUPPORT	1,000
2016	190040	OVEN SIDE PANEL BLACK RIGHT	2,000
2100	308041	BUMPER	1,000
2122	202370	CONTROL SUPPORT AND RESIST. PROTECTION	1,000
2130	201159	GRILL PROTECTION	1,000
4301	410974	VERTICAL PROFILE RIGHT	1,000
4302	410973	VERTICAL PROFILE LEFT	1,000
4311	409008	BLACK PUSH BUTTON FOR PROGRAMMER	5,000