



















Model: BAU95EE

No	Part No.	Description	Qty
1	601734	CIRCUIT DIAGRAM	1
1	800112	EXPLODED VIEW COOLING FAN	1
1	800290	EXPLODED VIEW OF MUFFLE	1
1	800743	EXPLODED VIEW OF STRUCTURE	1
1	800814	EXPLODED VIEW OF OVEN	1
1	800824	EXPLODED VIEW OF DOTATION	1
1	800917	EXPLODED VIEW OF WORK TABLE	1
2	3100141	USER MANUAL	1
38	306032	THERMOSTAT CLIP	4
P6C	P9C3X4	CERAMIC WORK TABLE	1
105	2020063	UP SUPPORT FOR AXIAL	1
106	2020062	DOWN SUPPORT FOR AXIAL COOLIN FAN	1
109	202220	INSIDE FLAP DOOR	1
117	190061	SELF CLEANING PROT. FOR VENT.OVEN 9000	1
120	101280	OVEN TRAY	1
138	202348	DISHWARMER BOTTOM	1
205	410987	PROFILE FOR GLASS DOOR	1
206	410986	PROFILE FOR GLASS DOOR	1
207	308061	BUMPER FOR GLASS	2
274	202681	HORIZONTAL VENT	3
311	301156	SCREW 4,2X30	4
329	309176	INSIDE DOOR PAN COMPARTMENT SPACER	2
362	4010451	PROFILE FOR GLASS DOOR TAP RIGHT	1
363	4010452	PROFILE FOR GLASS DOOR TAP LEFT	1
389	301105	SCREW M5X45	2
436	402475	BACK FIBER GLASS	1
441	404042	SIDE GRID FOR OVEN	2
442	404154	GRID FOR OVEN	2
443	404151	GRID FOR TRAY	1
444	202936	FLASK HINGE	2
446	405134	OVEN DOOR HINGE	2
450	409040	ELECTRONIC PROGRAMMER	1
478	200203	DISHWARMER FLAP DOOR	1
611	603037	MOTOVENTILATOR	1
612	603039	COOLING FAN	1
613	606094	HEATING ELMENT 1800W 240V	1
614	606095	UPPER+GRILL RESISTANCE	1
615	606045	CIRCULAR HEATER 3000W 240V	1
621	602031	COMMUTATOR 9+0	1
623	608062	OVEN BULB WITH HOLDER	1
624	309067	CORD FASTENER	1
648	601999	TERMINAL SEPARATOR	1
649	608034	SMALL WARNING LIGHT	1
667	602025	THERMOSTAT	1
917	200302	STAINLESS STEEL SIDE	2
929	202108	VERTICAL VENT	2
930	202214	FEET SUPPORT	2
941	2020107	SUPPORT FOR WORK TABLE	2
1031	4010598	POWER REGULATOR KNOB	2
1031	4010599	POWER REGULATOR KNOB	3
1039	4010511	THERMOSTAT KNOB	1
1048	4010510	COMMUTATOR	1
1407	406431	OUTER OVEN	1
1411	411087	GASKET FOR	1
1411	411088	GASKET FOR	1
1415	602037	THERMOREGULATOR	1
1421	406588	INNER OVEN DOOR GLASS	1
1508	410967	STAINLESS STEEL OVEN DOOR	1
1602	2100136	CONTROL PANEL	1
1614	202888	BACK PROTECTION	1
1615	2020262	CONTROL SUPPORT	1

No	Part No.	Description	Qty
1616	402169	FIBER GLASS	1
1622	608029	SMALL YELLOW BUD	1
1644	414055	FEET	4
1645	414063	BASE FOR LEGS	4
1661	202127	OVEN PANEL	1
1671	101256	ELECTRIC OVEN PANEL	1
1673	101468	BACK PANEL FOR OVEN	1
1674	101115	OVEN TOP PANEL BLACK	1
1677	101497	FRONT PANEL BLACK	1
1684	202959	BACK PROTECTION	2
1720	200858	OVEN DOOR SUPPORT	1
2016	190040	OVEN SIDE PANEL BLACK RIGHT	2
2100	308041	BUMPER	2
2100	308041	BUMPER	1
2122	202370	CONTROL SUPPORT AND RESIST.	1
2130	201159	GRILL PROTECTION	1
2317	202720	THERMOSTAT SUPPORT	2
4106	405047	HINGE FOR FLAP DOOR	2
4276	403629	OVEN HANDLE	1
4301	410978	RIGHT VERTICAL PROFILE	1
4302	410979	VERTICAL LEFT PROFILE	1
4311	409008	BLACK PUSH BUTTON FOR PROGRAMMER	5