




Model: BDW61S

No	Part No.	Description
1	DW-0003-226S	External door (Silver)
2	PS5-16B1C-80	Power switch
3	DW-0004-113	PCB holder
4	DW-0001-406	Inner door deadening
5	DW-0027-365-100	PCBA
6	DW-0007-361	Wiring
7	DW-0001-404	Inner door bitumen
8	DW-0001-027	Hinge assembly
9	DW-0001-164	Lower seal holder
10	DW-0001-345	Lower seal of inner door
11	DW-0001-225	Inner door
12	2857	Detergent dispenser
13	DW-0027-184	Program switch
14	DW-0001-346	Tub gasket
15	DW-0001-231	Lower front crosspiece
17	DW-0002-403	Tub bottom bitumen
18	DW-0001-230	Middle front crosspiece
19	DW-0002-212	Foot receiver
20	DW-0001-229	Bottom board
21	DW-0001-427	Overflow float
22	DW-0001-118	Overflow holder
23	MS1-06ZB1-A025-80	Overflow microswitch
24	050.0-708	OTK 500
25	DW-0005-024	Sump assembly
26	DW-0001-341	Hose clip
27	B25-6A	Drain pump
28	DW-0001-330	Sump seal
29	DW-0001-170	Sump deflector
30	CWF250KF3950	Temperature sensor
31	DW-0001-355	Seal for turbidity sensor
32	DW-0001-131	Overflow launder
33	DW-0001-382	Overflow hose
34	GB41-2000	Adjustable foot nut
35	DW-0002-151	Adjustable foot
36	DW-0005-239	Flowmeter holder
40	DW-0001-127	Air breaker nut
42	DW-0001-153	Hole plug
43	DW-0001-307	Screw for guide
44	DW-0001-140	Guide wheels
45	DW-0001-141	Guide rail support
46	DW-0001-356	Seal for guide support
50	DW-0001-336	Sump to heater hose
51	038.1-708	OTK381
52	YC032A1801	Heater
53	DW-0001-337	Heater to wash pump hose
54	039.6-708	OTK396

No	Part No.	Description
55	DW-0019-399	Rubber foot for washing pump
56	DW-0019-219	Washing pump bracket
60	DW-0002-228S	Right side panel(silver)
61	YXW48-2	Washing pump
62	036.1-708	OTK361
63	DW-0001-338	Outlet rubber duct for washing pump
66	DW-0001-351	Pressure hose
67	DW-0001-157	Hinge line
70	37610187	Pressure switch
71	DW-0002-303	Door spring
72	DW-0001-385	Air breaker
73	DW-0001-335	Seal for Air breaker
80	DW-0006-022	Tub assembly
81	DW-0001-211	Support reinforce
82	DW-0001-134	Clasp holder
83	DW-0001-306	Door lock hook
84	G004T13500	Jubilee clip
85	DW-0001-223	Middle rear crosspiece
88	017.5-708	OTK175
92	39290255	Water inlet valve
93	028.6-708	OTK286
94	DNF06-ZDFZF	Power filter
95	DW-0001-234	Middle rear crosspiece
96	DW-0001-362	Power cord
100	DW-0001-129	Draining hose casing
101	DW-0001-381	Drain hose
102	DW-0001-235	Pipe holder
103	XSL03-01	Inlet hose
104	DW-0001-405	Tub deadening
105	DW-0002-172	Side bracket of top panel
106	DW-0002-152	Top panel holder
107	DW-0002-171	Top panel front support
108	DW-0002-173	Top panel back support
109	DW-0002-154S	Top Panel (Silver)
110	DW-0002-434	Frame of top panel
111	DW-0002-401	Tub top bitumen
112	DW-0002-402	Tub band bitumen
113	DW-0001-232	Upper rear crosspiece
114	DW-0001-426	Pad for upper rear crosspiece
120	DW-0001-352	Rubber tack for inner pipe
123	DW-0001-137	Pipe casing
124	DW-0001-033	Lower sprayer assembly
125	DW-0001-133	Extractable cup filter
126	DW-0018-380	Inner pipe
127	DW-0001-132	Micro filter
128	DW-0001-135	Filter support
129	DW-0001-236	Flat filter

No	Part No.	Description
130	DW-0001-110	Watershed
131	DW-0001-333	Seal for watershed
141	DW-0001-237	Guide reinforcing plate
142		Hexagonal cap nut M5
143	DW-0002-227S	Left side panel (Silver)
144	DW-0005-387	Water breaker
145	DW-0005-358	Inlet hose for water breaker
146	019.2-708	OTK192
147	M0145801	Flowmeter
148	DW-0005-357	Inlet hose for flowmeter
150	DW-0001-122	Upper sprayer pipe holder
151	DW-0001-340	Matching seal
152	DW-0001-123	Matching piece
153	DW-0001-121	Upper sprayer pipe
154	DW-0001-032	Upper sprayer assembly
155	DW-0001-150	Cup rack
156	DW-0001-125	Basket wheel holder
157	DW-0001-124	Wheels for upper basket
158	DW-0001-301	Upper basket
161	DW-0001-126	Wheels for lower basket
162	DW-0001-302	Lower basket
163	DW-0001-039	Cutlery basket assembly
164	DW-0001-139	Guide rail rear block
165	DW-0001-138	Guide rail front block
166	DW-0001-238	Upper basket guide rail
167	W-15-302C	Door lock Microswitch
168	DW-0001-026	Door lock assembly
169	DW-0001-224	Dispenser holder
170	DW-0002-408	Inner door bitumen
172	DW-0027-366	Display board
173	DW-0027-117S	Power button (silver)
183	DW-0027-101S	Control panel (silver)
186	DW-0001-143	Drain hose hanger
191	DW-0027-177	Button
192	DW-0027-114	Display glass
193	DW-0002-155S	Kickplate (Silver)
135	DW-0027-183S	knob(Silver)