































Model: BFD6S

No	Part No.	Description	Qty
101	673002400205	Retaining box	1
102	673001500096	Hood	4
103	673001890128	HANDLE COVER	1
104	673000492434	Control Panel	1
105	673003000047	SCREEN cover	1
106	673001500095	Gasket	1
107	673002903831	Control panel film	1
108	672001801250	OUTER DOOR	1
109	673001101039	kick board	1
201	674010030017	DOOR SWICTH ASSEMBLY	1
202	672002200324	INNER DOOR	1
203	672002300037	FRICTION STRIP HOOKING	2
204	673001400330	LEFT FRICTION STRIP HOOKING CLAMPING	1
204	673001400331	RIHGT FRICTION STRIP HOOKING CLAMPING	1
205	672001300074	LEFT HINGE	1
208	672001700002	DISPENSER BRACKET	2
209	674000800058	DISPENSER	1
210	672001300073	RIGHT HINGE	1
211	672001300077	gemel join board	1
212	673002000165	right gap barrier	1
212	673002000164	left gap barrier	1
301	673000290166	TOP PANEL ASSEMBLY	1
302	672001600551	LEFT SIDE PANEL	1
303	673003100024	UPPER back support	1
305	673001300551	Cutlery shelf guider link stopper(back)	2
306	672001700023	Cutlery shelf guider(left)	1
309	673002801014	anti-noise borad	1
310	673001300639	UPPER BASKET guider link stopper(back)	2
311	672001700025	UPPER BASKET guider(left)	1
312	673001700132	door seal GASKET	1
313	673001400317	Cutlery shelf guider ASSEMBLY	4
314	672001400068	DOOR LOCK HOOK	1
315	672001600552	RIGHT SIDE PANEL	1
316	673001300552	Cutlery shelf guider supporting holder	4
401	674000000185	Power cord	1
402	673001600088	AIR BREAKER NUT	1
403	673002700610	AIR BREAKER ASSEMBLY	1
405	673000900354	DRAIN pipe CLAMPING	1
406	673002400251	weight BLOCK holder	2
407	676000600017	weight BLOCK	1
408	673001300556	tub Support	2
409	673000103038	motherboard ASSEMBLY	1
410	673001000052	FRICTION STRIP GUIDING	6
411	672002300063	FRICTION STRIP	2
414	672001100016	adjust screw OF DOOR SPRING	2
415	673000101085	base cover	1
417	673002400246	pcb seat cover	1
418	673002400245	pcb seat	1
419	674001002740	pcb	1
420	673001490013	FLOAT	1
421	674000200054	INLET VALVE ASSEMBLY	1
422	673001400197	overflow switch seat	1
423	673000900289	AIR BREAKER inlet pipe	1
424	674010030006	overflow switch	1
425	674000302021	PRESSURE SWITCH	1

No	Part No.	Description	Qty
426	673001400083	power supply loom clamping	1
427	673000900354	DRAIN pipe	1
501	673000903006	INNER PIPE	1
504	673001900023	water DISPENSER ASSEMBLY	1
505	673001900027	MIDDLE SPAYER PIPE ASSEMBLY	1
508	673000330030	LOWER SPRAYER	1
509	673001300548	LOWER SPRAYER seat	1
510	673002500142	PLASTIC FILTER	1
601	673001600057	SUMP NUT	1
602	673001500104	SUMP GASKET	1
603	673000900160	PVC pipe	1
607	673000701134	SUMP ASSEMBLY	1
608	673000900367	INNER DRAIN pipe	1
611	674000600154	Drainage pump	1
612	673002500134	main filter	1
613	673001300644	filter handle	1
614	673002500111	CYLINDR FILTER	1
615	673001500069	PUMP VIBRATION-PROOF PAD	1
616	674005600087	WASH PUMP ASSEMBLY	1
617	672002300038	motor holder	1
618	673001500111	PUMP GASKET	1
619	672000700031	940 CLAMPING	1
620	673001500115	HEATING ELEMENTS GASKET	1
621	674001100080	HEATING ELEMENTS ASSEMBLY	1
623	674000302012	WATER PRESSURE SWITCH ASSEMBLY	1
625	674000900038	Sensing device	1
701	672000810228	UPPER BASKET ASSEMBLY	1
704	672000820086	LOWER BASKET ASSEMBLY	1
705	673003200012	Cutlery shelf ASSEMBLY	1
710	673000900226	Inlet hose assembly	1
711	674000102041	Wiring harness	1
308+307	673001401022	basket guider supporter ASSEMBLY	4
306-a	672001700024	Cutlery shelf guider(right)	1
311-a	672001700026	UPPER BASKET guider(right)	1
412+413	672000101016	DOOR SPRING ASSEMBLY	2
507	12176000009090	Upper Spray Arm	