




Model: BS65MS

No	Part No.	Description	Qty
1	AK500KB06	KB06 knob	2
2	CPBS65MS	control panel for BS65MS	1
3/4	AKB501200001	indicator light red	2
5	AK5003250	function selector AK500-5D-2G-FS	1
6	AK50003	fixation board for LED display	1
7	AK500LD00T	LED display with touch control	1
8	AKB501180001	thermostat	1
9	AK500HD04	HD04 door handle (565MM)	1
11&12&13	AK500BDP06B01	the external glass of the BS65MS door (DP06)	1
14	AK50015	door hinge	2
	AK50016	hinge cover	1 set(2 pcs)
15	AK500SDF01	door frame (smeg door)	1
16	AK500SSC01	spring clip (smeg door)	4
18	AK50014SD	inner glass with clip	1
19&20	AK50018	sealing door	1
21	AKB501002401	plastic nut	4
22	AK50007B	front frame	1
23	AK50008CS	oven cube	1
24	AK5002534	support front frame left	2
25	AK50024	side panels (right/left)	2
26	AK50026	panel top outer casing	1
27	AK50027	air duct	1
28	AK50028	bracket cooling fan duct(air separator)	1
29	AK50029	cooling fan	1
30	AKB501060001	thermostat N/O	1
	AKB501001901	clip for thermostat	1
31	AK50031	top duct	1
32	AKB501210001	oven lamp	1
33&34&45	AKB501002101	Insulation Back, Bottom & Wrapper	1
36	AK50039	bracket oven support	2
37	AK50040	panel back cover	1
38&40&42	AKB501160001P	power cable with plug and terminal block	1
39	AK50041	thermostat N/C	1
	AKB501001901	clip for thermostat	1
41	AK500424D	inner power cord	1
43	AK50034	support front frame right	1
44	AK50043	panel base	1
46	AK50045	bottom duct	1
47	AK50046	hinge inner receiver	2
48	AK500HT70	top heat element(900W+1350W)	1
49	AK500HB70	bottom heat element(1300W)	1
50	AK50020	rear fan motor	1
51	AK50020B	blades of rear fan motor	1
52	AK50021	rear fan cover	1
53	AKB501002801	pan rack(trivet)	1
54	AK50023L02	safety shelf	1
55	AKB501001601	bake pan	1
56	AKB501001801	lift handle	1
57	AK50053	side shelf left (6 level)	1
58	AK50052	side shelf right (6 level)	1
59	AK500BPS	Baumatic pizza stone	1