









Model: CF6GW

Part No.	Description	Qty
IGHS604AFCI01	Electric box	1
IGHS604AFCI02	Nip 1 for the tube	1
IGHS604AFCI03	Bottom Cover plate	1
IGHS604AFCI04	Ignition sparker	1
IGHS604AFCI05	Inlet tube	1
IGHS604AFCI06	Aluminum tube 1	1
IGHS604AFCI07	Valve Gas Tap WOK T'Couple 1.1	1
IGHS604AFCI08	Nip 2 for the tube	1
IGHS604AFCI09	Sealing ring for valve	1
IGHS604AFCI10	Valve Gas Tap FR T'couple 0.6	1
IGHS604AFCI11	Valve Gas Tap Rear x 2 0.9	2
IGHS604AFCI12	Aluminum tube 4	1
IGHS604AFCI13	Burner Body # 50 Front Right	1
IGHS604AFCI14	Thermocouple (350 mm)	1
IGHS604AFCI15	Ignition pin (220 mm)	1
IGHS604AFCI16	Injector Front Right NAT	1
	Injector Front Right LPG	1
IGHS604AFCI17	Nut for the thermocouple	4
IGHS604AFCI18	Aluminum tube 3	1
IGHS604AFCI19	Burner Body #70 basement	2
IGHS604AFCI20	Thermocouple (500 mm)	1
IGHS604AFCI21	Injector Rear x 2 NAT	2
	Injector Rear x 2 LPG	2
IGHS604AFCI22	Aluminum tube 2	1
IGHS604AFCI23	Ignition pin (470)	1
GHS604AFCI24E	Knob Dark Grey HIGH TOP (see A)	4
GHS604AFCI24D	Dark Grey knob for serie 2 cooktop	4
GHS604AFCI24	Light Grey knob for serie 1 cooktop	4
GHS604AFCI24WH	Knob (white) (100#_WH)	4
IGHS604AFCI25	HOB EUROMAID Logo	1
IGHS604AFCI26	Trivet Left pan support	1
IGHS604AFCI27	Trivet Right pan support	1
IGHS604AFCI28	Burner #50 Front Right	1
IGHS604AFCI29	Cap Burner # 50 Front Right	1
IGHS604AFCI30	Burner #70 Rear x 2	2
IGHS604AFCI31	Cap Burner cast #70 Rear x 2	2
IGHS604AFCI32	Cap Burner Small inner WOK	1
IGHS604AFCI33	Cap Burner Ring outer WOK	1
IGHS604AFCI34	Burner - WOK # 120	1
IGHS604AFCI35	Thermocouple (350 mm)	1
IGHS604AFCI36	Ignition pin (550 mm)	1
IGHS604AFCI37	Injector WOK NAT	1
	Injector WOK LPG	1
IGHS604AFCI38	Burner Body # 120# basement	1
IGHS604AFCI39	Elbow	1
IGHS604AFCI40	Gasket	1
IGHS604AFCI41	Connection	1
IGHS604AFCI42	Nut for the connection	1