


Exploded View



Model: ECFR200W

No	Part No.	Description	Qty
1	20201020020	Door	1
2	20201020020	Door gasket	1
3	20122990706	Ice scoop	1
4	3039900254	Food box	1
5	20122990648	Drain-pipe plug	1
7	20106990029	Cover of compressor	1
8	3050500010	Indicator light	1
9	20122010167	Thermostat knob	1
10	20122010196	Thermostat display card	1
11	3040200053	Thermostat	1
12	20060745	Drier filter	1
13	20060046	Connecting tube	1
14	20122990649	Drain-pipe decorative cover	1
15	20061718	Process tube	1
16	3040100316	compressor	1
17	20105050013	Compressor base support	1
18	3050100125	Power supply cord plug	1
19	3050200220	Connecting wire of	1
20	20122990708	Scroll wheel	2
21	3031400173	Door hinge assembly	1
22	3039900311	Cover of door hinge	2
23	3039900310	Cover of door hinge	2
24	3031400174	Door hinge assembly	1
25	3070102284	Carton	1