




Model: ESBS563S

No	Part No.	Description	Qty
2	2107150009	Adjustable foot assembly	2
3	2208510094	Door aid-closer,right	1
4	2301400089	Lower door hinge assembly,left	1
5	2208510095	Door aid-closer,left	1
8	2301400088	Lower door hinge assembly,right	1
9	2501100018	Damper motor of refrigerator wind	1
10	2800100113	Seal sponge of damper motor	1
11	2701000348	Fixation foam of damper motor	1
12	20122990629	Thermal head cover	1
13	2208100797	Decorative cover of refrigerator wind tunnel parts	1
14	2208100776	Decorative link of refrigerator wind tunnel parts	1
15	2208500160	Front cover of refrigerator wind tunnel parts	1
16	2701000346	Front foam of refrigerator wind tunnel parts	1
17	2701000347	Rear foam of refrigerator wind tunnel parts	1
18	2208500161	Thin film of refrigerator wind tunnel parts	1
19	2800100102	Inner seal sponge of refrigerator wind tunnel parts	1
23	20122030509	Upper drawer	1
24	2106160592	Lower drawer	1
28	2106100386	Shelf of freezer chamber,upper	3
29	2106100384	Shelf of freezer chamber,middle	1
30	2106100385	Shelf of freezer chamber,lower	1
32	2107160034	Rjght guide	2
33	2107160033	Left guide	2
34	2106120379	Cover of crisper drawer	5
35	20122050392	Upper door rack cover,right	1
36	20122050409	Door rack,upper	1
37	20122050408	Door rack,lower	3
39	3039900184	Limit line iron	2
40	20122040293	Crisper drawer,upper	1
41	2106140791	Crisper drawer,lower	1
42	2200200137	Door gasket,right	1
43	2100250599	Door,right	1
44	20122990493	Screw cap	3
45	2208500163	Front cover of freezer wind parts,upper	1
46	2800100103	Seal sponge of upper cover	1
47	2501000015	Fan motor parts with fan	1
48	2208500048	Front cover of Freezer wind parts,lower	1
49	3080100058	Seal sponge of lower cover	1
50	2208500162	Upper bracket of freezer wind parts	1
51	2800100104	Seal sponge of outlet wind parts	1
52	2208100797	Decorative cover of refrigerator wind tunnel parts	1
53	2208100776	Decorative link of refrigerator wind tunnel parts	1
60	2208100963	Cover of ceiling light	2
61	2500400015	Ceiling light	2
62	2208100432	Cover of right hinge,upper	1
63	3031400215	Upper door hinge assembly,right	1
64	3031400214	Upper door hinge assembly,left	1
65	2208100431	Cover of left hinge,upper	1
67	2500300175	Control board	1
68	2305700074	Cover of control board	1
69	2207500223	Left rack,upper	1
71	20122050407	Left rack	3
72	2200200138	Door gasket,left	1
73	2100250600	Door,left	1
75	2500300124	Display circuit board	1
76	2209100176	Display panel	1
78	2207700087	Drain pan	1
79	2402400019	Evaporative condenser	1
80	3020600065	Drain pipe	1

No	Part No.	Description	Qty
82	2107100005	Compressor base support	1
83	2500100017	Power supply cord plug	1
85	20114070006	Connecting tube	1
86	3040500022	Drier filter	1
87	2400100434	Compressor assembly	1
91	3050200094	Earthing wire of compressor	1
92	3040600005	Process tube	1
93	2501100039	Temperature sensor	1
94	3040300056	Fin Evaporator	1
95	2500700048	Frost heater & fuse	1
97	3039900181	Fixed slot of heater	1
99	2501100017	Door switch	2
100	20122990140	Egg tray	1
101	20122990139	Egg tray	1
102	20122990103	Ice cube tray	1
300	2700501281	Trademark	1
301	2700115188	Carton	1