


# Exploded View



**Model: ETM362S**

| <b>No</b> | <b>Part No.</b> | <b>Description</b>                               | <b>Qty</b> |
|-----------|-----------------|--------------------------------------------------|------------|
| 1         | 20122990129     | Egg Rack                                         | 1          |
| 2         | 3031400197      | Upper door hinge                                 | 1          |
| 3         | 20122990103     | Ice cube tray                                    | 1          |
| 4         | 20122080140     | Upper door hinge,right                           | 1          |
| 5         | 3031400040      | Middle door hinge                                | 1          |
| 6         | 2208200007      | Door hinge screw hole cover                      | 1          |
| 7         | 2106100022      | Shelves of freezer chamber                       | 1          |
| 8         | 3039900316      | Water channel of drain heater                    | 1          |
| 9         | 3040300075      | Fin evaporator                                   | 1          |
| 10        | 3050700023      | Defrost heater                                   | 1          |
| 11        | 3050200087      | Connecting wire of temperature sensor            | 1          |
| 14.1      | 20122990720     | Rear cover of freeze wind tunnel part            | 1          |
| 14.2      | 20122990721     | Installation cover of electrical motor           | 1          |
| 14.3      | 3071000311      | Foam of freeze wind part                         | 1          |
| 14.4      | 3059900004      | Fan motor assembly of freeze wind tunnel part    | 1          |
| 14.5      | 2208500042      | Front cover of freeze wind tunnel part           | 1          |
| 14.6      | 2208100219      | Knob of freeze wind tunnel part                  | 1          |
| 14.7      | 2208200085      | Adjust catch of freeze wind tunnel part          | 1          |
| 18        | 2301400040      | Lower door hinge assembly,left                   | 1          |
| 19        | 20122080161     | Upper door hinge,left                            | 1          |
| 21        | 3050400018      | LED Light                                        | 1          |
| 23        | 2100290535      | Upper door                                       | 1          |
| 23.1      | 2200200070      | Upper door gasket                                | 1          |
| 23.2      | 2208510008      | Right limit block,upper door                     | 1          |
| 23.3      | 2208510007      | Left limit block,upper door                      | 1          |
| 23.4      | 3029900431      | Inner door gasket                                | 1          |
| 25        | 2207500047      | Door rack,freeze                                 | 2          |
| 29.1      | 20122990726     | Water rack                                       | 1          |
| 29.2      | 2701000134      | Foaming parts A of refrigerate wind tunnel part  | 1          |
| 29.3      | 3071000313      | Foaming parts B of refrigerate wind tunnel part  | 1          |
| 29.4      | 3050200252      | Connecting wire of refrigerator                  | 1          |
| 29.5      | 3050300057      | Potentiometer                                    | 1          |
| 29.6      | 2208500006      | Front cover of refrigerator wind tunnel part     | 1          |
| 29.7      | 2208100083      | Knob of refrigerate wind                         | 1          |
| 29.8      | 2800100001      | Adhesive tape of refrigerator wind foaming parts | 1          |
| 32        | 2207500051      | Lower door rack,upper                            | 1          |
| 33        | 2207500052      | Lower door rack,lower                            | 2          |
| 34        | 2100290536      | Lower door                                       | 1          |
| 34.1      | 2200200005      | Lower door gasket                                | 1          |
| 34.2      | 2208510049      | Right aid-closer,lower door                      | 1          |
| 34.3      | 2208510050      | Left aid-closer,lower door                       | 1          |
| 34.4      | 2305400017      | Iron liner of lower aid-closer,right             | 1          |
| 34.5      | 2305400018      | Iron liner of lower aid-closer,left              | 1          |
| 39        | 2208300005      | Front cover of freeze door                       | 1          |
| 40        | 2106100007      | Shelf of refrigerator chamber assembly           | 2          |
| 41        | 20120030165     | Cover of crisper drawer                          | 1          |
| 42        | 2106140017      | Crisper drawer                                   | 1          |
| 43        | 2207300019      | Drawer of freeze zone                            | 1          |
| 44        | 20122990727     | Long adjust leg                                  | 1          |
| 45        | 2301400039      | Lower door hinge assembly , right                | 1          |
| 46        | 20122990781     | Long leg                                         | 1          |
| 47        | 2107100002      | Compressor support base                          | 1          |
| 48        | 2500100017      | Power supply cord plug                           | 1          |
| 49        | 20114070006     | Connecting tube                                  | 1          |
| 51        | 3040100333      | Compressor                                       | 1          |
| 52        | 3050200094      | Earthing wire of compressor                      | 1          |
| 53        | 3040600005      | Process tube                                     | 1          |
| 54        | 3040500011      | Drier filter                                     | 1          |
| 55        | 20122990705     | Drain pan                                        | 1          |
| 56        | 20114010106     | Evaporative condenser                            | 1          |
| 57        | 2207700024      | Drain pipe                                       | 1          |

| No  | Part No.    | Description                                  | Qty |
|-----|-------------|----------------------------------------------|-----|
| 58  | 2208100428  | Installation cover of electric control board | 1   |
| 59  | 2500300066  | Electric control board                       | 1   |
| 61  | 20122010104 | Cover of ceiling lamp                        | 1   |
| 62  | 2501100002  | Door switch                                  | 1   |
| 300 | 2700500261  | Trademark                                    | 1   |
| 301 | 2700105455  | Carton                                       | 1   |