




Model: EUF246W

No	Part No.	Description
1	10010379	Box body
3	20011364	Top cover
5	20020251	Upper door hinge
6	20011363	Top cover support plate
7	20050016	Door switch
8		Door
9	20012794	Door gasket
10A	20012257	Lower door lower balcony (transparent)
10B	20011522	Lower door lower balcony (emerald green)
10C	20012662	Lower door lower balcony (ice blue)
11A	20012259	Lower door upper balcony (transparent)
11B	20011523	Lower door upper balcony (emerald green)
11C	20012663	Lower door upper balcony (ice blue)
12	10200525	Shelf
13	20060135	Thermostat
14	20050031	Lamp holder assembly (E14)
15	20010216	Thermostat cover
16	20010217	Lamp cover
17	20050046	Lamp Bulb (E14,220V)
18	20010024	Thermostat knob
19	20020158	Lower door hinge
20	20011385	Short adjust foot
21	10200524	Crisper cover
22A	20013159	Crisper drawer (transparent)
22B	20012880	Crisper drawer (emerald green)
22C	20013130	Crisper drawer (ice blue)
23	10201405	Compressor base support
24A	20012263	Lower door small balcony (transparent)
24B	20011751	Lower door small balcony (emerald green)
24C	20013127	Lower door small balcony (ice blue)
25		Power supply cord with plug
27	20050009	Compressor connecting wire
28	20050008	Compressor earthing wire
29	DL116000	Compressor
30	20060010	Process tube
33A	20060046	Connecting tube (short)
33B	20060020	Connecting tube (long)
34	20010193	Drain pan
36	20011356	Wire box
38	20010540	Long adjust foot
39	20060024	Drier filter (for R600a)
40A	20012301	Balcony cover (transparent)
40B	20011640	Balcony cover (emerald green)
40C		Balcony cover (ice blue)
42	20060649	Condenser