







Version 2 (141217)
































Model: GDDW60

Version 2 (141217)

14-Dec-17

No	Part No.	Description	Qty
	258300024	HANDLE-WHITE-BTO1-417-OEM	1
	218300777	MAIN OVEN TOP HINGE DOOR SIDE	1
	218300774	MAIN OVEN SIDE OPENING DOOR TOP HINGE	1
	218300775	MAIN OVEN BOTTOM HINGE DOOR SIDE	1
0010	250315183	TAP KNOB-	4
1006	250315599	KNOB COM-TOP OVEN	1
1007	250315598	MAIN OVEN COMMUTATOR+THERMOSTAT KNOB	1
0101	264440102	OVEN CIRCULATION BLOWER-220V-240V	1
1021	250390104	PLASTIC HOSINGPART OFLOKING GR. WITH RO	1
1027	215440258	BI METAL HIT PROTECTION SHEET	2
1047	215300099	SIDE OPENING HINGE SUPPORT SHEET	1
1049	219300069	TOP HEATER PROTECTING SHEET	1
0106	262900095	BOTTOM HEATING ELEM_(1100+1100)W_240V_UL	1
1064	258300032	BURNER PLATE FIXING DECOR	2
0107	262900098	GRILL HEATING ELEMENT_(1100+1100)W_240V	1
0108	215440109	HEATING ELEMENT HOLDER SHEET	1
0011	215300005	DOUBLE OVEN REAR WALL.	1
1127	258300040	YELLOW SIGNAL LAMP HOLDER PLASTIC GR	2
0118	260305109	SERVICE CABLE GROUP.	1
0012	218300199	SIDE WALL -WHITE -60X60X90	2
1238	218300219	BOTTOM PLATE CONDENSATION SHEET-BLACK	1
0124	255244004	DEFENDI WOK BURNER NOZZLE SEAL 5 KW	1
0124	255900028	BURNER NOZZLE SEAL 1 KW - 0690	1
0124	255900029	BURNER NOZZLE SEAL 2 KW - 0690	2
1240	215300027	STATIC CONNECTION SHEET	2
0014	210920256	FOOT GROUP	4
0140	173100022	KNOB PROTECTING SHEET CLIP WASHER	2
0015	215930001	LOWER BASE PLATE	1
0150	171100083	M4X6 HANDLE TO PIN CONNECTION SCREW	2
0155	230100028	TERMOCOUPLE_SHORT_350mm	1
0155	230244004	DEFENDI THERMOCOUPLE WOK	1
0155	230100032	TERMOCOUPLE_SHORT_520mm	2
0160	215300031	DRAWER SUPPORTING SHEET _ RIGHT _ BARFS	1
0165	415100017	Q 16 TAP CONNECTING PIPE CLIP	4
0180	258300065	SWITCH PROTECTING SHEET	1
0019	266920004	TERMINAL BLOCK.	1
0020	210440773	MAIN OVEN BODY	1
0205	140954006	DC200.GRILL SHELF	1
0205	240440119	WIRE SHELF FOR TRAY	1
0209	410920509	TRAY HANDLE GROUP.	1
0021	291300027	GLASS WOOL_PERIPHERAL	1
0021	291400024	GLASS WOOL_PERIPHERAL	1
0021	291300010	GLASS WOOL_PERIPHERAL	1
0022	291300011	GLASS WOOL_ REAR_60ANK_15MM	1
0022	291300017	REAR GLASS WOOL	1
0023	215300015	BARBAROS FS TURBO MOTOR CONNECTION SHEET	1
0024	210300166	ELECTRICAL FLUE GROUP	1
0024	224300016	ELECTRICAL FLUE GROUP	1
0240	131261014	THERMOCOUPLE FIXING NUT	4
0242	219440108	REMOVABLE CATALYTIC LINER-RIGHT	1
0242	219440109	REMOVABLE CATALYTIC LINER-LEFT	1
0242	219450022	CATALITIC SIDE WALL LEFT	1
0242	219450023	CATALITIC SIDE WALL RIGHT	1
0243	240440116	WIRE SHELF RIGHT - 55 Lt OVEN	1
0243	240440117	WIRE SHELF LEFT - 55 Lt OVEN	1
0243	240440156	WIRE SHELF LEFT-35 Lt OVEN	1
0243	240440157	WIRE SHELF RIGHT - 35 Lt OVEN	1
0261	450300012	HANDLE BOTTOM PLASTIC	2
0263	263100015	EGO THERMOSTAT 551705303_280 HUAYI 285 C	1

No	Part No.	Description	Qty
0263	263100016	EGO THERMOSTAT 55.17042.030_250_TOP OVEN	1
0027	240440219	INTERNAL WIRE FRY STOPER RAFLI_BAR_AVUST	3
0276	290300030	GLASS	1
0279	250400250	SWITCH GROUP	1
0028	419920299	TRAY-WIDE SKIRTED	2
0028	219440101	BLACK ENAMELED ST TRAY(W_462xD_365xH_39)	1
0286	155955703	HANDLE SEAL	2
0029	255440101	MAIN OVEN _O_ SEAL	1
0029	255440139	TOP OVEN _O_ SEAL	1
0294	210450108	TOP OVEN BODY	1
0300	458920104	TIMER BUTTON.	6
0304	210390101	FRONT DOORLOCK GR.(PLAS. ROLLERS-SMALL)	1
0305	215390102	FRONT DOOR LOCK PIM	1
0322	218440227	UPPER COVER SHEET_ROLL FORMING_BLACK	1
0328	4431900198	G30-30MBAR BUTANGAZ_3+WOK_3.3 kw_SABAF	1
0338	219910072	BURNER CAP 1 KW	1
0339	219910071	BURNER CAP 2 KW.	2
0342	423920044	BURNER HEAD 1 KW_SABAF	1
0343	423920045	BURNER HEAD 2 KW_SABAF	2
0346	223910060	BURNER GROUP (SABAF 1 KW).	1
0347	223910059	BURNER GROUP (SABAF 2 KW).	2
0350	431920061	SABAF INJ G20-10MBAR 1KW_M90	1
0350	431920052	SABAF INJ G30_28-30BAR 1KW_M50	1
0351	431920060	INJECTOR OVEN-GRILL 2 KW	2
0351	431920051	SABAF-BRAND ENJ G30.28-30 2.XKW_M72	2
353	231244008	DEFENDI WOK INJECTOR	1
36	289300001	COUNTER WEIGHT_RIGHT..	1
368	218300215	SIDE PROFILE-BLACK-LEFT	1
369	218300216	SIDE PROFILE -BLACK-RIGHT	1
371	217300231	BURNER PLATE FRONT FIXING SPRING	2
374	265900012	OVEN LAMP 15 W-230 V	1
375	265100022	OVEN LAMP GROUP	1
376	410930196	CAST IRON PAN SUPPORT GROUP	2
378	223910156	SABAF COAXIAL GAS TAP_1 KW_.	1
379	223910157	SABAF COAXIAL GAS TAP 2 KW_.	2
384	221300028	FEEDING TUBE-REAR RIGHT	1
384	221300111	FEEDING TUBE-REAR RIGHT	1
385	221300029	FEEDING TUBE- FRONT RIGHT	1
386	221300027	FEEDING TUBE.REAR LEFT	1
0400	151900001	TIP OF THE PLASTIC HOSE_NG	1
0400	123900021	AUSTRALIA NG ADAPTER	1
0400	231900047	ADAPTOR PART SEAL_BELGIUM	1
0412	258111180	TIMER INDICATOR PLASTIC	1
0432	268100075	IGNITION ELECTRIC SWITCH	1
0045	210441121	TOP OVEN FRONT DOOR HINGE	2
0452	215300215	GAS BURNER SUPPORT -4G	1
0452	215300216	GAS BURNER SUPPORT -WOK	1
0460	250920069	CABLE TIE-BIG_M TYPE_A20	4
0047	250000023	HANDLE GR.WHITE	1
0475	165930012	SIGNAL LAMP_YELLOW	2
0489	215300120	PROTECTION SHEET FOR KNOB	1
0496	210300258	TOP OVEN FRONT DOOR OUTER PART	1
0531	231440109	MAIN OVEN SIDE OPENING DOOR PIM	2
0533	440100010	OVEN FIXING CHAIN	0.48
0541	255300016	BURNER PLATE FIXING TAMPON	4
0541	255300017	BURNER PLATE FIXING TAMPON_BAR FS	2
557	263410017	BODY BIMETAL THERMOSTAT ABNORMAL CONDITI	2
566	155261009	PAN SUPPORT BOTTOM PLASTIC	8
576	250100045	SWITCH PLASTIC COVER	2
579	215390101	DOUBLE OVEN REAR WALL BOTTOM SHEET	1

No	Part No.	Description	Qty
584	218440178	CONDENSATION SHEET-BLACK	1
6	219300093	BURNER PLATE.	1
62	168244011	SPARK PLUG WOK MIDDLE 600 MM	1
62	268900035	SPARK PLUG 650 MM	2
62	268900046	SPARK PLUG_REAR LEFT 380 MM	1
654	255900015	SPRAK PLUG SEAL.	1
657	260100005	SAP CABLE GROUP	1
665	218920313	SPLASH BACK	1
67	210300779	MAIN GAS PIPE GROUP	1
68	242900003	SPARK PLUG CLIPS - SABAF	3
68	242900013	DEFENDI WOK BURNER SPARK PLUG KLIPS	1
70	268100065	GAS IGNITOR.	1
70	110241216	GAS IGNITOR GR	1
71	415920131	IGNITION FIXING SHEET	1
72	255100012	NOZZLE SEAL	3
72	255440112	FRONT DOOR STOPER PLASTIC	2
775	223244004	DEFENDI 3.3 WOK BURNER	1
776	223244062	DEFENDI WOK BURNER GR	1
777	219244012	DEFENDI WOK BURNER CAP INNER	1
777	219244013	DEFENDI WOK BURNER CAP OUTER	1
787	256300001	KNOB PROTECTION SHEET	2
81	123900020	AUSTRALIA LPG ADAPTER	1
81	133900003	ADAPTOR-1/2"LPG HOSE	1
82	133900001	1_2 PLUG	1
822	223910163	SABAF COAXIAL GAS TAP 2 KW_.	1
83	218300284	KNOB HEAT SHIELD	1
857	119240080	PAN SUPPORT WOK ADAPTER	1
883	250440102	DOOR GR SIDE HINGE PLASTIC HOUSING_LEFT	1
883	250440103	DOOR GR SIDE HINGE PLASTIC HOUSING_RIGHT	1
884	210300265	MAIN OVEN SIDE OPENING DOOR GR	1
885	234000002	DOOR TO HANDLE CONNECTION PIN	2
885	234300021	DEATTACHABLE DOOR HANDLE REFERENCE PIN	2
885	234440103	HANDLE REFERENCE CONNECTION PIN	2
9	218315256	DECORATIVE CONTROL PANEL.	1
902	210440105	THERMOSTAT BULB CLIP	2
905	450930003	OVEN DOOR PROFILE TOP COVER PLASTICRIGHT	1
911	450920615	FOOT GROUP NUT_LONG_PLASTIC	4
912	215300004	OVEN REAR SUPPORT_72CM	2
916	255440116	FRONT DOOR STOPER PLASTIC	2
916	255440118	FRONT DOOR STOPER PLASTIC_BOTTOM_Ø8	1
93	263100004	TURBO COMMUTATOR	2
936	450930005	OVEN DOOR PROFILE TOP COVER LEFT	1
938	218300205	SIDE DECOR PROFILE-LEFT	1
939	218300206	SIDE DECOR PROFILE-RIGHT	1
944	215300006	REAR CONNECTION SHEET	2
945	250300034	FLUE ADAPTOR PLACTIC	1
946	258300066	SIDE DECOR DOOR -LEFT_WHITE	1
947	258300067	SIDE DECOR DOOR -RIGHT_WHITE	1
948	250300022	PANEL BOTTOM PLASTIC	1
949	172440103	WIRE SHELF FIXING NUT	4
950	217440103	BAR TURBO FAN BLADE	1
957	215300068	FLUE FIXING SHEET	2
96	267100147	DIGITAL TIMER WITH 6 BUTTONS_BARACUDA	1
97	219440102	FAN PROTECTING SHEET	1
971	215410152	DROPPER SHEET SIDE OPENING	1
975	4418100102	SPLASHBACK FIXING SCREW GR	1
98	262900090	CIRCULAR HEATING ELEMENT	1
984	234300025	SHEET TOP LID FIXING SPECIAL SCREW	2
985	250300612	SHEET TOP LID HINGE HOLDER PLASTIC PART	2