



999039703

FRONTALINO - D-101

Frontalino 1F-1A con TIMER


AGG. 14-07-05



999039402


ESTETICA - C-061

AGG. 14-10-05



FORNO - B-025


AGG. 24-02-04



999022422

STRUTTURA - A001

AGG. 27-09-05



Model: IOF6SE2

No	Part No.	Description
CUA007	542007800	TERMINAL BOARD
CUA283	268105200	BODY SUPPORT COLUMN
CUA287	268103500	OVEN TOP PANEL
CUE287	268103500	OVEN TOP PANEL
CUE288	272025900	OVEN SIDE PANEL
CUA289	254018100	OVEN BOTTOM PANEL
CUA293	292004300	OVEN REAR PANEL
CUA297	268059300	SWITCH PROTECTION BOX
CUA300	502010900	GROMMET
CUB017	524023100	UPPER OVEN ELEMENT
CUB022	502011601	COMPLETE LIGHT UNIT
CUB038	512012801	MOTORISED FAN
CUB039	524022100	MOTORISED FAN CIRCULAR HEATING ELEMENT
CUB043	502008900	LIMITER
CUB073	248033000	OVEN GRILL
CUB075	268080900	HOT AIR DIFFUSER
CUB076	420069700	OVEN DOOR GASKET ALTERNATE PART No. 420066700
CUB144	248019700	TRAY RACK
CUB246	294000502	OVEN TRAY
CUB270	268107900	BODY SUPPORT COLUMN
CUB272	258014300	OVEN SUPPORT REAR CROSS MEMBER
CUB292	502013300	TANGENTIAL FAN
CUB309	180001200	BODY PROTECTION WOOL PANEL
CUB310	180007600	REAR PROTECTION WOOL PANEL
CUB312	268091200	OVEN TOP AIR CASING
CUB312	268113100	OVEN TOP AIR CASING
CUB313	268070200	TANGENTIAL DUCT
CUB315	268049300	CONDENSATE DUCT
CUB316	29000100	DOUBLE HANDLE FOR TRAY
CUB330	402031600	OVEN SHELL HOLE PLUG
CUB330	350018600	OVEN SHELL HOLE PLUG
CUB529	540005300	OVEN LIGHT
CUC028	260009700	HANDLE MOUNTING BRACKET
CUC028	260013200	HANDLE MOUNTING BRACKET
CUC053	246018501	RIGHT OVEN HINGE
CUC059	428010500	HANDLE SPACER
CUC063	769066200	OVEN OUTER GLASS
CUC077	322140200	OVEN HANDLE
CUC136	402029000	COMPARTMENT AND OVEN DOOR RUBBER
CUC233	760028500	OVEN INNER DOOR
CUC265	287010300	BODY FASCIA
CUC265	287011700	BODY FASCIA
CUC311	180003600	HANDLE PROTECTION WOOL PANEL
CUC343	436009500	HOB SPACER
CUC412	458004801	ROLLER CARRIER
CUC512	430027900	SCREWS (FASCIA)

No	Part No.	Description
CUC513	430024400	SCREWS (HANDLE)
CUD015	540003900	NEUTRAL CONE INDICATOR WITH BLUE WIRES
CUD020	502006301	OVEN SWITCH
CUD032	346013600	LIGHT BULB FOR YELLOW INDICATOR
CUD067	804650000	FRONT PANEL
CUD081	326160300	ELECTRIC KNOB
CUD081	326170700	ELECTRIC KNOB
CUD096	516048100	TIMER OR PROGRAMMER
CUD172	526015403	OVEN OR GRILL THERMOSTAT
CUD616	444018400	THERMOSTAT BULB SPRING
CUM069	428015200	TIMER SPACER
CUP027	526022100	OVEN SWITCH + ELECTRIC THERMOSTAT