




69	EB70-14-01		1			55	EB-75ERCD-04		1		
68			1			54	EB90-5		1		
67	EB-75ERCD-27		1			53	EB90-19-1		1		
66	EB90-6		1			52	EB90-19-3		1		
65			2			51			4		
64	EB-68ECD3-15		1			50	42. ---, ---		1		
63	EB90-18-1		1			49	EB56-153-3A		1		
62	EB70-11-04		2			48			2		

47	EB56-182-A		6		
46	EB90-38-A		1		
45	EB90-28-1		2		
44	EB90-41-A		1		
43	EB90-40-A		1		
42	EB75-14-01		1		
41	EB-75ERCD-28		1		
40	EB-75ERCD-03-02		1		
39	EB56-08-01		2		
38	EB90-44-A		1		
37	EB90-37-A		1		
36	EB-75ERCD-03-05		1		
35	EB-75ERCD-03-03		1		
34	EB-75ERCD-03-04		1		
33	EB90-20		1		
32			4		
31	EB90-14		1		
30			2		
29	EB75-BC02-01		1		
28	EB-75ERCD3-P-02		1		
27			1		
26	EB90-34		1		
25	EB90-33		1		
24	EB56-122-A		2		
23	55. 19---, ---		1		
22	EB-75ERCD3-P-01		1		
21	EB-68ECD8-25		1		
20	EB90-28-2		2		
19	EB-68ECD8-31		2		
18	EB-68ECD3-16		1		
17	EB-75ERCD-09		1		
16	EB90-38		1		
15	EB-75ERCD-13		1		
14	EB90-19-2		1		
13	EB40-210-A		1		
12	EB40-211-A		1		
11	EB40-234-A		1		
10	ST3. 9 × 22		2		
09	HL-YZWF		1		
08	EB-75ERCD-05		1		
07	EB90-8		1		
06			1		
05	HL-YJRF		1		
04	X555		2		
03	EB-75ERCD-06		1		
02	XH-B-3		1		
01	H05RR-F		1		

--	--	--	--	--	--

Model: IOM75S

No	Part No.	Description
1	H05RR-F	power cord
2	XH-B-3	electric box
3	EB-75ERCD-06	outer rear panel
4	X555	Oven lamp
5	HL-YJRF	convection fan motor and blade
6		round plate
7	EB90-8	mounted plate for upper elements
8	EB-75ERCD-05	Outer oven top panel
9	HL-YZWF	cooling fan
10	ST339X22	screw
11	EB40-234-A	exhausting box
12	EB40-211-A	exhausting cover for cooling fan
13	EB40-210-A	Outer top insulation panel
14	EB90-19-2	top element
15	EB-75ERCD-13	Insulation blanket - top
16	EB90-38	Protective sheet for top element
17	EB-75ERCD-09	Right frame for cavity
18	EB-68ECD3-16	Outer oven side panel R/H
19	EB-68ECD8-31	oven side handle
20	EB90-28-2	door hinge R/H
21	EB-68ECD8-25	mounted sheet for control panel
22	EB-75ERCD3-P-01	base board for control panel
23	55.19-	temperature control
24	EB56-122-A	gasket for control panel
25	EB90-33	mounted sheet for temperature control
26	EB90-34	mounted cover for temperatrue control
27		digital timer
28	EB-75ERCD3-P-02	glass for control panel
29	EB75-BD02-01	Control panel
30	NA05_mat black	knob
31	EB90-14	back cover for convection fan
32		nut for back cover
33	EB90-20	Oven door seal
34	EB-75ERCD-03-04	Inner oven door glass
35	EB-75ERCD-03-03	Middle oven door glass
36	EB-75ERCD-03-05	Exhausting cover on glass door
37	EV90-37-A	Bracket for glass - right
38	EB90-44-A	bracket for glass - top
39	EB56-08-01	Gasket for handle screw
40	EB75ERCD-03-02	ourter glass
41	EB-75ERCD-28	door handle
42	EB75-14-01	S.S strip on ourter glass
43	EB90-40-A	bracket for door hinge R/H
44	EB90-41-A	bracket for door hinge L/H
45	EB90-28-1	Oven door hinge L/H & R/H
46	EB90-38-A	Bracket for glass - left

No	Part No.	Description
47	EB56-182-A	bracket for middle glass
48		Indicator light
49	EB56-153-3A	bracket for display
50		function switch
51		screw
52	EB90-19-3	Round element
53	EB90-19-1	bottom element
54	EB90-5	Heating element base plate
55	EB-75ERCD-04	Outer base plate
56	EB-75ERCD-07-00	side board for cavity
00057	EB-75ERCD-08	Left frame for cavity
00058	EB-75ERCD-10	bottom frame
00059	EB-70-05-01	small grill rack
00060	EB90-15-C	backing tray
00062	EB70-11-04	side rack left/right
00063	EB90-18-1	big grill rack
00064	EB-68ECD3-15	Outer oven side panel L/H
00065		aluminum sleeving
00066	EB90-6	synchronous motor board
00067	EB-75ERCD-27	thermostat - 172 degree
00068		thermostat - 50 degree
00069	EB70-14-01	Fixing bracket for thermo