




TU950TLE8

Position	Part No.	Description	QTY
1	SP200037000	wall cover baord	1
2	PA210004000	pan support	1
3	PA210003027	iron cap-wok small	1
4	PA210003028	iron cap-wok large	1
5	PA210003000	iron cap-rapid	1
6	PA210001013	burner cover-wok	1
7	PA210001001	burner cover-rapid	1
8	XZ200012001	hob panel	1
9	PA210016009	aluminium tube	1
10	PA210006003	wok thermocouple	1
11	PA210005002	indicator light	1
12	PA210002005	burner base	1
13	SP200008003	pan support	1
14	PA210005000	ignition light	2
15	PA210002006	burner base-rapid	1
16	PA210029000	air flue	1
17	PA210034000	spark pack	1
18	SP200025000	air flue	1
19	PA210031014	overheat protector	1
20	SP200026003	bottom flue	1
21	PA210032013	selector switch	1
21	PA210032015	selector switch EGO	1
22	PA210036008	temperature switch	1
23	PA210012011	inner air flue	1
24	PA210015001	44mm	1
	PA210015000	65mm	1
	PA210015002	34mm	2
	PA210015003	29mm	1
25	PA210038000	microswitch	1
26	PA210039005	knobs TK4#	7
27	SP200032003	inner support	1
28	XZ200004000	door seal	1
29	PA210042000	side rack fixing kit	2
30	PA210049000	side rack	2
31	PA210008037	fan element	2
32	SP220024033	inner assembly	1
33	PA210008002	grill element	1
33	PA210008048	grill element EGO	1
34	SP230078002	hinge fixing board	1
35	SP220001011	fan element cover board	1
36	SP200002000	timer support	1
37	PA210035051	timer	1
38	PA210077000	timer buttons	6
39	SP200015002	panel connect trim	1
40		contol panel	1
40	SP200007098L	contol panel EGO	1
41	PA210037005	indicator light	2
42	PA210028000	handle	1
43	SP200063001	rear support	1
44	XZ200017000	side panel	1
45	PA210027000	wire rack	2
46	PA210026000	tray rack	1
47	PA210057000	tray guide kit	2
48	SP220027000	baking trey	1
49	PA210048002	telescopic runner	1
50	SP200005003	telescopic runner support	1
51	SP240018002	bottom drawer cover board	1

Position	Part No.	Description	QTY
52	SP240020000	drawer inner support	1
53	SP200019037	drawer panel	1
54	PA210056000	stop pushing washer	2
55	SP200029018	feet	1
56	SP240022004	inner cover baord	1
57	SP200006011	feet fixing	1
58	SP200030005N	kick panel	1
59	SP200005002	telescopic rim	1
60	SP200031002	kick panel fixing board	1
61	SP200029019	feet	1
62	PA210018003	non-slip feet	4
63	XZ200017016	side panel	1
64	SP200003000	bottom fixing support	1
65	PA210008000	bottom element	1
66	PA210025003	cable	1
67	PA210055000	terminal box	1
68	SP230078006	hinge guide	1
69	PA210033000	temperature sensor fixing	4
70	PA210046000	insulation fibre	0.056
71	SP200023003	rear fixing board	1
72	SP200032002	inner liner support	1
73	SP210035014	liner front panel	1
74	PA210009009	cooking fan motor	2
75	PA210053000	lamp assembly	2
76	SP200004009	back cover baord	1
77	SP200057001	hold climbing	2
78	SP200056000	air inner flue	2
79	SP200016004	back cover fixing	1
80	SP200016005	back cover fixing	1
81	PA210009008	cooling fan motor	1
82	SP200033000	air flue cover	1
83	PA210030000	cooling fan thermostat	1
84	pa210002008	burner base-rapid	1
85	PA210006001	thermocouple 360mm	2
86	PA210002007	burner base-middle	2
87	PA210006000	thermocouple 500mm	2
88	PA210001003	burner cover-rapid	1
89	PA210001002	burner cover-middle	2
90	PA210003003	iron cap-rapid	1
91	PA210003001	iron cap-middle	2
92	PA210004001	pan support-left&right	1
93	SP200038000	back cover board	1
94	PA210137003	handle washer	2
95	SP200010000	handle fixing board	2
96	SP230014030	door top support	1
97	PA210063006	middle glass top fixing	3
98	SP230014028	door frame support-right	1
99	SP230014029	door frame support-left	1
100	PA210017273	inner glass with trim	1
101	PA210017281	middle glass	1
102	PA210052000	handle	1
103	PA210017252	outer glass	1
104	SP200012006	top trim	1
105	SP200013000	bottom trim	1
106	PA210040006	hinge	2
107	PA210021008	middle glass fixing	1
108	PA210021009	middle glass fixing	1
109	PA210063001	glass fixing	1

New Inner Glass 30500400069 (October '17)

Position	Part No.	Description	QTY
110	PA210014001	washer	3
111	PA210113000	air inner connector	1
112	PA210095001	end cap	1
113	PA210011000	copper elbow	1
	XZ200001429	COMPLETE DOOR (NEW)	