



















Model: LEF7GGSS

No	Part No.	Description
1	21150079	60L GAS OVEN FOR SELF-CLEAN. CAT. PAN.
2	03210103	FOOTSTALL 70X60
3	03170241	ADJ. FOOT
4	03210156	UNDER OVEN DOOR MX66
5	03120269	WOOL GLASS EUROVER 2000
6	03210145	RT/LT STEEL SIDE 96-76
7	03120016	INSULATING MATTRESS
8	03040076	OVEN DOOR HINGE HOLDER
9	10160474	BAR FIXING OVEN/SIDES MX76G
10	10160336	RAMP SUPPORT BAR
11	10160550	BACK 70X60 (for 40mm working top)
13	03210175	COMPLETE CHIMNEY COOKER 60X60
14	03110547	FRONT PANEL FOR MX76GI/V
15	10160059	SWITCH BOARD FIXING SQUARE
16	03170155	B-IN OVEN CONTIN.GASKET
19	10580208	WORKING TOP MX66 U.K.
21	03060115	2FLAMES GRID 70X60 WITH RUBBER FEET
22	03060116	5TH BURNER GRID 70X60
24	03100108	SMALL FLAME DISTRIBUTOR SUPPORT
24	03100109	MEDIUM FLAME DISTRIBUTOR SUPPORT
24	03100110	LARGE FLAME DISTRIBUTOR SUPPORT
25	03090016	SMALL CROWN FLAME DISTRIBUTOR
25	03090017	MEDIUM CROWN FLAME DISTRIBUTOR
25	03090018	LARGE CROWN FLAME DISTRIBUTOR
26	03190048	SMALL FLAME DISTRIB.COVER
26	03190049	MEDIUM FLAME DISTRIB.COVER
26	03190050	LARGE FLAME DISTRIB.COVER
27	10160015	HOB HINGE FIT
28	03040014	RIGHT HINGE FOR WORKING TOP
28	03040015	LEFT HINGE FOR WORKING TOP
29	10160078	RIGHT HOB HINGE SQUARE
29	10160079	LEFT HOB HINGE SQUARE
31	03080190	LID FRAME 70X60
32	03040030	RIGHT HINGE FOR GLASS LID
32	03040031	LEFT HINGE FOR GLASS LID
33	03050264	GLASS LID 70X60
34	20090051	GLASS LID RUBBER SUPPORT/FEET
40	03040077	LT/RT OVEN DOOR HINGE/TRIPLE GLAZ.DOOR
47	03050195	OVEN DOOR GLASS MX65-66
47	10020199	RT OVEN GLASS SUPPORT SQUARE
47	10020200	LT OVEN GLASS SUPPORT SQUARE
48	03070044	60L OVEN DOOR HANDLE/DIAM.=18
49	03020100	SCREW M5X25 FIX.OVEN DOOR HANDLE
49	03170220	WASHER FOR UNDER HANDLE BUSH
49	03170228	UNDER HANDLE BUSH
51	20170314	COCK WITH SAFETY ONE SCREW 0,27

No	Part No.	Description
51	20170315	COCK WITH SAFETY ONE SCREW 0,29
51	20170316	COCK WITH SAFETY ONE SCREW 0,39
51	20170317	COCK WITH SAFETY ONE SCREW 0,65
52	03100149	CUP FOR RAPID/BIG BURNER
52	03100147	CUP FOR SMALL BURNER
52	03100148	CUP FOR MEDIUM BURNER
52	03100149	CUP FOR RAPID/BIG BURNER
53	03090042	INJECTOR 0,85
53	03090110	INJECTORS 0,5 S/222
53	03090113	INJECTOR DIAM. 1,10
53	03090492	INJECTORS 0,92 S/222
53	03090493	INJECTORS 0,72 S/222
53	03090494	INJECTORS 1,07 S/222
54	03090254	THERMOCOUPLE MM. 750
54	03090271	THERMOCOUPLE MM 320
54	03090272	THERMOCOUPLE MM 500
54	03090273	NUT FIXING HOB THERMOCOUPLE
54	03150402	TREBLE RING PIPE FOR MX76
55	03150430	LEFT ANT. PIPE MX75/SAFETY
55	03150398	BACK LEFT GAS PIPE
55	03150451	RIGHT ANT. PIPE FOR MX76
55	03150460	RIGHT BACK PIPE MX76
56	10160080	CLIP FIXING RAMP ON BAR
56	10160395	SQUARE FIX.RAMP ON SWITCHBOARD+ FRONT
57	03090350	CONNECTION TO GAS PIPE (NIPLES)
58	03090072	WASHER "AL" FOR NIPPLES
59	03150615	SHORT RAMP X46G/ONE HAND IGN.
60	03020383	CLIP FIXING DRILL
65	03010329	LAMP HOLDER COMPL.WITH LAMP 25W
65	03010541	LAMP 25W E/14
68	03010088	WIRE HO5RR-F 3X1 AUSTRAL
69	03010615	GENERATOR 6OUT.
76	03010211	GREEN LED
76	03010222	PILOT LAMP T150 mm250
79	03010239	BIPOLAR SWITCH
80	03010241	BLACK CROWNED ESC. PLATE
81	03010242	GRILL CROWNED BLACK BUTTON
81	03010246	LIGHT/SPIT BLACK CROWNED BUTTON
82	03010424	IGNITION CANDLE FOR HOB BURNER
86	10500206	BLACK LOWER TRAY
91	03010526	TURNSPIT ROD CE
92	03010384	TURNSPIT HANDLE
93	10500230	OVEN TRAY 60lts MF OVEN
99	03120158	WOOL GLASS FOR BACK
104	03020086	SCREW 4,2X14,5 FIX.WORKTOP
104	03020386	CLIP FIX.SWITCH BOARD
121	20090107	THERMOSTAT 0,55 72L

No	Part No.	Description
122	03170181	OVEN BURNER
123	03090230	THERMOCOUPLE FOR THERMOST.1200MM
123	03090231	OVEN THERMOCOUPLE FIXING NUT
124	03010419	IGNITION CANDLE EFP239-2 L=1000
125	03010382	TURN-SPIT MOTOR
126	03090226	RING NUT INJECTORHOLDER S-42
126	03090155	INJECTOR HOLDER
127	03090125	INJECTOR X INJ.HOLDER 1,30
130	03150453	OVEN PIPE MX76
136	03010493	GRILL HEATING ELEMENT 1500 W
142	03170169	MINUTE-COUNTER
143	03010584	CATENARY (5 SW.)/GAS OVEN
145	10160405	TURNSPIT SPACER BAR - MULTIF. OVEN
146	03170210	TURNSPIT SUPPORT/60L OVEN
149	03010509	FEEDING WIRE SUPPORT
150	03010632	EL. THERMOSTAT/MULTIF. OVEN
161	03060082	UP-DOWN 60L OVEN GRID
162	03060094	UPSIDE OVEN GRID/MULTIF. 60L OVEN
163	03060089	SIMPLE OVEN GRID/60X60
164	03060079	LT/RT SIDE FIX. SHELVES MX66G
165	03020094	SCREW M5 FIX.OVEN SIDE GRIDS
166	03020225	NUT FOR SCREW M5
167	03140264	BLACK KNOB (EL. MOD.)
168	03140263	BLACK KNOB (GAS MOD)
174	03100150	TR.RING CUP
175	03100181	TR.RING BUR.FLAME DITRIBUTOR/3,9kW
176	03190060	EXTERN.TRIPLE RING BURN.COVER
177	03190069	EXTERN.TRIPLE RING BURN.COVER
178	03170239	TRIPLE RING CUP GASKET
179	03090468	THERMOCOUPLE TRIPLE RING BURN.3,9kW
180	03090469	NUT FIX.THERMOCOUPLE TRIPLE RING BURN.
181	03010609	TR.RING IGNIT.CANDLE/3,9kW
182	03020566	SPRING FIX.TRIPLE RING CANDLE
195	21500774	RIGHT END WALL PROTECTION/WORK TOP 40mm
195	21500775	RIGHT END WALL PROTECTION/WORK TOP 40mm
201	03170229	FRONT PANEL GASKET
214	03170234	INTERN.OVEN DOOR PROTEC.RUBBER
221	03080033	RT STEEL PROFILE TRIPLE GL.DOOR
222	03080034	RT STEEL PROFILE TRIPLE GL.DOOR
223	03080030	SUP.STEEL LIST TRIPLE GL. DOOR
224	03050287	NEUTRAL INTER.OVEN DOOR GLASS
225	03080032	SPACER FOR OVEN DOOR GLASSES
999	03060073	WOK GRID D=190