




TU950TLE8

Position	Part No.	Description	QTY
1	SP200037000	Splash back	1
2	PA210004000	pan support	1
3	PA210003027	inner lid for triple ring burner	1
4	PA210003028	outer lid for triiple ring burner	1
5	PA210003000	Rapid fire burner iron cover	1
6	PA210001013	flame spreaderfor triple ring burner	1
7	PA210001001	lid for rapid burner	1
8	XZ200012001	panel	1
9	PA210016009	aluminuim pipe	1
10	PA210006003	thermocouple	1
11	PA210005002	spark pin	1
12	PA210002005	burner base for triple ring burner	1
13	SP200008003	support for burner	1
14	PA210005000	spark pin	2
15	PA210002006	burner base for rapid burner	1
16	PA210029000	Row chimneys	1
17	PA210034000	ignition	1
18	SP200025000	duct	1
19	PA210031014	Overheat protector	1
20	SP200026003	bottom board for duct	1
21	PA210032013	Selector switch	1
21	PA210032015	Selector switch-EGO	1
22	PA210036008	Temperature control switch	1
23	PA210012011	primary pipe	1
24	PA210015001	valve	1
25	PA210038000	microswitch	1
26	PA210039005	knob	7
27	SP200032003	Panel fixed connection board	1
28	XZ200004000	door sealer	1
29	PA210042000	fixing axes for side rack	2
30	PA210049000	side racks	2
31	PA210008037	fan element	2
32	SP220024033	cavity	1
33	PA210008002	grill element	1
33	PA210008048	grill element EGO	1
34	SP230078002	Hinge connecting plate	1
35	SP220001011	fan element cover	1
36	SP200002000	timer fixer	1
37	PA210035051	Timer	1
38	PA210077000	Timer buttons	6
39	SP200015002	Timer buttons fixer	1
40	SP200014003	control panel	1
40	SP200007098L	control panel EGO	1
41	PA210037005	indicator	2
42	PA210028000	handle for rack	1
43	SP200063001	support	1
44	XZ200017000	side panel	1
45	PA210027000	wire rack	2
46	PA210026000	grill rack	1
47	PA210057000	baking tray fixer	2

Position	Part No.	Description	QTY
48	SP220027000	baking tray	1
49	PA210049001	slide board	1
50	SP200005003	slide board fixer	1
51	SP240018002	drawer bottom panel	1
52	SP240020000	drawer inner panel	1
53	SP200019037	drawer panel	1
54	PA210056000	anti-skid feet	2
55	SP200029018	fixing frame for adjustable feet	1
56	SP240022004	drawer	1
57	SP200006011	feet fixer	1
58	SP200030005	fixer board	1
59	SP200005002	slide board fixer	1
60	SP200031002		1
61	SP200029019	feet fixer	1
62	PA210018003	anti-skid feet	4
63	XZ200017016	side board	1
64	SP200003000	bottom element fixer	1
65	PA210008000	bottom element	1
66	PA210025003	power cord	1
67	PA210055000	terminal box	1
68	SP230078006	hinge plate-right	1
69	PA210033000	temperature sensor fixer	4
70	PA210046000	insulation fibre	0.056
71	SP200023003	cavity fixer	1
72	SP200032002	cavity fixer	1
73	SP210035014	cavity front panel	1
74	PA210009009	circulation motor	2
75	PA210053000	lamp holder	2
76	SP200004009	back cover	1
77	SP200057001		2
78	SP200056000		2
79	SP200016004	fixing frame for panel-right	1
80	SP200016005	fixing frame for panel-left	1
81	PA210009008	cooling fan	1
82	SP200033000	Baffle	1
83	PA210030000	thermostat	1
84	PA210002008	burner base for auxiliary burner	1
85	PA210006001	thermocouple	2
86	PA210002007	burner base for semi-rapid burner	2
87	PA210006000	thermocouple	2
88	PA210001003	lid for auxiliary burner	1
89	PA210001002	lid for semi-rapid burner	2
90	PA210003003	middle pan support	1
91	PA210003001	lid for semi-rapid burner	2
92	PA210004001	pan support	1
93	SP200038000	splash back cover	1
94	PA210017169	inner glass	1
95	PA210063000	inner glass bulckle	4
96	SP220010005	door frame	1
97	PA210021003	fixing bucket for middle glass	4
98	PA210052000	handle	1
99	SP200012000	top s.s frame for oven door	1

Position	Part No.	Description	QTY
100	SP200010000	Shake handhandle support block	2
101	PA210017030	middle glass	1
102	PA210040006	hinge	2
103	PA210064000	removable fixing bucket for inner glass	3
104	PA210017003	Outer Glass	1
105	SP200013000	bottom s.s frame for oven door	1
106	SP200011002	Panel fixed frame	8
107	SP200009000	Panel fixed frame under	3
108	SP230078005	silicon washer	2
109	PA210014001	inlet connector	3
110	PA210113000	block	1
111	PA210095001	elbow pipe	1
112	PA210011000		1
	XZ200001429	complete door (new)	
	XZ200001025	complete door (old)	