


Exploded view - RQ-115S



Model: RQ-115S

No	Part No.	Description	Qty
1	20122080163	Door hinge cover	1
4	20122080162	Door hinge screw hole cover	1
5	3031400148	Upper door hinge,right	1
7	2501100002	Door switch	1
8	2100170087	Door	1
8.1	3020400019	Door gasket	1
8.2	20122090569	Right aid-closer,lower door	1
8.3	20122090569	Left aid-closer,lower door	1
11	20120030015	Cover of crisper drawer	1
13	20120020052	Shelf of refrigerator chamber	1
14.1	3050500008	Lamp bulb	1
14.2	2207100001	Thermostat knob	1
14.3	20122010050	Lamp cover	1
14.4	20122010013	Thermostat cover	1
14.5	3040200018	Thermostat	1
14.6	3050600003	Lamp holder	1
23	3040300002	Evaporator assembly	1
24	20122990052	Water pan	1
25	3031400067	Lower door hinge	1
26	20122990810	Short adjust leg	1
27	20122090201	Freezer Door	1
31	3039900125	Compressor support base	1
32	3050100124	Power supply cord plug	1
34	3050200094	Earthing wire of compressor	1
35	3040100092	Compressor	1
36	3040600005	Process tube	1
37	20114070006	Connecting tube	1
39	3040500009	Drier filter	1
42	20122040402	Crisper drawer	1
43	20122990782	Long adjust leg	1
45	3020500090	Door bar,upper	2
46	3031500004	Door bar,lower	1
300	2700500261	Trade mark	1
301	2700105810	Carton	1