


Exploded View



Model: RQ87TD

No	Part No.	Description	Qty
2	20010187	Cover of door hinge screw hole	1
3	20122080090	Door hinge cover	1
4	3031400148	Upper hinge assembly	1
6	20016012	Upper door gasket	1
8	20101061111	Upper door	1
9	20010068	Right limit block of door	1
10	20010371	Left limit block of door	1
11	20101060493	Lower door	1
12	20016110	Lower door right aid-closer	1
13	20016111	Lower door left aid-closer	1
14	20016013	Lower door gasket	1
15	20012449	Lower Rack	1
16	20012447	Upper rack	2
19	20012441	Crisper Drawer (ice blue)	1
20	10200607	Crisper box cover	1
21	3039900264	Compressor support base	1
22	3050100003	Power supply cord	1
23	20060745	Drier filter (for R600a)	1
24	20060046	Connecting tube (short)	1
25	3040100315	Compressor	1
26	20050008	Earthing wire of compressor	1
27	20050009	Connecting wire of compressor	1
28	20061718	Process tube	2
29	20014437	Wire Box	1
30	20014438	Base of wire box	1
31	20010123	Long Adjustable Foot	1
32	20010111	Short Adjustable Foot	1
33	10203743	Shelves of fridge (glass)	2
34	20022150	Lower Door Hinge Assembly	1
35	20014084	Lamp cover	1
36	20050046	Lamp Bulb (E14,220V)	1
37	20014085	Knob	1
38	20014082	Thermostat cover	1
39	20060135	Thermostat	1
40	20050111	Lamp holder (E14)	1
41	20050016	Door switch	1
42	20010193	Drain pan	1
43	20023116	Middle hinge	1
45	20122080090	Carton	1