




Model: VCG90S

No	Part No.	Description	Qty
1	17S915B-F	Inlet tube	1
2	142004-34	Valve 4	1
3	142002-34	Valve 2	1
4	142003-34	Valve 3	1
5	142001-34	Valve 1	1
6	270001-3	Nip for the tube	1
7		Sealing ring for valve	1
8	18S915B-F1	Aluminum tube 1	1
9	18S915B-F2	Aluminum tube 2	1
10	18S915B-F3	Aluminum tube 3	1
11	18S915B-F4	Aluminum tube 4	1
12	18S915B-F5	Aluminum tube 5	1
13	12S915	Bottom plate	1
14	130501	50# burner basement	1
15	130504	50# nozzle	1
16	200004-4	Ignition pin (470)	1
17	131001	100# burner basement	1
18	131004	100# nozzle	1
19	200004-3	Ignition pin (370)	1
20	220002	Knob	5
21	11S915	S.S panel	1
22	130502	50# burner	1
23	130503	50# burner cap	1
24	131002	100# burner	1
25	131003	100# burner cap	1
26	15S915-D3	Right pan support	1
27	15S915-D2	Middle pan support	1
28	15S915-D1	Left pan support	1
29	130703	70# burner cap	2
30	130702	70# burner	2
31	131204	120# burner cap - internal	1
32	131203	120# burner cap - external	1
33	131202	120# burner	1
34	216220	Ignition sparker	1
35	240001	Electric box	1
36	200004-1	Ignition pin (120)	1
37	130701	70# burner basement	2
38	130704	70# nozzle	2
39	200003-4	Ignition pin (470)	1
40	131201	120# burner basement	1
41	131205	120# nozzle	1
42	171001	Elbow	1
43	171002	Gasket washer	1
44	171003	connector	1
45	171004	Nut for connector	1