

ELECTRIC HOBS

USER AND INSTALLATION INSTRUCTIONS

VENINI
EUROPEAN EXCELLENCE

For future reference please record the following information which can be found on the Rating Plate and the date of purchase which can be found in the invoice:

Model Number

Serial Number

Date of Purchase

CONTENTS

General Information	Page 4
Warning Safety Instructions	Page 5
Instructions for Use	Page 6---7
Instructions for Installation	Page 8--10
Technical Data	Page 11
Conditions of Guarantee	Back cover

GENERAL INFORMATION

Please read this booklet thoroughly before you use this appliance. It is important that you understand all the control functions before commencing to cook with your Venini appliance.

Please remember the advice and warnings shown on page 5 which is headed 'IMPORTANT – Warning and Safety Instructions'.

This appliance is designed for domestic household use when built into kitchen worktop.

NOTE: The housing, adjacent furniture and all materials used in the installation must be able to withstand a minimum temperature rise of 85°C above ambient during periods of operation. This information is for guidance only and the actual withstand temperature will depend on the performance rating for the surface finish of the worktop.

Certain types of kitchen furniture surface finishes are particularly prone to heat damage or discolouration at temperatures lower than the above guidelines.

Installing the appliance in contravention of the guidance given will be at the liability of the owner.

The use for any other purpose or in any other environment without the express agreement of Venini would invalidate any warrantee or liability claim.

Your new appliance is guaranteed against electrical or mechanical defects subject to certain exclusions noted in Venini Conditions of Guarantee.

The foregoing does not affect your statutory rights.

For Warranty conditions in Australia please consult the enclosed Cucina Australia Warranty card, or call Cucina National Service on 1800 444 357.

Before using this appliance ensure that any protective packaging or coatings have been removed.

To aid the protection of the environment, please sort the packing materials into different types and dispose of them in accordance with the local waste disposal laws.

Any further information on waste disposal can be obtained from your local Environment Agency office.

When first used, an odour may be emitted by any residual protective finish or moisture, which will cease after a short period of time.

This appliance has been constructed and distributed in compliance with the essential requirements of the following EEC DIRECTIVES, EUROPEAN NORMS and Australian Standards:

CE Marking – 93/68 Low Voltage – 73/23 EMC – 89/336

Materials that can touch food – 89/109.

Safety Standards – EN 60 335-1, EN 60 335 – 2 – 6, AS/NZS3350-1, AS/NZS3350-2-6

As Venini have a policy of continued product improvement, the right is reserved to adjust and make any modifications deemed necessary without notification.

IMPORTANT NOTE – WARNING and SAFETY INSTRUCTIONS

This appliance complies with all current European and Australian safety legislation, however Venini do wish to emphasise that compliance does not remove the fact that surfaces will become hot during use and retain heat after operation.

Venini advise that the appliance is not intended for use by young children and infirm persons without supervision.

Young children should be supervised to ensure they do not play with the appliance.

If it is necessary for younger family members to be in the kitchen, please ensure that they are kept under close supervision at all times.

We also advise that great care is taken during use and cleaning operations.

Do make sure that the pan handles are always correctly positioned to avoid accidental contact.

Do not leave heated oil or fat unattended as there is a risk of fire.

Do use pans that are flat bottomed and the correct size for the heating area to be used (never smaller).

Do not allow electrical fittings or cables to be in contact with hot areas of the appliance.

Do not use the appliance for space heating or to dry clothes.

Do not install the appliance next to curtains or soft furnishings.



⚠: This appliance must be correctly installed by a suitably qualified person, strictly in accordance with the manufacturer's instructions.

Venini declines any responsibility for injury or damage to persons or property as a result of improper use or installation of this appliance.

Heat, steam and moisture will be created during use, take care to avoid injury and ensure that the room is adequately ventilated. If prolonged use occurs, additional ventilation may be required – please consult your Qualified Installer if you are in any doubt about the amount required.

WARNING

- Do not use commercial simmering aids as these can create excessive heat that can damage the appliance
- Do not leave hotplates on without a pan or an empty pan
- Be aware that hotplates will retain heat whilst cooling down
- **When cooking foods with high sugar content, ensure that any spillage is removed immediately to avoid damage to the cooktop surface.**

HELPFUL HINTS

- Always use the correct diameter pan, one that is the same or slightly larger than the hotplate.
- The bottom of the pan must be flat
- Whenever possible keep the lid on the pan while cooking
- Avoid over-spill of liquid by reducing the heat when boiling has occurred

CLEANING THE APPLIANCE

Always allow the appliance to cool down before cleaning to avoid a burn injury

SOLID HOTPLATES – VSEC / VSEC.2/ VECE

The hotplates should be lightly greased with oil (using a soft cloth). This will ensure that the surface remains clean and will also prevent formation of rust.

INSTRUCTIONS FOR INSTALLATION

This appliance must be installed by a competent person in accordance with the current version of the following Regulations and Safety Standards or your local Regulations and Safety Standards.

Venini Installation Instructions

In Australia the installation must comply with AS/NZS3000 wiring rules.

POSITIONING THE APPLIANCE

This appliance is classified as Class 3 and therefore is to be built into a kitchen unit (depending on size) or 600mm worktop, providing the minimum distance is allowed.

- 650mm between the top surface and the underside of any horizontal surface above it.
- 50mm clearance around the appliance and any combustible materials

The surface of any adjacent unit must be capable of withstanding a minimum temperature rise of 85°C.

PRE-COMMISSING THE APPLIANCE

When unpacked, check that the following parts are included with the appliance


- Venini Instructions and Installation booklet
- Adhesive sealing agent and fixing clamps & screws

INSTALLATION NOTES

- 1 Cut the aperture to the dimensions shown in the table below or use the template provided on the packaging.
- 2 Invert the hob and apply the sealing agent provided to match the outer perimeter edge.
- 3 If the sealing agent is a strip type, the protective covering must be removed from both sides. Do not leave a gap in the sealing agent or overlap the thickness.
NOTE: do not use any Silicone based sealant, as this can damage the worktop surface if repairs are required.
- 4 Insert the appliance into the aperture and fix into position via the clamps & screws, tightening the screws evenly (see fig.3.)




Fig.3.



HOB APERTURE DIMENSIONS

MODEL	A	B	C	D	E
VSEC	585	500	560	480	30
VSEC.2	585	500	560	480	30



ELECTRICAL CONNECTION

This appliance must be installed by a competent person, such as one holding NICEIC Registration and in accordance with the latest edition of the IEE WIRING Regulations.

Before connecting the appliance, make sure that the supply voltage marked on the rating Plate corresponds with the mains supply voltage.

In Australia the appliance must be installed by a qualified electrician in accordance with AS/NZS3000 wiring rules.

WARNING – THIS APPLIANCE MUST BE EARTHED

Depending on the Power Input of the model to be installed, connection will require a 32Amp protected supply using a switched double pole isolating unit having a minimum 3mm contact separation. (see Technical Data at page 11 for full information).

Care must be taken to avoid the cable being in contact with hot parts of the appliance.

The isolating unit should be placed in an easily accessible position adjacent to the appliance.

NOTE

The appliance must not be connected to the mains supply by means of a 10A plug and socket.

MAINTENANCE

During the guarantee period, in case of need all service intervention should be referred back to the Venini Service Department. Please note that intervention or repair by any unauthorised personnel will invalidate such guarantee.

TECHNICAL DATA

ELECTRICAL DETAILS

Rated Voltage: 240V ac 50Hz

Supply Connection: Switched Double-pole Isolator with 3mm contact separation

POWER INPUTS AND PROTECTION RATING

Model	Max kW	Total Amp	Min Fuse Protection Rating
VSEC	6.0	30Amp	32Amp
VSEC.2	5.0	25Amp	32Amp
VECE6005	5.0	25Amp	32Amp
VECE6008	5.0	25Amp	32Amp

Mains Supply Connection Cable: 3 x 2,5mm² type HO5 V2V2-F <HAR>marked

NOTE:

For cable connection details, see diagram on appliance base plate.

VENINI
CONDITIONS OF GUARANTEE

Dear Customer,

Included with your new Venini appliance is a guarantee registration card, please complete this and return and your earliest convenience.

This guarantee is in addition to your statutory legal rights and will not in any way hinder any legal rights.

The conditions of the guarantee, which applies, to your Venini appliance are as follows:

All 'Work' in relation to the Guarantee must be carried out by Venini or an approved service agent of Venini. Any claims made under the terms of the guarantee must be supported by the original invoice / bill of sale issued at the time of purchase.

The guarantee period starts from the date of the original purchase and the manufacturer will provide the parts and labour required to repair the appliance should breakdown occur as a result of mechanical / electrical failure. This service will be given Free of charge within the Guarantee period. An additional Insurance scheme is available should you wish to extend the warranty period.

THIS GUARANTEE DOES NOT COVER:

- Any damage caused by transit, misuse, or neglect.
- Cosmetic and perishable parts: plugs, fuses, light bulbs, light covers, cosmetic trims, cables, filters and attachments, knobs, any rubber and seals, ceramic or glass surfaces, dents, scratches, paintwork.
- Attachments / Accessories, trivets and handles, griddles, pan stands, shelves, burner caps and collars, oven liners. Plus any additions thereafter.
- Periodic maintenance, the repair or replacement of parts due to natural wear and tear.
- Material discoloration, corrosion.
- Incorrect installations, modifications or repair by any unauthorised personnel.
- Use of non-Venini parts.
- Damage caused by foreign objects or substances.
- Appliances used for non-domestic use.
- Operation on unsuitable voltage, water or gas supplies.
- Accidents, Civil war, acts of God or any cause beyond the control of Venini.

PLEASE NOTE ALL GUARANTEES ARE NON TRANSFERABLE

For Australian Warranty Terms and Conditions, please refer to your enclosed Warranty Card.

AUSTRALIAN SALES

PH: 1300 132 824

FX: 1300 660 188

AUSTRALIAN SERVICE

PH: 1800 444 357

FX: 1300 133 279

For further information or any other query you may have please contact one of the above numbers. Thank you for buying Venini.

