
















Model: VEF90EG

No	Part No.	Description	Comments
11	202375	PART FOR BURNER FIXING	
38	306003	THERMOSTAT CLIP	
39	306002	SPRING FOR KNOB	
80	504160	COVER FOR SMALL FLAME SPREADER	
81	504161	COVER FOR MEDIUM BURNER	
82	504162	COVER FOR RAPID BURNER	
83	504158	COVER OUT FOR ULTRA RAPID FLAME SPREADER	
83	504800	COVER OUT FOR ULTRA RAPID FLAME SPREADER	from 13/12/10
84	504191	COVER IN FOR ULTRA RAPID FLAME SPREADER	
84	504798	COVER IN FOR ULTRA RAPID FLAME SPREADER	from 13/12/10
117	101414	PROTECTION FOR FAN ASSISTED OVEN	
120	101280	OVEN TRAY	
138	202348	DISHWARMER BOTTOM	
160	202526	BRIDLE FOR FIXING GAS VALVES	
166	101297	INSIDE OVEN DOOR	
176	202351	CARTER MOTORVENTILATOR	
274	202681	HORIZONTAL VENT	
311	301122	SCREW 4,2X30	
312	200145	OVEN GLASS FIXING RING	
313	301073	SCREW 5MAX10 TCT	
329	309116	HIGH INSIDE DOOR SPACER	
385	306024	SPRING FOR SPARK PLUG	
389	301077	SCREW M5X35 FOR HANDLE	
392	309026	PART FOR KNOB PROTECTION FIXING	
425	415054	SPARK PLUG 350MM	
426	415057	SPARK PLUG 700MM	
428	415073	SPARK PLUG FOR ULTRA RAPID BURNER	
428	415102	SPARK PLUG FOR ULTRA RAPID BURNER	from 13/12/10
430	415081	ACCUMULATOR	
436	402090	BACK FIBER GLASS	
441	404042	SIDE GRID FOR OVEN	
442	404154	GRID FOR OVEN	
443	404151	GRID FOR TRAY	
444	405003	OVEN DOOR HINGE FIX PART	
446	405039	OVEN DOOR HINGE M9/D2	
450	409040	ELECTRONIC PROGRAMMER	
453	411084	RING GASKET	
478	200430	DISHWARMER FLAP DOOR	
611	603025	MOTOR convect fan 46mm shaft 220/240V 50/60HZ	33mm see below
614	606062	GRILL RESISTANCE	
615	606045	CIRCULAR HEATER 3000W 240V	
620	602038	COMMUTATOR	
623	608018	OVEN BULB WITH HOLDER	
648	601965	TERMINAL SEPARATOR	
649	608034	SMALL WARNING LIGHT	
667	602025	THERMOSTAT	
670	504128	SMALL FLAME SPREADER	
671	504129	MEDIUM FLAME SPREADER	
672	504130	RAPID FLAME SPREADER	
673	504777	ULTRA RAPID FLAME SPREADER	
673	504796	ULTRA RAPID FLAME SPREADER	from 13/12/10
715	604072	DASYCHAIN SWITCH	
760	510507	SMALL BURNER	
761	510508	SEMI RAPID BURNER	
762	510509	RAPID BURNER	
763	510707	ULTRA-RAPID BURNER	
880	502208	GAS VALVE BY PASS 034	
881	502209	GAS VALVE BY PASS 036	
882	502210	GAS VALVE BY PASS 052	

No	Part No.	Description	Comments
883	502212	GAS VALVE BY PASS 065	
917	200303	STAINLESS STEEL SIDE	
929	202108	VERTICAL VENT	
930	202214	FEET SUPPORT	
940	405075	WORK TABLE AND TOP COVER HINGE RIGHT	
941	405076	WORK TABLE AND TOP COVER HINGE LEFT	
943	308031	BUMPER FOR C.I. GRIDS AND DISHWARMER	
960	408074	CAST IRON PAN SUPPORT 1 BURNER	
965	408073	CAST IRON PAN SUPPORT 2 BURNERS	
972	202360	WORK TABLE FIXING	
1044	4010199	ELECTRIC KNOB BLACK	
1050	4010200	GAS VALVE KNOB RING BLACK	
1051	4010202	COMMUTATOR KNOB	
1052	4010201	ELECTR.THERMOSTAT KNOB RING	
1143	410532	RISER	
1406	403206	OVEN DOOR HANDLE	
1407	406143	OVEN DOOR GLASS STOPSOL	
1409	411052	UNDER GLASS OVEN GASKET	
1411	411087	GASKET FOR OVEN FRONT 4 SIDE	
1411	411088	GASKET FOR OVEN FRONT ONE SIDE	
1415	602037	THERMOREGULATOR	
1421	406349	INTERNAL OVEN GLASS	
1602	210595	CONTROL PANEL	
1614	201160	BACK PANEL	
1615	202411	CONTROL SUPPOR	
1616	402169	FIBER GLASS	
1622	608029	SMALL YELLOW BUD	
1624	200319	WORK TABLE	
1627	501872	GAS COLLECTOR	
1628	501836	TUBE FOR RIGHT FRONT BURNER	
1629	501839	LEFT FRONT BURNER	
1630	501837	TUBE FOR RIGHT BACK BURNER	
1631	501838	LEFT BACK TUBE	
1632	501841	CENTRAL TUBE	
1640	202223	CLAMP PROTECTION FOR FLAP DOOR	
1644	414044	FEET	
1645	414031	BASE FOR LEGS	
1661	202127	OVEN PANEL	
1671	101256	ELECTRIC OVEN PANEL	
1673	101409	BACK PANEL FOR OVEN	
1674	101115	OVEN TOP PANEL BLACK	
1677	101299	FRONT PANEL BLACK M9/D2	
1685	201152	BACK VENT STACK	
1705	200081	OVEN GLASS SUPPORT M9/D2	
2016	101369	OVEN SIDE PANEL BLACK	
2130	201159	GRILL PROTECTION	
4301	410540	RIGHT VERTICAL PROFILE	
4302	410541	LEFT VERTICAL PROFILE	
611	12590030	MOTOR convect fan 33mm shaft 220/240V 50/60HZ	46mm see above