




**Model: 6H-185AX**

| No  | Part No.  | Description                         | Qty |
|-----|-----------|-------------------------------------|-----|
| 3   | CA7A009A5 | SEAL DOOR                           | 1   |
| 4   | CB8H004A1 | GRID OVEN                           | 1   |
| 6   | AS0010931 | GRID PULL SYSTEM PLUS               | 1   |
| 6   | CB8H001A7 | GRID PULL SYSTEM PLUS               | 1   |
| 7   | CB1C000D2 | DISH ROASTS                         | 1   |
| 8   | CB1D000D7 | DISH DEEP ROASTS                    | 1   |
| 10  | C23I001X4 | COMPONENT HOLDER                    | 1   |
| 11  | AS0013487 | SILICONED CONTROL P                 | 1   |
| 11  | CJ7P05428 | SILICONED CONTROL P STAINLESS STEEL | 1   |
| 15  | C98E001C9 | HINGE                               | 2   |
| 16  | X02D006E0 | SCREW                               | 2   |
| 17  | CB3E01326 | INNER DOOR SILICONED                | 1   |
| 19  | CA7U003A4 | SEAL CLOCK                          | 1   |
| 20  | AS0003178 | BRACKET FIXING                      | 1   |
| 20  | C21F00116 | WASHER                              | 2   |
| 21  | CE4A008A7 | SOCKET DISTANCER                    | 2   |
| 22  | C24N032A3 | HANDLE                              | 1   |
| 23  | CB7N17224 | DOOR SILICONED                      | 1   |
| 24  | AS0013831 | BASE RIGHT HANDLE                   | 1   |
| 24  | AS0013832 | BASE LEFT HANDLE                    | 1   |
| 24  | C24N030C9 | BASE RIGHT HANDLE                   | 1   |
| 24  | C24N031C7 | BASE LEFT HANDLE                    | 1   |
| 28  | CB5C00014 | BRACKET BULB SUPPORT                | 1   |
| 30  | C89D007D7 | FRAME ENAMELED                      | 1   |
| 31  | C91C008D3 | COVER FAN                           | 1   |
| 34  | C11R010A0 | OVEN SWITCH                         | 1   |
| 35  | C07J002A4 | INDICATOR BIG/LARGE                 | 2   |
| 36  | C18V006A9 | CLOCK BUTTON INTERMEDIATE           | 3   |
| 37  | AS0013488 | CLOCK                               | 1   |
| 37  | C43I012A6 | PROGRAMMER CLOCK                    | 1   |
| 38  | CA7U005A9 | SEPARATOR TIMER BUTTON              | 3   |
| 39  | C18V020C6 | CLOCK BUTTON TIMER                  | 3   |
| 40  | CL1A009A2 | THERMOSTAT DERIVATOR                | 1   |
| 41  | CA5G000A3 | RESISTOR FOLDING GRILL              | 1   |
| 41  | CA5G001A1 | RESISTOR FIXED GRILL                | 1   |
| 42  | CL1D000A8 | LIMITER TEMPERATURE                 | 1   |
| 43  | C46B002A3 | MOTOR CONVECTION HEATERS            | 1   |
| 45  | CG5G002A4 | FASTENING RESISTANCE                | 1   |
| 49  | C08D000A1 | THERMOSTAT OVEN                     | 1   |
| 50  | C04E002A2 | STOPPER DOOR                        | 2   |
| 51  | C04E000A6 | STOPPER FRAME                       | 2   |
| 55  | C18U008D6 | CONTROL KNOB                        | 2   |
| 58  | CG5G001A6 | HOLDER GUIDE                        | 2   |
| 59  | C14E000A2 | ASSEMBLY LAMPHOLDER                 | 1   |
| 59  | CC1141700 | LAMP OVEN 15W 230V                  | 1   |
| 61  | CA5C006A7 | RESISTOR CONVECTION HEATERS         | 1   |
| 63  | CA5F000A7 | RESISTOR BOTTOM                     | 1   |
| 64  | CH8D002A6 | MOTOR EXTRACTOR                     | 1   |
| 82  | AS0015714 | GUIDE LEFT SIDE                     | 1   |
| 82  | AS0015715 | GUIDE RIGHT SIDE                    | 1   |
| 82  | CB8H016A2 | GUIDE RIGHT SIDE                    | 1   |
| 82  | CB8H017A0 | GUIDE LEFT SIDE                     | 1   |
| 82  | CB8H028A4 | GUIDE LEFT SIDE                     | 1   |
| 82  | CB8H029A2 | GUIDE RIGHT SIDE                    | 1   |
| 110 | AS0011712 | HOLDER RIGHT HINGE                  | 1   |
| 110 | AS0011713 | HOLDER LEFT HINGE                   | 1   |
| 110 | C86C00014 | HOLDER RIGHT HINGE                  | 1   |
| 110 | C86C00112 | HOLDER LEFT HINGE                   | 1   |
| 115 | CG9A004A7 | EXTENSION HINGE                     | 2   |