




Model: 6H-936AX

No	Part No.	Description
0	AS0009320	SELF-ADHESIVE STICK
3	CC1993000	SEAL 2 PINS EACH CORNER
3	AS0022575	SEAL ALT PART NO
5	CC1993100	COVER REAR
6	CC1993200	COVER TOP/UPPER
14	CC1993300	FAN MOTOR CONVECTION HEATERS
15	AS0008325	THERMOSTAT 140°C
16	CC1993500	THERMOSTAT 65°C
17	CC1993600	LAMP HOLDER
20	CC1993700	FAN TANGENTIAL
22	CC1993800	MOTOR ROASTER
34	CC1994000	COVER
35	CC1994100	COVER LEFT SIDE
36	CC2055436	COVER BOTTOM/LOWER
50	CC1994300	DISH DEEP ROASTS
51	CC2055342	GRID OVEN
52	AS0008324	COVER FAN
53	CC2055255	RESISTOR KEYBOARD
54	CC1994700	RESISTOR DOME
55	CC1994800	RESISTOR BOTTOM
56	AS0008323	HOLDER RESISTANCE
59	CC1995000	GRID
60	CC1995100	ENGAGER
61	CC1995200	HOLDER CHICKEN SPIT
62	CC1995300	ROTISSERIE
66	CC1995400	DISH ROASTS
80	AS0008321	HANDLE
81	AS0008322	GLASS DOOR ASSEMBLY
82	CC2041200	BRACKET GLASS FIXING
83	CC1995800	HINGE
84	CC1995900	ASSEMBLY COUNTERDOOR
88	CC1997000	LAMP NEON
89	AS0002140	TULIP RED
91	AS0008320	THERMOSTAT
92	CC1996400	OVEN SWITCH
93	AS0008317	CONTROL PANEL
94	AS0008318	PROGRAMMER CLOCK
95	AS0008319	CLOCK BUTTON
99	CC2041700	RUBBER
112	CC1996900	CLIP
137	AS0008315	BASE HANDLE
138	AS0008316	BASE HANDLE
151	CC2055343	ICE INTERMEDIATE
152	CC2055341	PROFILE
169	AS0000446	CARD LIGHT
170	AS0005049	HOLDER BUTTON

No	Part No.	Description
171	AS0000447	GUIDE LIGHT
172	AS0008313	RETRACTABLE BUTTON 8 FUNCTIONS
173	AS0002103	RETRACTABLE BUTTON