



1

ABITACOLO - PORTA
HABILLAGE - PORTE
COOKER BODY - DOOR

COD. 505129





Model: BAF54GG.1

Page	No	Part No.	Description
1	5	176194	Working table (Spill Tray)
1	6	621492	Control Panel
1	7	166286	Heat deflector for ctrl knobs
1	8	631650	Deflector spacer
1	9	38020101	Door hinge support
1	10	393595	Door seal
1	11	60265801	Front frame
1	12	690368	Warming drawer
1	14	168150	Cooker side rear support
1	17	16814501	Cooker side front support
1	19	38678301	Oven door upper section
1	20	395795	Oven door handle
1	21	60810201	Oven door vertical section
1	22	391199	Oven door hinge
1	23	68992002	Oven door glass Outer
1	27	378565	Inner glass
1	28	16018301	Oven LEFT side panel
1	28	16018401	Oven RIGHT side panel
1	29	16812005	Burners support
1	30	68761901	Working table support rear
1	32	680565	Exhaust duct
1	33	16002601	Rear panel
1	37	386047	Side insulation panel
1	38	682956	Oven cavity inner side panel
1	39	60422801	Drip tray
1	40	602695	Oven base
1	43	393254	Oven shelf
1	45	692735	Assembling splash board set
1	46	390219	Oven side rack
1	47	380607	Right support external cooker side
1	48	380606	Left support external cooker side
1	0	691890	G30 LPG jets (set)
1	0	395658	Grill pan handle (Not supplied as standard)
1	0	993204	Set of 4 legs
2	1	393019	Left hand pan stand
2	2	393018	Right hand pan stand
2	4	380960	Small (aux) burner cap
2	4	380961	Medium (semi rapid) burner cap
2	4	380962	Large (rapid) burner cap
2	5	460613	Small (aux) flame spreader
2	5	460614	Medium (semi rapid) flame spreader
2	5	460615	Large (rapid) flame spreader
2	6	399019	Small burner cup GN 0.90 G20 - 11.3MB
2	6	399020	Medium burner cup GN1.10 G20 - 11.3MB
2	6	399021	Large burner cup GN 1.50 G20 - 11.3MB
2	8	391171	Spark electrode for burners
2	9	220803	Ignition plug clip
2	11A	313855	Ignition Switch
2	11B	313856	Crowned Switch Support
2	11C	313801	Electric ignition switch
2	11C	313808	Power Button
2	13	397320	Small (aux) gas tap
2	13	397349	Medium (semi rapid) gas tap

Page	No	Part No.	Description
2	13	397348	Large (rapid) gas tap
2	15	399045	Thermostat
2	16	399283	Gas connection tube front l/h burner
2	17	399237	gas connection tube rear l/h burner
2	18	399238	Gas connection tube rear r/h burner
2	19	399284	Gas connection tube front r/h burner
2	20	398940	Gas connection tube - Grill
2	21	687268	Main gas supply rail
2	22	380569	Clamp
2	24	398368	GRILL thermocouple
2	26	391558	Ignition electrode - GRILL
2	27	631607	Ignition plug nut
2	28	190034	Grill burner
2	29	698261	Nozzle support D1.20 GRILL
2	30	398942	Gas connection tube - Oven
2	31	306212	Lamp holder / cover / bulb
2	37	160007	Ignition electrode - OVEN
2	38	398371	OVEN Thermocouple
2	39	631606	Thermocouple nut (oven and grill)
2	41	692730	Oven burner
2	42	698232	Oven nozzle support D1.50
2	45	397401	Pressure regulator
2	60	304828	Terminal block
2	61	396215	Gas knob
2	62	224731	Knob spring
2	63	387228	Ring / collar for gas knob
2	64	310044	Spark generator